



SOFTWARE MANUAL

VISILOGIC FUNCTION BLOCKS

V230-21-G23 Rev: 3:00



The information in this document reflects products at the date of printing. Unitronics reserves the right, subject to all applicable laws, at any time, at its sole discretion, and without notice, to discontinue or change the features, designs, materials and other specifications of its products, and to either permanently or temporarily withdraw any of the forgoing from the market.

All information in this document is provided "as is" without warranty of any kind, either expressed or implied, including but not limited to any implied warranties of merchantability, fitness for a particular purpose, or non-infringement. Unitronics assumes no responsibility for errors or omissions in the information presented in this document. In no event shall Unitronics be liable for any special, incidental, indirect or consequential damages of any kind, or any damages whatsoever arising out of or in connection with the use or performance of this information.

The tradenames, trademarks, logos and service marks presented in this document, including their design, are the property of Unitronics (1989) (R"G) Ltd. or other third parties and you are not permitted to use them without the prior written consent of Unitronics or such third party as may own them.

Table of Contents


VisiLogic Function Blocks.....	6
MODBUS (Serial)	10
MODBUS (Serial) Overview	11
MODBUS: Configuration	15
MODBUS: ScanEX and Scan.....	17
Read Coils (1).....	18
Read Inputs (2).....	19
Read Holding Registers (3)	20
Read Float Registers (3).....	21
Read Input Registers (4)	22
Read Float Registers (4).....	23
Force Coil (5).....	24
Preset Holding Register (6).....	25
Loopback Test (8)	26
Force Coils (15).....	27
Preset Holding Registers (16).....	28
Preset Float Registers (16)	29
Read/Write from Data Tables	30
Read/Write Mixed Data via MODBUS	33
Configuring a MODBUS slave device.....	35
Slave Addressing.....	36
MODBUS via GSM or Standard Modem	41
MODBUS Status Operands	42
MODBUS (IP)	45
MODBUS IP Overview	46
MODBUS: Configuration	49
MODBUS: ScanEX and Scan.....	52
Read Coils (1).....	53
Read Inputs (2).....	54
Read Holding Registers (3)	55
Read Flat Registers (3)	56
Read Input Registers (4)	57
Read Float Registers (4).....	58
Force Coil (5).....	59
Preset Holding Register (6).....	60
Loopback Test (8)	61
Force Coils (15).....	62
Preset Holding Registers (16).....	63
Preset Float Registers (16)	64
Read/Write Mixed Data via MODBUS	65
Read/Write from Data Tables	67
Configuring a MODBUS slave device.....	71
Slave Addressing.....	72
SMS Messaging.....	79

SMS Messaging Overview	80
SMS: Scan.....	89
SMS: Send	91
SMS Variables.....	94
SMS: Check GSM Signal Quality	96
Send SMS messages from a GSM cell phone	97
SMS Operands	99
GPRS.....	102
GPRS Overview	103
GPRS Configuration	107
GPRS Register to Network	108
GPRS Run.....	109
Start Call, End Call	110
Listen /Stop Listening to Remote Device.....	111
Unregister from Network	112
Check Signal Quality	113
GPRS Operands & Status Messages	114
PLC DataCom	116
PLC DataCom Overview.....	117
PLC DataCom: Configuration.....	120
Master Data Request.....	124
Update.....	125
DataCom Data Synchronization	126
PLC DataCom Status Messages	127
Protocol FB, Serial.....	128
Protocol FB (Serial) Overview.....	129
Protocol: Configuration	134
Protocol: Scan	135
Protocol: Send	139
Protocol: Copy Buffer Contents	143
Protocol: Reset Buffer	146
Variables	147
Checksum Configuration.....	154
Protocol Status Operands and Messages.....	159
Examples	160
Protocol FB (TCP/IP).....	168
Protocol FB (TCP/IP) Overview	169
Protocol TCP/IP: Configuration	171
Protocol TCP/IP: Scan	173
Protocol TCP/IP: Send.....	177
Variables	178
Protocol TCP/IP Status Messages.....	185
PID	187
PID Overview	188
PID Configuration	190
Run Auto-Tune.....	192
Run PID	193

Pause Integral & Derivative Calculation	194
Read Control Components	195
Error Integral.....	196
General Background: How PID Works	197
PID Status Messages	201
PID Tips	202
Drum Sequencer.....	206
Drum Sequencer Overview	207
Drum Sequencer: Configuration	209
Drum Sequencer: Jump to Step	210
Events	211
Events Overview	212
PWM.....	219
PWM FB Overview	220
Loadcell	222
Loadcell Overview	223
Advanced Loadcell Functions.....	237
Filter	248
Filter Overview.....	249
Accelerate.....	252
Accelerate Overview	253
Configuration	254
Increment/Decrement.....	255
Fast Response	256
Fast Response Overview.....	257
Fast Response: Configuration.....	264
Fast Response: Set Mode	265
Fast Response: Set Counter.....	267
Fast Response: Scan.....	268
BAS (Building Automation Systems)	269
BAS, CSI Overview	270
Configuration	271
Open Session.....	273
Scan	274
Read, Write Inputs: Digital or Analog I/Os.....	275
Draw Axis	277
Draw Axis Overview.....	278
Configuration	279
Draw	282
Clear.....	283

VisiLogic Function Blocks


When you install VisiLogic, the program also installs a Function Block (FB) library for advanced functions, such as SMS messaging and MODBUS communications. FBs that are currently installed in VisiLogic are listed under the FB's menu.




- Note •** | You must use a condition (RLO) to activate any FB that requires Configuration in your application, such as MODBUS or SMS.
- Note •** | To enable Live Update, you can select to use a proxy server in Project Properties.

Use Function Block Information, located on the View menu, to check:

- Which FBs are installed in your library.
- Which FB versions are installed, which versions are used in the open project, and to manage FB versions.
- FB memory usage.



Versions Used



Updating FB versions

Standard Vision: To install an updated FB library, select Update from the Web from the FBs menu or Help menu, then follow the on-screen instructions. Note that at the end of the download, you must close and then restart VisiLogic. The new FBs will appear on the FBs menu.

Enhanced Vision: FB libraries are updated as part of OS releases. When you update the OS, FBs are automatically updated as well.

FBs List

MODBUS, serial

MODBUS, IP

SMS Messaging

GPRS

Remote PLC DataCom

Communication Protocol

TCP/IP Communication Protocol

PID FB

Drum

Events

MB as PWM

Loadcell

Filter

Accelerate

Fast Response

Draw Axis

BAS

Trends

If your project is configured to Vision controllers that do not support HMI object Trend graphs, the Trend objects will not be displayed in the Project Navigation Window. These controllers include V120/230/260/280/290 (monochrome). In these models, the Trends (Legacy) Function Block may be used.

Examples

Sample applications may be found in the VisiLogic Examples folder, located on the VisiLogic Help menu. This folder contains field-tested VisiLogic (.vlp) sample applications.

MODBUS (Serial)

MODBUS (Serial) Overview

Converting Projects: Vision Divisions

The memory structure of Standard Vision controllers is different from that of Enhanced. Note that if you convert projects, you must make changes according to the information given in the Slave Address tables.

MODBUS enables you to establish master-slave communications between Unitronics PLCs and any connected device that supports the MODBUS protocol. Any controller in the network may function as either master or slave using any of the controller's existing COM Ports.

Within a MODBUS network, you can use standard MODBUS commands to read and write bit and register data; you can also read and write data to Vision controller Data Tables.


Unitronics currently supports RTU (binary) transmission mode.

Using MODBUS: Unitronics' PLCs, Master - Slave


Before using a MODBUS operation in your application, you must:

- Synchronize the communication port settings of master and slave devices. This is done by placing COM Port Init FBs, set with identical parameters, in the ladder application of both master and slave.
- Include at least 1 MODBUS Configuration FB in the ladder application of both master and slave. The port you select must be the same port selected in the COM Port Init FB.
- The condition that activates the Configuration must turn ON for a single program cycle (positive transition recommended). **However, the MODBUS Configuration must be scanned during every program cycle--after the Configuration is activated. One way to ensure this is by placing the Configuration in the first subroutine of the main module.**
- Enable slave devices to be accessed by placing a Scan_EX FB in the slave's Ladder application.

The figure below shows the elements required to carry out a Read Coils Operation.



Note that the operand addresses in slave PLCs are indirect addresses (pointers).




Using MODBUS: Accessing PLC data via SCADA/OPC server

The PC master can access data within the PLC via the addresses given in the Slave Addresses Table.

The PLC slave's Ladder application must include the following:

- A COM Port Init FB.
- A MODBUS Configuration FB. Within the Configuration, the port you select must be the same port selected in the COM Port Init FB.
Note • The condition that activates the Configuration must turn ON for a single program cycle (positive transition recommended). **However, the MODBUS configuration must be scanned during every program cycle--after the Configuration is activated. One way to ensure this is by placing the configuration in the first subroutine of the main module.**

- A Scan_EX FB



Note • The operand addresses in slave PLCs are indirect addresses (pointers).

Note that it is possible to broadcast to the MODBUS network by writing to Slave ID # 0. To do this indirectly address the Slave ID to a register, and write 0 to that register.

Slaves: Consecutive References

Whether the MODBUS master is a Unitronics PLC or another device, if the master application size and system requirements allow, it is recommended to add a delay between consecutive references to slaves according to the table below.

Delay (msec) between consecutive references to slaves;

Minimum Baud rate = 9600

	Minimum	Recommended
Jazz	20	40
M90/M91	15	30
V120, V2xx	10	20
V130	5	10
V350, V570	0	5


FB Operations

Operations are grouped under MODBUS on the FB's menu.

MODBUS: Configuration**MODBUS: Scan****MODBUS: Read Coils (1)****MODBUS: Read Inputs (2)****Read Holding Registers (3)****Read Float Registers (3)****Read Input Registers (4)****Read Float Input Registers (4)****Force Coil (5)****Preset Holding Register (6)****Loopback Test (8)****Force Coils (15)****Preset Holding Registers (16)****Preset Float Registers (16)****Read/Write Mixed Data****Read/Write to Data Tables**

MODBUS: Configuration

A MODBUS Configuration FB must be included in both master and slave Ladder applications as shown below.




Parameter	Type	Function
Port Number	Constant	Click the drop-down arrows to view available ports; click the port you want to use.
Network ID	Constant	This number identifies the device on the network. You can either assign an ID via an MI, or directly via a constant number. The unit ID range is from 0-255. Do not assign the same ID number to more than one device.
Time out	Constant or MI	This is the amount of time a master device will wait for an answer from a slave. Time out units are defined in 10 msec; a Time out value of 100 is equal to 1 second.
Retries	Constant or MI	This is the number of times a device will try to send a message.
Function in Progress	MB	This bit is ON when MODBUS is active. Use this as a condition bit for MODBUS operations to avoid communication conflicts.

- Note •** Indirectly addressed parameters in a MODBUS Configuration FB are only read when the Configuration is called. Since a Configuration is generally called as a power-up task, if, for example Retries has been indirectly addressed, and the linked MI is updated, the new value will **not** be read into the Configuration. The value will only be updated until the Configuration is called.
- While a master attempts to send a command, the Function In Progress bit is ON. The number of attempts that the master will make is the number in Retries +1, where '1' is the initial access attempt.
 - When a master attempts to access a slave device, and the slave does not answer, the Function In Progress bit will turn ON. This bit will

remain on according to the following:
 (the number of retries + 1) x (Time Out), where '1' is the initial access attempt. Note that the Time Out parameter is in units of 10 msec.

The Ladder application below enables the controller act as a MODBUS master and read coils in a slave PLC. The Scan_EX operation shown below enables the controller to also act as a slave.




Status Operands

When you place MODBUS operations in your application (Force, Read, Preset, and Loopback commands), you link operands that show the status of MODBUS sessions. Use these to troubleshoot problems.

MODBUS: ScanEX and Scan

Scan_EX enables a master device to access a slave PLC. A Scan_EX must be included in the slave application.



Note • | Scan_Ex is recommended for new applications.

About Scan and Scan_EX


MODBUS Versions **previous to V2.01** offered only the **Scan** FB. Scan is still supported for older, working applications. When MODBUS operations accessed double registers (5100 addresses and higher), using odd addresses, such as 5101, there were incompatibility issues.

When ScanEX receives an input parameter in the 32-bit range (for example, 5100{ML}), it automatically takes double-register values.

If, for example, ScanEX receives a Read Register (6) request for **5100**, it returns the values in 5100 **and** 5101. If, however, ScanEX receives Read Register (6) request for **5101**, it returns Status Message #2-- since 5101 provides the 'high' bytes of the 32-bit register, it is not a legal address.

Read Coils (1)


Use this command to read the status of a selected group of coils and write them into a vector. The coil's status is written into a vector of MBs in the master PLC.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the slave device containing the coils to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of coils to be read (data source). Note • Check topic Slave Address Tables
Read: Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 1900 bit operands at one time. In addition, 0 is not a legal length.
Master: Start of Vector	MB	This is the start of a vector of MBs that will contain the coils' status in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Inputs (2)


Use this command to read the status of a selected group of inputs in a slave device and write them into a vector. The inputs' status is written into a vector of MBs in the master PLC.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the slave device containing the inputs to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of inputs to be read (data source). Note • Check topic Slave Address Tables
Read: Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 1900 bit operands at one time. In addition, 0 is not a legal length.
Master: Start of Vector	MB	This is the start of a vector of MBs that will contain the inputs' status in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Holding Registers (3)


Use this command to read the values of a selected group of registers in a slave PLC and write them into a defined vector of registers in the master.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device containing the registers to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be read (data source). Note • Check topic Slave Address Tables
Read: Vector Length	Const, MI, ML, DW	The vector length Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number.
Master: Start of Vector	MI	This is the start of a vector of MIs that will contain the registers' values in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Float Registers (3)


Use this command to read the values of a selected group of floating point registers in a slave device and write them into a defined vector of registers in the master. Values after the decimal point are rounded to the nearest whole value.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device containing the registers to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be read (data source). Note • Check topic Slave Address Tables
Read: Vector Length	Const, MI, ML, DW	The vector length Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. <ul style="list-style-type: none"> • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: <ul style="list-style-type: none"> - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number. <ul style="list-style-type: none"> • You can transpose 16 bits of a 32-bit double register value by turning SB 102 MODBUS Read Long ON in your program. SB 102 is OFF by default, and must be reset by the user program.
Master: Start of Vector	MI	This is the start of a vector of MIs that will contain the registers' values in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Input Registers (4)


Use this command to read the values of a selected group of registers in a slave PLC and write them into a defined vector of registers in the master.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device containing the registers to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be read (data source). Note • Check topic Slave Address Tables
Read: Vector Length	Const, MI, ML, DW	The vector length Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number.
Master: Start of Vector	MI	This is the start of a vector of MIs that will contain the registers' values in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Float Registers (4)


Use this command to read the values of a selected group of floating point registers in a slave device and write them into a defined vector of registers in the master. Values after the decimal point are rounded to the nearest whole value.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device containing the registers to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be read (data source). Note • Check topic Slave Address Tables
Read: Vector Length	Const, MI, ML, DW	The vector length Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number. • You can transpose 16 bits of a 32-bit double register value by turning SB 102 MODBUS Read Long ON in your program. SB 102 is OFF by default, and must be reset by the user program.
Master: Start of Vector	MI	This is the start of a vector of MIs that will contain the registers' values in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Force Coil (5)


Use this command to force the status of a selected coil in a slave PLC. The coil's status is forced according to the status of a selected MB in the master PLC.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device containing the coil to be forced (data source).
Slave Address	Const, MI, ML, DW	The address of the coil to be forced (data target). Note • Check topic Slave Address Tables
Value to Force	M, SB, I, O,T	This MB is located in the master PLC; this MB contains the status to be forced (data source). If, for example, the status of this MB is OFF, the status of the coil in the slave will be forced to OFF. Note • A MODBUS command cannot read/write more than 1900 bit operands at one time. In addition, 0 is not a legal length.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Preset Holding Register (6)


Use this command to preset the value of a single register in a slave PLC. The value is set in a register contained in the master PLC.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device containing the register to be preset (target).
Slave: Operand Address	Const, MI, ML, DW	The address of the register to be preset (target). Note • Check topic Slave Address Tables
Value to Preset	Constant, MI, SI, ML, SL, DW, SDW or T	This is the address of the register containing the value in the master PLC (source). This value will be written into the slave's register, the register that is to be preset.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Loopback Test (8)


Use this command to send a test message to a slave device and receive Acknowledgements when communications are functioning properly.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device to be checked.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Force Coils (15)


Use this command to force the status of a selected group of coils in a slave PLC. The coils' status is forced according to the status of a group of MBs in the master PLC.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the slave device containing the coils to be forced (target).
Slave:Start of Vector	Const, MI, ML, DW	The start of the vector of coils to be forced (data target). Note • Check topic Slave Address Tables
Master: Start of Vector	MI, SB, I, O, T	This is the start of a vector of MBs that will contain the coils' status in the master (data source).
Force: Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 1900 bit operands at one time. In addition, 0 is not a legal length.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Preset Holding Registers (16)


Use this command to preset the value of a group of registers in a slave PLC. The values are set in a vector of registers contained in the master PLC.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device containing the registers to be preset (target).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be preset (target). Note • Check topic Slave Address Tables
Master: Start of Vector	Constant, MI, SI, ML, SL, DW, SDW or T	This is the start of a vector of MIs that will contain the registers' values in the master (data source).
Preset: Vector Length	Const, MI, ML, DW	The length of the vector of registers in both master and slave. Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Preset Float Registers (16)

Use this command to preset the value of a group of floating point registers in a slave PLC. The values are set in a vector of registers contained in the master PLC. Values after the decimal point are rounded to the nearest whole value.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the device containing the register to be preset (target).
Slave: Start of Vector	Const, MI, ML, DW	The address of the register to be preset (target). Note • Check topic Slave Address Tables
Master: Start of Vector	MI, SI, ML, SL, DW, SDW or T	This is the address of the register containing the value in the master PLC (source). This value will be written into the slave's register, the register that is to be preset.
Preset: Vector Length	Const, MI, ML, DW	The length of the vector of registers in both master and slave. Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read/Write from Data Tables

Use these commands to access the bytes in Vision data tables **without** reference to table structure.




Please note that this is not a standard MODBUS function. Read/Write from Data Tables is compatible with Unitronics' Vision PLC data tables only .

To determine the byte number of a data table cell, hold the cursor over the data table cell. A Tooltip opens, displaying the byte number.


Note • A MODBUS command cannot read/write more than 242 DT bytes at one time.

In addition, 0 is not a legal length.



Read from Data Table


Below, a MODBUS master reads data tables in Slave ID 1. Bytes 24-43 are read from Slave 1 into bytes 140-159 in the master's data tables.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the slave device containing the coils to be read (data source).
Slave: DT Start of Vector	Const, MI, ML, DW	The start of the vector of bytes to be read (data source).
Slave: DT Offset in Vector	Const, MI, ML, DW	Offset from the Slave: DT Start of Vector
Master: DT Start of Vector	Const, MI, ML, DW	This is the start of a vector of bytes that will contain the data read from the slave.
Master: DT Offset in Vector	Const, MI, ML, DW	Offset from the Master: DT Start of Vector
Read: DT Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 242 DT bytes at one time. In addition, 0 is not a legal length.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Write to Data Table

Below, a MODBUS master writes to data tables in Slave ID 1. Bytes 140-159 are written from the master into bytes 24-43 in the slave's data tables.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the slave device to which the data will be written (data target).
Slave: DT Start of Vector	Const, MI, ML, DW	The start of the vector of bytes to be written into (data target).
Slave: DT Offset in Vector	Const, MI, ML, DW	Offset from the Slave: DT Start of Vector
Master: DT Start of Vector	Const, MI, ML, DW	This is the start of a vector of bytes, in the master, that will contain the data to be written to the slave (data source)
Master: DT Offset in Vector	Const, MI, ML, DW	Offset from the Master: DT Start of Vector
Read: DT Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 242 DT bytes at one time. In addition, 0 is not a legal length.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read/Write Mixed Data via MODBUS

The Read/Write Mixed Data function enables you to combine Read & Write operations in a single MODBUS command, transferring data between master and slave controllers, without using standard MODBUS commands and addressing conventions.



This is **not** a standard MODBUS function. Read/Write Mixed Data is compatible with Unitronics' Vision controllers **only**.

Note that this function is compatible with O/S 401 and higher, and is not supported for V120-12-xxx.

Each function can contain both Read and Write Mix Requests. Each request may be for a different data type. Your data request must include:

- Master and Slave operand addresses
- Length of vector
- Direction: Read or Write

After you add a request, the OK button is disabled. Click the Compile button to see current buffer status; if the buffer contains less than the maximum number of bytes, the OK is enabled.

The screenshot shows the 'MODBUS Read/Write Mixed Data' dialog box. It includes a 'Select Name' dropdown set to 'MODBUS_1', a 'Params' table, a 'Mix Requests' table, and buffer usage indicators. Annotations provide instructions on field selection and the 'Compile' button's function.

Params	Type	Add	Format	Description
IN	D#	0	DEC	Slave ID 0
OUT	MI	3	DEC	Status Messages
	DW	6	DEC	Total Sessions
	DW	7	DEC	Acknowledgements

#	Master	Slave	Length	Direction
1	MI 50 - Master: Start Of Vector	MI 10	1	Read
2	DW 50	DW 60	1	Read
3	MB 111	MB 1111	3	Read
5				

Send Buffer Usage: 11 %
 Receive Buffer Usage: 6 %

Buttons: Compile, Clear Line, Ok, Cancel, Help

Annotations:







- Click in a field to select the:
 - Start of the master's data vector
 - Start of the slave's data vector
 - Vector length
 - Direction, Read from Slave or Write to Slave
- Clicking Compile updates the Buffer Usage report. If the Request fits in the buffer, the OK button is enabled.

Read Write Limitations

Only the following data types may be used in Mixed Data requests: MI, ML, DW, MB, I and O.

Registers: may only be read/written to the same data type.

Booleans: Inputs cannot be written to.

Booleans, Read Write			Registers, Read Write		
I		MB, O			
O		MB, O			MI
MB		MB, O			ML
					DW


Send / Receive Buffers

The function uses two buffers, Send and Receive. Each buffer can contain a maximum of 500 bytes.

Configuring a MODBUS slave device

The Ladder section below shows what elements are necessary to enable a master device to read from a slave. Note that the MODBUS Scan_EX operation should **not** be performed during the initial program scan.

Note that you must use a condition (RLO) to activate the MODBUS Configuration and SCAN_EX.




Slave Addressing

Monochrome / Color PLCs

The memory structure of monochrome screen PLCs is different from that of color screen PLCs. This is why each series has its own slave addressing scheme.

- Note •** The slave addresses given for the **monochrome** series are **decimal** values.
- The slave addresses given for the **color** series are **hexadecimal** values.



Slave Addresses

Standard Vision Division

Coils		MODBUS Command Number	
Pointer Value From:	Operand type	Read	Write
0000	MB 0-2999	#01 Read Coils	#15 Force Coils
3000	SB		#15 Force Coils
4000	I (read-only)		Read-only
5000	O		#15 Force Coils
6000	T (read-only)		Read-only
7000	C (read-only)		Read-only
8000	MB 3000-4095		

- Note •** Note that in order to access MBs 3000-4095, you address as follows:

to access MB 3012, request slave address 8012.

Registers			MODBUS Command Number	
Pointer Value From:	Operand type	Register size	Read	Write
0000	MI	16 bit	# 03 Read Holding Registers	# 16 Preset Holding Registers
4000	SI	16 bit		
5100	ML	32 bit		
6100	SL	32 bit		
6300	MDW	32 bit		
6700	SDW	32 bit		
6900	Timer preset	32 bit		
7300	Timer current	32 bit		
7700	MF	32 bit		
7800	Counter Preset	16 bit		
7900	Counter Current	16 bit		

Enhanced Vision Series

Coils		MODBUS Command Number	
Pointer Value From (hex):	Operand type	Read	Write
0000h	MB 0	#01 Read Coils	#15 Force Coils
3000h	XB		#15 Force Coils
4000h	O		#15 Force Coils
5000h	SB		Read-only
6000h	I (read-only)		#15 Force Coils
7000h	T (read-only)		Read-only
8000h	C (read-only)		Read-only

Registers			MODBUS Command Number			
Pointer Value From (hex):	Operand type	Register size	Read	Write		
0000h	MI	16 bit	# 03 Read Holding Registers	# 16 Preset Holding Registers		
3000h	XI					
9000h	SI	16 bit				
5000h	XL					
6000h	XDW					
7000h	ML	32 bit				
A000h	SL	32 bit				
8000h	MDW	32 bit				
B000h	SDW	32 bit				
C000h	Timer preset	32 bit				
D000h	Timer current	32 bit				
4000h	MF	32 bit				
E000h	Counter Preset	16 bit				
F000h	Counter Current	16 bit				

Examples

The examples below show that:

- MODBUS addressing systems start at 1.
- Vision addressing starts at 0.

Bit Operands

Read a 10-bit vector of inputs in a slave Vision controller, starting at Input 20, via Read Coils (MODBUS COMMAND #1)

- Vision PLC as the MODBUS master to Monochrome PLC
 In VisiLogic's Read Coils FB, set the Slave: Start of Vector parameter to 4020 (DEC), and the Read: Vector Length parameter to 10. Within the slave Vision controller, VisiLogic will read I 20 - I 29.
- Vision PLC as the MODBUS master to Color PLC
 In VisiLogic's Read Coils FB, set the Slave: Start of Vector parameter to 6014h (HEX), and the Read: Vector Length

parameter to 10. Within the slave Vision controller, VisiLogic will read I 20 - I 29.

- **SCADA as the MODBUS master to Monochrome PLC**
 In the SCADA application, set the Slave: Start of Vector parameter to 34021(30001 + 4000 + 20), and the Read: Vector Length to 10, enabling the Master device to read I 20 - I 29 within the slave Vision controller.
- **SCADA as the MODBUS master to Color PLC**
 Convert the HEX address to DEC
 In the SCADA application, set the Slave: Start of Vector parameter to 54597(24576 (6000h) + 20), and the Read: Vector Length to 10, enabling the Master device to read I 20 - I 29 within the slave Vision controller.

Write a 3-bit vector of outputs in a slave Vision controller, starting at Output 8, via Force Coils (MODBUS COMMAND #15)

- **Vision PLC as the MODBUS master to Monochrome PLC**
 In VisiLogic's Force Coils FB, set the Slave: Start of Vector parameter to 5008, and the Force: Vector Length parameter to 3. Within the slave Vision controller, the master will force the status of O 8 - O 10.
- **Vision PLC as the MODBUS master to Color PLC**
 In VisiLogic's Force Coils FB, set the Slave: Start of Vector parameter to 4008h (HEX), and the Force: Vector Length parameter to 3. Within the slave Vision controller, the master will force the status of O 8 - O 10.
- **SCADA as the MODBUS master to Monochrome PLC**
 In the SCADA application, set the Slave: Start of Vector parameter to 35009 (30001 + 5000 + 8) and the Force: Vector Length parameter to 3, enabling the Master device to write to O 8 - O 10 within the slave Vision controller.
- **SCADA as the MODBUS master to Color PLC**
 Convert the HEX address to DEC.
 In the SCADA application, set the Slave: Start of Vector parameter to 46393 (30001 + 16384(4000h) + 8) and the Force: Vector Length parameter to 3, enabling the Master device to write to O 8 - O 10 within the slave Vision controller.

Registers

Read a 9-register long vector of **16-bit integers** in a slave Vision controller, starting at MI 32, via Read Holding Registers (MODBUS COMMAND #03)

- Vision PLC as the MODBUS master
In VisiLogic's Read Holding Registers FB, set the Slave: Start of Vector parameter to 32, and the Read: Vector Length parameter to 9. Within the slave Vision controller, VisiLogic will read MI 32 - MI 41.
- SCADA as the MODBUS master
In the SCADA application, set the Slave: Start of Vector parameter to 40033 (40001 + 0000 + 3), and the Read: Vector Length parameter to 9, enabling the Master device to read MI 32 - MI 41 within the slave Vision controller.

Note •

If, within the Slave: Start of Vector parameter, the selected register type is a **32-bit double register** (slave addresses 5100 and greater) the preset vector length must be **doubled** as well.

If, for example in the VisiLogic Preset Holding Registers FB:

- Slave: Start of Vector parameter is set to 6300, and
- You wish to preset 4 registers, for a total of 16 bytes
- You must set the Preset Vector length to 8.

Note that this means that, in these cases, the **Preset: Vector Length** parameter will always be an even number.


Read a 9-register long vector of **32-bit integers** in a slave Vision controller, starting at SL 32, via Preset Holding Registers (MODBUS COMMAND #16)

- Vision PLC as the MODBUS master
In VisiLogic's Preset Holding Registers FB, set the Slave: Preset Vector parameter to 6132, and the Read: Vector Length parameter to 18 (2x9, in order to fit the 32-bit SL registers). Within the slave Vision controller, VisiLogic will read SL 32 - SL 41.
- SCADA as the MODBUS master
In the SCADA application, set the Slave: Start of Vector parameter to 406133, and the Read: Vector Length parameter to 18, enabling the Master device to read SL 32 - SL 41 within the slave Vision controller.

Write a 6-register long vector of **16-bit integers** in a slave Vision controller, starting at MI 32, via Preset Holding Registers (MODBUS COMMAND #16)

- Vision PLC as the MODBUS master
In VisiLogic's Preset Holding Registers FB, set the Slave: Start of Vector parameter to 32, and the Preset: Vector Length parameter to 6. Within the slave Vision controller, VisiLogic will write to MI 32 - MI 37.
- SCADA as the MODBUS master
In the SCADA application, set the Slave: Start of Vector parameter to 40033, and the Read: Vector Length parameter to 6, enabling the Master device to write to MI 32 - MI 37 within the slave Vision controller.

MODBUS via GSM or Standard Modem



To run MODBUS via landline or GSM modem, use the appropriate SB in your MODBUS Scan conditions to detect when the modem has finished initializing.

Note •

When MODBUS (Serial) is configured to a port linked to a modem, the MODBUS function checks SI 100 Maximum Time Delay between characters (units 2.5ms) MODBUS + Modem. If SI 100 = 1, a time interval of up to 2.5 msecs is permitted between characters, if SI 100 contains 2, the permitted interval is 5 msecs (n x 2.5 = interval. Note that the application must update SI 100 before the MODBUS configuration is activated.

MODBUS Status Operands

All of the Status operands linked to MODBUS FBs should be assigned Power-up Values; bits should be reset, and registers initialized to 0.

MODBUS: Configuration FB Status Operand

All MODBUS operations run through a MODBUS configuration placed in the master device's program.

<p>Function in Progress Shows status of master's MODBUS Configuration</p>	<p>MB</p>	<p>Turns ON when:</p> <ul style="list-style-type: none"> • A master Vision initiates MODBUS communication. • Remains ON during the MODBUS session. 	<p>Turns OFF when</p> <ul style="list-style-type: none"> • The MODBUS: Configuration is activated. • An answer is received from a slave. • The TimeOut defined in the Configuration is exceeded. • Certain Status Messages are given
---	------------------	---	---

MODBUS Operation Status Operands

When you place MODBUS operations in your application (Force, Read, Preset, and Loopback commands), you link the operands below. These show the status of MODBUS sessions.

<p>Status Messages Shows status of master's data requests and the replies the master receives from the slaves</p>	<p>MI</p>	<ul style="list-style-type: none"> • Automatically initialized to 0 when MODBUS operation is activated. • Updated at the end of each attempt to communicate via MODBUS. • Indicates status of MODBUS communications, according to the table below. Note that the current value always shows the most recent status.
--	------------------	--

#	<u>Status Message</u>
0	Status OK
1	<p>Unknown Command Number This is received from the slave device.</p>
2	<p>Illegal Data Address</p> <ul style="list-style-type: none"> • Master: an invalid address is found by the master before a data request is sent to a slave. This may result, for example, when an MI is used to provide vector length. • Slave: The slave notifies the master that the data request command includes invalid addresses. • Slave--ScanEX: When ScanEX receives an input parameter in the 32-bit range (for example, 5100{ML}), it automatically takes double-register values. If, for example, ScanEX receives a Read Register(6) request for 5100, it returns the values in 5100 and 5101. If, however, ScanEX receives Read Register(6) request for 5101, it returns Error #2-- since 5101 provides the 'high' bytes of the 32-bit register, it is not a legal address.
3	<p>Slave to Master: Illegal Data Type Quantity Number of operands requested by user exceeds the maximum</p> <p>Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, 62 float registers, or 1900 bit operands at one time. In addition, 0 is not a legal vector length.</p>

4	<p>Master--Time Out This occurs if the master has been waiting for a slave response for an amount of time exceeding the Time-out set in the Configuration. If this error occurs, check Time Out, Baud Rate, and Distance</p>
5	<p>No Communication The MODBUS session cannot be established.</p>

Note • Messages 4 & 5. **TimeOut** and **Number of Retries** are defined in the **Configuration**. A Retry is an attempt to establish a MODBUS session.
 If, for example, TimeOut is defined as 2 seconds, and number of Retries as 3:
 - the controller will try to establish the session once, and will continue to try for 2 seconds.
 - If the first attempt fails, the **Status Message value will be 4**, Master TimeOut.
 -The controller will try twice more, for a total of 3 retries over 6 seconds.
 - If all attempts fail, the **Status Message value will be 5**.
 -If any attempt succeeds, the Status Message will be 0.

* 6	Master-slave data incorrectly synchronized
* 7	Master-slave data incorrectly synchronized
8	<p>Master to application: Illegal Data Type Quantity Number of operands requested by user exceeds the maximum permitted for that FB operation in the master. Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, 62 float registers, or 1900 bit operands at one time. In addition, 0 is not a legal vector length.</p>
9	<p>Slave ID =0 An attempt does to communicate with Slave ID 0.</p>
10	Incorrect CRC
* 11	Master-slave data incorrectly synchronized

* Messages 6, 7, and 11 mean that the master has found incompatible elements in the data sent between master and slave.

Total Sessions	DW	This is the total number of times the master PLC attempts to access the slave device, whether the attempt is successful or not, including Retries. Note that this is a simple incremental counter. <ul style="list-style-type: none"> • This must be initialized by the user, by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers. <ul style="list-style-type: none"> • This must be initialized by the user, by storing 0 into the selected DW.

Time Out, Baud Rate, and Distance

The default Time Out set in the Configuration is one second. In certain cases, the length of the network may cause this to be exceeded. You can calculate a Time Out value by using the following formula, and use it in the Configuration.

$$\text{Time Out} = \frac{(\text{TX bytes} + \text{RX bytes} + 7) \times 1000}{\text{baud rate} / (\text{data bits} + \text{start bits} + \text{stop bits}) * 10\text{ms}}$$

SI	Description	Value
100	Maximum Time Delay between characters (units 2.5ms) MODBUS + Modem	When MODBUS (Serial) is configured to a port linked to a modem, the MODBUS function checks SI 100. If SI 100 = 1, a time interval of up to 2.5 msec is permitted between characters, if SI 100 contains 2, the permitted interval is 5 msec (n x 2.5 =interval. Note that: - The power-up value is 1, - the application must update SI 100 before the MODBUS configuration is activated.

MODBUS (IP)

MODBUS IP Overview

Converting Projects: Vision Divisions

The memory structure of Standard Vision controllers is different from that of Enhanced. Note that if you convert projects, you must make changes according to the information given in the Slave Address tables.

If your controller comprises an Ethernet card, you can use MODBUS IP commands with any connected device that supports the MODBUS protocol.

Within a MODBUS network, you can use standard MODBUS commands to read and write bit and register data; you can also read and write data to Vision controller Data Tables.

Any controller in the network may function as either master or slave.

Unitronics currently supports both TCP and UDP, as explained in the topic About Ethernet. This topic also contains general information about Ethernet, IP addressing, sockets, and ports.


Specific information on implementing Ethernet is provided in the topic Using Ethernet.

Using MODBUS


Before using a MODBUS IP operation in your application, you must:

- Assign IP addresses to both master and slave devices. This is done by placing Ethernet Card Init FBs in the ladder application of both master and slave.
- Include at least 1 MODBUS Configuration FB in the ladder application of both master and slave.
- The condition that activates the Configuration must turn ON for a single program cycle (positive transition recommended)
However, the MODBUS configuration must be scanned during every program cycle--after the Configuration is activated. One way to ensure this is by placing the configuration in the first subroutine of the main module.
- Enable slave devices to be accessed by placing a Scan FB in the slave's Ladder application.

The figure below shows the elements required to carry out a Read Coils Operation.



Note that the operand addresses in slave PLCs are indirect addresses (pointers).



Note that a MODBUS master can broadcast to the MODBUS network by writing to Slave ID # 0. To do this, indirectly address the Slave ID to a register, and write 0 to that register.

FB Operations

MODBUS IP Operations are located on the FBs menu.

MODBUS: Configuration

MODBUS: Scan

MODBUS: Read Coils (1)

MODBUS: Read Inputs (2)

Read Holding Registers (3)

Read Float Registers (3)

Read Input Registers (4)

Read Float Input Registers (4)

Force Coil (5)

Preset Holding Register (6)

Force Coils (15)

Preset Holding Registers (16)

Preset Float Registers (16)


Read/Write Mixed Data (non-standard MODBUS command)

Read/Write to Data Tables

MODBUS Status Operands

MODBUS: Configuration

A MODBUS Configuration FB must be included in both master and slave Ladder applications as shown below. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Port Number	Constant	Click the drop-down arrows to view available ports; click the port you want to use.
Network ID	Constant	This number identifies the device on the network. You can either assign an ID via an MI, or directly via a constant number. The unit ID range is from 0-255. Do not assign the same ID number to more than one device.
Time out	Constant or MI	This is the amount of time a master device will wait for an answer from a slave. Time out units are defined in 10 msec; a Time out value of 100 is equal to 1 second.
Retries	Constant or MI	This is the number of times a device will try to send a message.
Function in Progress	MB	This bit is ON when MODBUS is active. Use this as a condition bit for MODBUS operations to avoid communication conflicts.

Note • Indirectly addressed parameters in a MODBUS Configuration FB are only read when the Configuration is called. Since a Configuration is generally called as a power-up task, if, for example Retries has been indirectly addressed, and the linked MI is updated, the new value will **not** be read into the Configuration. The value will only be updated

	until the Configuration is called.
•	While a master attempts to send a command, the Function In Progress bit is ON. The number of attempts that the master will make is the number in Retries + 1, where '1' is the initial access attempt.
•	When a master attempts to access a slave device, and the slave does not answer,- the Function In Progress bit will turn ON. This bit will remain on according to the following: (the number of retries + 1) x (Time Out), where '1' is the initial access attempt. Note that the Time Out parameter is in units of 10 msec.

Vision Slaves

In order to access Vision Controllers as slave devices and implement MODBUS commands, you must enter the IP addresses of the slave devices in the MODBUS IP configuration. This means that you must first assign IP addresses to each slave. This is done via the Ethernet Card Init FB, which must be configured as described in the topic Using_Ethernet.

1. Here, slaves have been defined in the MODBUS IP configuration.

2. The list of slaves is now available for all MODBUS IP commands; link the command to the desired slave.

The screenshot displays three overlapping windows from the VisiLogic software:

- MODBUS IP Configuration:** Shows a table of parameters and a list of slaves.

Params	Type	Add	Format	Description
IN	D#	0	DEC	Socket 0
	D#	1	DEC	Network ID 1
	MI	0	DEC	
	D#	3	DEC	Retries
OUT	MB	0		Function in Progress

Index	Description	IP Address	Port	Slave ID
0	slave1	192.168.192.112	20000	255
1	slave 2	192.168.192.112	20000	255
2	slave 3	192.168.192.113	20000	255
- MODBUS IP Read Coils (1):** Shows a configuration for a read coil command.


Params	Type	Add	Format	Description
IN	MI	10		
	D#	10		
OUT	MB	100		
	MI	5		
	DW	2		
	DW	3		
- Slave:** A dialog box for selecting a slave.

0 - slave1; IP=192.168.192.111; PO=20000; ID=255;
1 - slave1; IP=192.168.192.111; PO=20000; ID=255;
1 - slave 2; IP=192.168.192.112; PO=20000; ID=255;
2 - slave 3; IP=192.168.192.113; PO=20000; ID=255;
3 - ;

Note • Slave IP addresses can also be linked to an MI vector, note that the vector is 4 MIs long. The low byte of each MI provides the number for an octet within the IP address. If, for example, the IP address is linked to MI 0, and the low bytes of MI 0 to MI 3 contain the values 192, 198, 192, 45, the IP address

will be 192.198.192. 45.

The Ladder application below enables the controller act as a MODBUS master and read coils in a slave PLC. The same PLC can also act as a slave, if a Scan_EX operation is included in the application.




Status Operands

When you place MODBUS operations in your application (Force, Read, Preset, and Loopback commands), you link operands that show the status of MODBUS sessions. Use these to troubleshoot problems.

MODBUS: ScanEX and Scan

Scan_EX enables a master device to access a slave PLC. A Scan_EX must be included in the slave application. MODBUS IP Operations are located on the FBs menu.



Note • | Scan_Ex is recommended for new applications.

About Scan and Scan_EX

MODBUS Versions **previous to V2.01** offered only the **Scan** FB. Scan is still supported for older, working applications. When MODBUS operations accessed double registers (5100 addresses and higher), using odd addresses, such as 5101, there were incompatibility issues.


Scan_EX is recommended for new applications.

When ScanEX receives an input parameter in the 32-bit range (for example, 5100{ML}), it automatically takes double-register values.

If, for example, ScanEX receives a Read Register(6) request for **5100**, it returns the values in 5100 **and** 5101. If, however, ScanEX receives Read Register(6) request for **5101**, it returns Status Message #2-- since 5101 provides the 'high' bytes of the 32-bit register, it is not a legal address.

Read Coils (1)


Use this command to read the status of a selected group of coils and write them into a vector. The coil's status is written into a vector of MBs in the master PLC. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the slave device containing the coils to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of coils to be read (data source). Note • Check topic Slave Address Tables.
Read: Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 1900 bit operands at one time. In addition, 0 is not a legal length.
Master: Start of Vector	MB	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Inputs (2)


Use this command to read the status of a selected group of inputs in a slave device and write them into a vector. The inputs's status is written into a vector of MBs in the master PLC. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the slave device containing the inputs to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of inputs to be read (data source). Note • Check topic Slave Address Tables.
Read: Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 1900 bit operands at one time. In addition, 0 is not a legal length.
Master: Start of Vector	MB	This is the start of a vector of MBs that will contain the inputs' status in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Holding Registers (3)


Use this command to read the values of a selected group of registers in a slave PLC and write them into a defined vector of registers in the master. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device containing the registers to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be read (data source). Note • Check topic Slave Address Tables.
Read: Vector Length	Const, MI, ML, DW	The vector length Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number.
Master: Start of Vector	MI	This is the start of a vector of MIs that will contain the registers' values in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Flat Registers (3)


Use this command to read the values of a selected group of floating point registers in a slave device and write them into a defined vector of registers in the master. Values after the decimal point are rounded to the nearest whole value. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device containing the registers to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be read (data source). Note • Check topic Slave Address Tables.
Read: Vector Length	Const, MI, ML, DW	The vector length Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. <ul style="list-style-type: none"> • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: <ul style="list-style-type: none"> - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number. <ul style="list-style-type: none"> • You can transpose 16 bits of a 32-bit double register value by turning SB 102 MODBUS Read Long ON in your program. SB 102 is OFF by default, and must be reset by the user program.
Master: Start of Vector	MI	This is the start of a vector of MIs that will contain the registers' values in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Input Registers (4)


Use this command to read the values of a selected group of registers in a slave PLC and write them into a defined vector of registers in the master. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device containing the registers to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be read (data source). Note • Check topic Slave Address Tables.
Read: Vector Length	Const, MI, ML, DW	The vector length Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number.
Master: Start of Vector	MI	This is the start of a vector of MIs that will contain the registers' values in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read Float Registers (4)

Use this command to read the values of a selected group of floating point registers in a slave device and write them into a defined vector of registers in the master. Values after the decimal point are rounded to the nearest whole value. MODBUS IP Operations are located on the FBs menu.




Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device containing the registers to be read (data source).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be read (data source). Note • Check topic Slave Address Tables.
Read: Vector Length	Const, MI, ML, DW	The vector length Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number. • You can transpose 16 bits of a 32-bit double register value by turning SB 102 MODBUS Read Long ON in your program. SB 102 is OFF by default, and must be reset by the user program.
Master: Start of Vector	MI	This is the start of a vector of MIs that will contain the registers' values in the master (data destination).
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Force Coil (5)

Use this command to force the status of a selected coil in a slave PLC. The coil's status is forced according to the status of a selected MB in the master PLC.


MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device containing the coil to be forced (data source).
Slave Address	Const, MI, ML, DW	The address of the coil to be forced (data target). Note • Check topic Slave Address Tables.
Value to Force	M, SB, I, O, T	This MB is located in the master PLC; this MB contains the status to be forced (data source). If, for example, the status of this MB is OFF, the status of the coil in the slave will be forced to OFF. Note • A MODBUS command cannot read/write more than 1900 bit operands at one time. In addition, 0 is not a legal length.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Preset Holding Register (6)


Use this command to preset the value of a single register in a slave PLC. The value is set in a register contained in the master PLC. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device containing the register to be preset (target).
Slave: Operand Address	Const, MI, ML, DW	The address of the register to be preset (target). Note • Check topic Slave Address Tables
Value to Preset	Constant, MI, SI, ML, SL, DW, SDW or T	This is the address of the register containing the value in the master PLC (source). This value will be written into the slave's register, the register that is to be preset.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Loopback Test (8)


Use this command to send a test message to a slave device and receive Acknowledgements when communications are functioning properly. MODBUS IP Operations are located on the FBS menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device to be checked.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Force Coils (15)


Use this command to force the status of a selected group of coils in a slave PLC. The coils' status is forced according to the status of a group of MBs in the master PLC. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the slave device containing the coils to be forced (target).
Slave:Start of Vector	Const, MI, ML, DW	The start of the vector of coils to be forced (data target). Note • Check topic Slave Address Tables.
Master: Start of Vector	MI, SB, I, O,T	This is the start of a vector of MBs that will contain the coils' status in the master (data source).
Force: Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 1900 bit operands at one time. In addition, 0 is not a legal length.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Preset Holding Registers (16)


Use this command to preset the value of a group of registers in a slave PLC. The values are set in a vector of registers contained in the master PLC. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device containing the registers to be preset (target).
Slave: Start of Vector	Const, MI, ML, DW	The start of the vector of registers to be preset (target). Note • Check topic Slave Address Tables.
Master: Start of Vector	Constant, MI, SI, ML, SL, DW, SDW or T	This is the start of a vector of MIs that will contain the registers' values in the master (data source).
Preset: Vector Length	Const, MI, ML, DW	The length of the vector of registers in both master and slave. Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Preset Float Registers (16)

Use this command to preset the value of a group of floating point registers in a slave PLC. The values are set in a vector of registers contained in the master PLC. Values after the decimal point are rounded to the nearest whole value. MODBUS IP Operations are located on the FBs menu.



Parameter	Type	Function
Slave ID	Constant or MI	The IP address of the device containing the register to be preset (target).
Slave: Start of Vector	Const, MI, ML, DW	The address of the register to be preset (target). Note • Check topic Slave Address Tables.
Master: Start of Vector	MI, SI, ML, SL, DW, SDW or T	This is the address of the register containing the value in the master PLC (source). This value will be written into the slave's register, the register that is to be preset.
Preset: Vector Length	Const, MI, ML, DW	The length of the vector of registers in both master and slave. Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, or 64 float registers at one time. In addition, 0 is not a legal length. • If, within the Slave: Start of Vector parameter, the selected register type is a 32-bit double register (slave addresses 5100 and greater) the preset vector length must be doubled as well. If, for example: - Slave: Start of Vector parameter is set to 6300, and - You wish to preset 4 registers, for a total of 16 bytes - You must set the Preset Vector length to 8. Note that this means that, in these cases, the Preset: Vector Length parameter will always be an even number.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Operands.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Read/Write Mixed Data via MODBUS

The Read/Write Mixed Data function enables you to combine Read & Write operations in a single MODBUS command, transferring data between master and slave controllers, without using standard MODBUS commands and addressing conventions.



Please note that this is not a standard MODBUS function. Read/Write Mixed Data is compatible with Unitronics' Vision controllers only.

Note that this function is compatible with O/S 401 and higher, and is not supported for V120-12-xxx.

Each function can contain both Read and Write Mix Requests. Each request may be for a different data type. Your data request must include:

- Master and Slave operand addresses
- Length of vector
- Direction: Read or Write

After you add a request, the OK button is disabled. Click the Compile button to see current buffer status; if the buffer contains less than the maximum number of bytes, the OK is enabled.

Click in a field to select the:

- Start of the master's data vector
- Start of the slave's data vector
- Vector length
- Direction, Read from Slave or Write to Slave

Clicking Compile updates the Buffer Usage report. If the Request fits in the buffer, the OK button is enabled.

Params	Type	Add	Format	Description
IN	D#	0	DEC	0 - Slave 0; IP=198.168.2.105; Port=2105
	MI	2	DEC	Status Messages
OUT	DW	4	DEC	Total Sessions
	DW	5	DEC	Acknowledgements

#	Master	Slave	Length	Direction
1	MI 50 - Master: Start Of Vector	MI 10	1	Read
2	Dw 50	Dw 60	1	Read
3	MB 111	MB 1111	3	Read
5				

Send Buffer Usage: 11 %
 Receive Buffer Usage: 6 %







Buttons: Compile, Clear Line, Ok, Cancel, Help

Read Write Limitations

Only the following data types may be used in Mixed Data requests: MI, ML, DW, MB, I and O.

Registers: may only be read/written to the same data type.

Booleans: Inputs cannot be written to.

Booleans, Read Write			Registers, Read Write		
I		MB, O			
O		MB, O			MI
MB		MB, O			ML
					DW

Send / Receive Buffers

The function uses two buffers, Send and Receive. Each buffer can contain a maximum of 500 bytes.

Read/Write from Data Tables

Use these commands to access the bytes in Vision data tables **without** reference to table structure.




Please note that this is not a standard MODBUS function. Read/Write from Data Tables is compatible with Unitronics' Vision PLC data tables only.

To determine the byte number of a data table cell, hold the cursor over the data table cell. A Tooltip opens, displaying the byte number.


Note •

A MODBUS command cannot read/write more than 242 DT bytes at one time.
In addition, 0 is not a legal length.



Read from Data Table


Below, a MODBUS master reads data tables in Slave ID 1. Bytes 24-43 are read from Slave 1 into bytes 140-159 in the master's data tables.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the slave device containing the coils to be read (data source).
Slave: DT Start of Vector	Const, MI, ML, DW	The start of the vector of bytes to be read (data source).
Slave: DT Offset in Vector	Const, MI, ML, DW	Offset from the Slave: DT Start of Vector
Master: DT Start of Vector	Const, MI, ML, DW	This is the start of a vector of bytes that will contain the data read from the slave.
Master: DT Offset in Vector	Const, MI, ML, DW	Offset from the Master: DT Start of Vector
Read: DT Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 242 DT bytes at one time. In addition, 0 is not a legal length.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Write to Data Table

Below, a MODBUS master writes to data tables in Slave ID 1. Bytes 140-159 are written from the master into bytes 24-43 in the slave's data tables.



Parameter	Type	Function
Slave ID	Constant or MI	The ID of the slave device to which the data will be written (data target).
Slave: DT Start of Vector	Const, MI, ML, DW	The start of the vector of bytes to be written into (data target).
Slave: DT Offset in Vector	Const, MI, ML, DW	Offset from the Slave: DT Start of Vector
Master: DT Start of Vector	Const, MI, ML, DW	This is the start of a vector of bytes, in the master, that will contain the data to be written to the slave (data source)
Master: DT Offset in Vector	Const, MI, ML, DW	Offset from the Master: DT Start of Vector
Read: DT Vector Length	Constant or MI	The vector length. Note • A MODBUS command cannot read/write more than 242 DT bytes at one time. In addition, 0 is not a legal length.
Status Messages	MI	Shows a message number. To check status and diagnose errors, check the MODBUS Status Messages.
Total Sessions	DW	This is the number of times the master PLC will attempt to access the slave device. Note that this is a simple incremental counter. Initialize it by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers.

Configuring a MODBUS slave device


The Ladder section below shows what elements are necessary to enable a master device to read from a slave. Note that the MODBUS Scan operation should **not** be performed during the initial program scan.

Note that you must use a condition (RLO) to activate the MODBUS Configuration.

The slave PLC Ladder application must include the elements shown below.


Step 1: Initializing the Ethernet card and configuring MODBUS

Note that all slave devices must be assigned ID number 255.



Step 2: Scan

To enable the master PLC to access the slave, include a MODBUS Scan FB in the slave's application.




Slave Addressing

Monochrome / Color PLCs

The memory structure of monochrome screen PLCs is different from that of color screen PLCs. This is why each series has its own slave addressing scheme.

- Note •**
- The slave addresses given for the monochrome series are decimal values.
 - The slave addresses given for the color series are hexadecimal values.



Slave Addresses

Standard Vision Division

Coils		MODBUS Command Number		
Pointer Value From:	Operand type	Read	Write	
0000	MB 0-2999	#01 Read Coils	#15 Force Coils	
3000	SB		#15 Force Coils	
4000	I (read-only)		Read-only	
5000	O		#15 Force Coils	
6000	T (read-only)		Read-only	
7000	C (read-only)		Read-only	
8000	MB 3000-4095			

Note • | Note that in order to access MBs 3000-4095, you address as follows: to access MB 3012, request slave address 8012.

Registers			MODBUS Command Number	
Pointer Value From:	Operand type	Register size	Read	Write
0000	MI	16 bit	# 03 Read Holding Registers	# 16 Preset Holding Registers
4000	SI	16 bit		
5100	ML	32 bit		
6100	SL	32 bit		
6300	MDW	32 bit		
6700	SDW	32 bit		
6900	Timer preset	32 bit		
7300	Timer current	32 bit		
7700	MF	32 bit		
7800	Counter Preset	16 bit		
7900	Counter Current	16 bit		

Enhanced Vision Series

Coils		MODBUS Command Number	
Pointer Value From (hex):	Operand type	Read	Write
0000h	MB 0	#01 Read Coils	#15 Force Coils
3000h	XB		#15 Force Coils
4000h	O		#15 Force Coils

5000h	SB	Read-only
6000h	I (read-only)	#15 Force Coils
7000h	T (read-only)	Read-only
8000h	C (read-only)	Read-only

Registers			MODBUS Command Number	
Pointer Value From (hex):	Operand type	Register size	Read	Write
0000h	MI	16 bit	# 03 Read Holding Registers	# 16 Preset Holding Registers
3000h	XI			
9000h	SI	16 bit		
5000h	XL			
6000h	XDW			
7000h	ML	32 bit		
A000h	SL	32 bit		
8000h	MDW	32 bit		
B000h	SDW	32 bit		
C000h	Timer preset	32 bit		
D000h	Timer current	32 bit		
4000h	MF	32 bit		
E000h	Counter Preset	16 bit		
F000h	Counter Current	16 bit		

Examples

The examples below show that:

- MODBUS addressing systems start at 1.
- Vision addressing starts at 0.

Bit Operands

Read a 10-bit vector of inputs in a slave Vision controller, starting at Input 20, via Read Coils (MODBUS COMMAND #1)

- Vision PLC as the MODBUS master to Monochrome PLC

In VisiLogic's Read Coils FB, set the Slave: Start of Vector parameter to 4020 (DEC), and the Read: Vector Length parameter to 10. Within the slave Vision controller, VisiLogic will read I 20 - I 29.

- Vision PLC as the MODBUS master to Color PLC

In VisiLogic's Read Coils FB, set the Slave: Start of Vector parameter to 6014h (HEX), and the Read: Vector Length parameter to 10. Within the slave Vision controller, VisiLogic will read I 20 - I 29.

- SCADA as the MODBUS master to Monochrome PLC

In the SCADA application, set the Slave: Start of Vector parameter to 34021(30001 + 4000 + 20), and the Read: Vector Length to 10, enabling the Master device to read I 20 - I 29 within the slave Vision controller.

- **SCADA as the MODBUS master to Color PLC**

Convert the HEX address to DEC

In the SCADA application, set the Slave: Start of Vector parameter to 54597(24576 (6000h) + 20), and the Read: Vector Length to 10, enabling the Master device to read I 20 - I 29 within the slave Vision controller.

Write a 3-bit vector of outputs in a slave Vision controller, starting at Output 8, via Force Coils (MODBUS COMMAND #15)

- Vision PLC as the MODBUS master to Monochrome PLC

In VisiLogic's Force Coils FB, set the Slave: Start of Vector parameter to 5008, and the Force: Vector Length parameter to 3. Within the slave Vision controller, the master will force the status of O 8 - O 10.

- Vision PLC as the MODBUS master to Color PLC

In VisiLogic's Force Coils FB, set the Slave: Start of Vector parameter to 4008h (HEX), and the Force: Vector Length parameter to 3. Within the slave Vision controller, the master will force the status of O 8 - O 10.

- SCADA as the MODBUS master to Monochrome PLC

In the SCADA application, set the Slave: Start of Vector parameter to 35009 (30001 + 5000 + 8) and the Force: Vector Length parameter to 3, enabling the Master device to write to O 8 - O 10 within the slave Vision controller.

- **SCADA as the MODBUS master to Color PLC**

Convert the HEX address to DEC.

In the SCADA application, set the Slave: Start of Vector parameter to 46393 (30001 + 16384(4000h) + 8) and the Force: Vector Length parameter to 3,

enabling the Master device to write to O 8 - O 10 within the slave Vision controller.

Registers

Read a 9-register long vector of **16-bit integers** in a slave Vision controller, starting at MI 32, via Read Holding Registers (MODBUS COMMAND #03)

- Vision PLC as the MODBUS master

In VisiLogic's Read Holding Registers FB, set the Slave: Start of Vector parameter to 32, and the Read: Vector Length parameter to 9. Within the slave Vision controller, VisiLogic will read MI 32 - MI 41.

- SCADA as the MODBUS master

In the SCADA application, set the Slave: Start of Vector parameter to 40033 (40001 + 0000 + 3), and the Read: Vector Length parameter to 9, enabling the Master device to read MI 32 - MI 41 within the slave Vision controller.

Note •

If, within the Slave: Start of Vector parameter, the selected register type is a **32-bit double register** (slave addresses 5100 and greater) the preset vector length must be **doubled** as well.

If, for example in the VisiLogic Preset Holding Registers FB:

- Slave: Start of Vector parameter is set to 6300, and
- You wish to preset 4 registers, for a total of 16 bytes
- You must set the Preset Vector length to 8.

Note that this means that, in these cases, the **Preset: Vector Length** parameter will always be an even number.

Read a 9-register long vector of **32-bit integers** in a slave Vision controller, starting at SL 32, via Preset Holding Registers (MODBUS COMMAND #16)

- Vision PLC as the MODBUS master

In VisiLogic's Preset Holding Registers FB, set the Slave: Preset Vector parameter to 6132, and the Read: Vector Length parameter to 18 (2x9, in order to fit the 32-bit SL registers). Within the slave Vision controller, VisiLogic will read SL 32 - SL 41.

- SCADA as the MODBUS master

In the SCADA application, set the Slave: Start of Vector parameter to 406133, and the Read: Vector Length parameter to 18, enabling the Master device to read SL 32 - SL 41 within the slave Vision controller.

Write a 6-register long vector of **16-bit integers** in a slave Vision controller, starting at MI 32, via Preset Holding Registers (MODBUS COMMAND #16)

- Vision PLC as the MODBUS master

In VisiLogic's Preset Holding Registers FB, set the Slave: Start of Vector parameter to 32, and the Preset: Vector Length parameter to 6. Within the slave Vision controller, VisiLogic will write to MI 32 - MI 37.

- SCADA as the MODBUS master

In the SCADA application, set the Slave: Start of Vector parameter to 40033, and the Read: Vector Length parameter to 6, enabling the Master device to write to MI 32 - MI 37 within the slave Vision controller.

MODBUS Status Operands

All of the Status operands linked to MODBUS FBs should be assigned Power-up Values; bits should be reset, and registers initialized to 0.

MODBUS: Configuration FB Status Operand

All MODBUS operations run through a MODBUS configuration placed in the master device's program.

Function in Progress Shows status of master's MODBUS Configuration	MB	Turns ON when: A master Vision initiates MODBUS communication. Remains ON during the MODBUS session.	Turns OFF when The MODBUS: Configuration is activated. An answer is received from a slave. The TimeOut defined in the Configuration is exceeded. Certain Status Messages are given
---	-----------	--	---

MODBUS Operation Status Operands

When you place MODBUS operations in your application (Force, Read, Preset, and Loopback commands), you link the operands below. These show the status of MODBUS sessions.

Status Messages Shows status of master's data requests and the replies the master receives from the slaves	MI	Automatically initialized to 0 when MODBUS operation is activated. Updated at the end of each attempt to communicate via MODBUS. Indicates status of MODBUS communications, according to the table below. Note that the current value always shows the most recent status.
---	-----------	--

#	Status Message
0	Status OK
1	Unknown Command Number This is received from the slave device.
2	Illegal Data Address Master: an invalid address is found by the master before a data request is sent to a slave. This may result, for example, when an MI is used to provide vector length. Slave: The slave notifies the master that the data request command includes invalid addresses. Slave--ScanEX: When ScanEX receives an input parameter in the 32-bit range (for example, 5100{ML}), it automatically takes double-register values. If, for example, ScanEX receives a Read Register(6) request for 5100 , it returns the values in 5100 and 5101. If, however, ScanEX receives Read Register(6) request for 5101 , it returns Error #2-- since 5101 provides the 'high' bytes of the 32-bit register, it is not a legal address.
3	Slave to Master: Illegal Data Type Quantity Number of operands requested by user exceeds the maximum Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, 62 float registers, or 1900 bit operands at one time. In addition, 0 is not a legal vector length.
4	Master--Time Out This occurs if the master has been waiting for a slave response for an amount of time exceeding the Time-out set in the Configuration. If this error occurs, check Time Out, Baud Rate, and Distance
5	No Communication The MODBUS session cannot be established.

Note • Messages 4 & 5. **TimeOut** and **Number of Retries** are defined in the **Configuration**. A Retry is an attempt to establish a MODBUS session.

- If, for example, TimeOut is defined as 2 seconds, and number of Retries as 3:
- the controller will try to establish the session once, and will continue to try for 2 seconds.
- If the first attempt fails, the **Status Message value will be 4**, Master TimeOut.
- The controller will try twice more, for a total of 3 retries over 6 seconds.
- If all attempts fail, the **Status Message value will be 5**.
- If any attempt succeeds, the Status Message will be 0.

* 6	Master-slave data incorrectly synchronized
-----	--

* 7	Master-slave data incorrectly synchronized
8	Master to application: Illegal Data Type Quantity Number of operands requested by user exceeds the maximum permitted for that FB operation in the master. Note • A MODBUS command cannot read more than 124 16-bit integers, 62 double registers, 62 float registers, or 1900 bit operands at one time. In addition, 0 is not a legal vector length.
9	Slave ID =0 An attempt does to communicate with Slave ID 0.
10	Incorrect CRC
* 11	Master-slave data incorrectly synchronized

* Messages 6, 7, and 11 mean that the master has found incompatible elements in the data sent between master and slave.

Total Sessions	DW	This is the total number of times the master PLC attempts to access the slave device, whether the attempt is successful or not, including Retries. Note that this is a simple incremental counter. This must be initialized by the user, by storing 0 into the selected DW.
Acknowledgements	DW	This is the number of times the slave device answers. This must be initialized by the user, by storing 0 into the selected DW.

Time Out, Baud Rate, and Distance

The default Time Out set in the Configuration is one second. In certain cases, the length of the network may cause this to be exceeded. You can calculate a Time Out value by using the following formula, and use it in the Configuration.

$$\text{Time Out} = \frac{(\text{TX bytes} + \text{RX bytes} + 7) \times 1000}{\text{baud rate} / (\text{data bits} + \text{start bits} + \text{stop bits}) \times 10\text{ms}}$$

Note •	To automatically reconnect a lost Ethernet connection, turn SB 168 Automatically reconnect (keep alive) ON at power-up.
•	To enable PLC to disconnect when the Ethernet connection is inactive for a period of time, assign timeout values in SIs 103 -106
•	To enable a PLC attempt to reconnect when there is no communication from the connected device for a period of time, assign timeout values in SIs 107 -110

SMS Messaging

SMS Messaging Overview

To enable a controller to use SMS messaging, connect it to a modem that supports connection to a cellular network with SMS messaging service. SMS messaging operations are located on the FBs menu.

To send or receive SMS messages:

1. Initialize one of the controller's communications ports using a COM Init FB.

Note •	Communications cannot flow through the port during initialization. To avoid conflicts in your program, use the Modem Initialization Status SBs.
---------------	---

- | | |
|---|--|
| • | Before using a modem, prepare it as described in the help topic PLC-side Modems. |
|---|--|

Place an SMS Configuration FB into your application. Link it to the port initialized via the COM Init FB. The SMS Configuration will use this port to receive and send messages.

The SMS Configuration contains a list of SMS messages and phone numbers.

Note •	COM Init and SMS Configuration must appear in the application and be activated before any SMS operations are activated. If this is not done, the application will not work.
---------------	---

To enable the controller to receive messages, place an SMS Scan FB in your application and link it to a Configuration. When activated, this causes the controller to scan the GSM modem's SIM card for incoming SMS messages

To enable the controller to send SMS messages, place an SMS Send FB in your application and link it to a Configuration. You can then either send one of the messages in that Configuration or create one for that specific Send FB.

In either case, the port defined in the Configuration will be used to send the message.

FB Operations

SMS: Configuration


SMS: Scan

SMS: Send


SMS: Check GSM Signal Quality

How to Configure, Receive, and Send Messages

1. Initialize a COM Port. The initialization status of each port is indicated in Modem Initialization Status SBs. These SBs can be used to activate an SMS configuration.




2. Select SMS Configuration from the FBs menu and place the function in your application.



- Note •**
- The condition that activates the SMS Configuration must turn ON for a single program scan (positive transition recommended).
 - Once an SMS Configuration is activated, it can process SMS messages. However, messages are sent or received **only** when the MB linked to Modem Busy (GSM) is **OFF**. This MB turns ON when the modem is processing a message, or is communicating data to another application such as VisiLogic.
 - The appropriate Modem: Initialized SBs [80 (COM 1), SB 82 (COM 2), SB 84 (COM 3)] must turn ON before activating an SMS Configuration using that COM port; the SBs should be used as an activating condition.

The SMS configuration must be scanned during every program cycle--after the Configuration is activated. One way to ensure this is by placing the configuration in the first subroutine of the main module.

3. To receive messages, place a Scan FB in your application.



- Note •**
- An SMS Scan generally uses a direct contact as an activating condition. This enables the configuration to continually 'listen' for incoming messages. When the controller registers that a




Scan has been activated, the MB linked to Modem Busy (GSM) turns ON, turning OFF only after the Scan is complete.

You can also write incoming messages to an operand vector, including messages that are not in the Configuration.

1. Turn SB 199.
2. Enter the Start of Vector address (MI) in SI 199. You can write to an XI vector by entering a negative value.

If SB 199 is ON, SB 198 will be SET when an SMS message is received, and the message will be stored in operand vector. The length of the message, in bytes, will be stored in SI 198.

4. To send messages, place a Send FB in your application.



Note • When the positive transition contact used to activate the Send FB rises, the MB linked to Modem Busy (GSM) turns ON. The rest of the logic in the net is processed whether or not the Send operation is completed.


- Operands linked to SMS FBs, such as Modem Busy (GSM), should be assigned Power-up Values; bits should be reset, and registers initialized to 0.

- When an SMS message is sent, the Modem Busy (GSM) MB remains ON until the message has cleared the SIM card.


- Be careful when using positive transition contacts to activate a Send operation. When a Send operation is in progress, the modem is busy. If another Send operation is activated while the modem is busy, the second Send operation will not be activated and the message will **not** be sent--even after the modem is no longer busy.

SMS: Configuration

An SMS Configuration contains a list of SMS messages with attached variables and a phone book that is unique to that configuration. SMS Configuration is also where you define Message Properties.



Note • The appropriate Modem: Initialized SB [80 (COM 1), SB 82 (COM 2), SB 84 (COM 3)] must turn ON before the application can activate an SMS Config FB using that COM port. A Modem Initialized SB should be used as an activating condition.




Creating SMS Messages & Variables

A single SMS message can contain both fixed text and up to 10 variables. A message containing only English characters may contain up to 160 characters. A message containing non-English characters may contain up to 70 characters.


Note • When you create messages in a Configuration, VisiLogic does not allow you to begin a message with a fixed text character that is not a numeral (0-9) or a number sign (#). These limitations do not apply to messages that you compose in an SMS Send FB, or to Indirect Messages. These may begin with variables or with any alphanumeric character.

- Although the PLC can send Binary Text, Numeric, and List of Texts variables, it can only receive **Numeric variables**..



Binary Variable

This type of variable displays different text in the SMS variable field according to the status of a bit operand.



Number Variable

A Number Variable enables you to:

- Show any numeric value within a message.
- Control the format in which that value is shown, including the placement of a decimal point and leading zeros.
- Use Linearization to show a converted value, such as an analog temperature converted to degrees Celsius.

List of Texts: by Pointer

This type of variable contains numbered lines of text. You link the Variable to an operand. The value within that operand 'points' to the number of a line within the list. When the operand value is equal to a particular line number, the text of that line is shown in the Display.

Message Properties

This defines how the PLC deals with a specific SMS message that is **received** by the system. Note that a SMS Scan FB must be placed in the Ladder to enable the PLC to check a specific SMS Configuration for received messages.

Message Properties...

- Scan Message
- Receive Bit: MB 20 : Holding Temperature
- Auto Acknowledge
- Limit To Authorized Phone Numbers

Phone Index	Phone Number
<input checked="" type="checkbox"/>	Last Received Phone Number
<input checked="" type="checkbox"/>	+3145348237
<input checked="" type="checkbox"/>	0453483237
<input type="checkbox"/>	055338793
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	

Callouts:

- Selecting Scan causes the PLC to check if this specific message has been received, when the entire SMS Configuration is scanned for received messages.
- When this message is received by the PLC, this MB turns ON.
- AutoAcknowledge (ACK) allows a cell phone user to check if the PLC received this message.
- Selecting Limit to Authorized Phone Numbers enables you to define legal origins for an SMS message; the numbers from which the message may be received.

Phone Book

Click on a line to either:

- Directly enter a phone number in the phone book, or
- Use a vector of registers to indirectly dial a number. HMI Keypad Entry Variables can then be linked to this vector, enabling a user to dial a number from the controller keypad via HMI Entry Variables.

Phone Book

Options:


- Phone Number
- Indirect Vector (Each register byte contains one character)

Callouts:

- Enter a number
- Select Indirect Vector
- The number of characters determines the length of the vector--relative to the data type (MI, ML, DW).


Indirect Vector

Each register byte contains 1 character. Note that the byte actually contains the **ASCII** value of the desired numeral. For example, the ASCII value of 1 is 049.



International Cell Phone Number Format

To work with international phone numbers, use the full GSM format, including the '+' in front of the country code.





Message Index Numbers

The messages in the Configuration are numbered consecutively. Inserting and deleting messages causes the index numbers to increment and decrement.


If your application contains Send functions that send messages from the Configuration, you must edit the message index number accordingly.

Example

In the following figure, the Send function is set to send the message with Index # 2.



In the next figure, the user inserted a line, causing the index number to increment. However, the user did not edit the Send function, and message Index # is now blank.




SMS: Scan

To enable the controller to receive messages, place an SMS Scan FB in your application and link it to a Configuration. When activated, this causes the controller to scan the GSM modem's SIM card for incoming SMS messages.

Before you can receive an SMS, you must initialize a COM port to use a GSM modem, create an SMS Configuration, and set conditions as explained in Using SMS Messaging.

- Note •** Communications cannot flow through the port during initialization. To avoid conflicts in your program, use the Modem Initialization Status SBs.
- Although the PLC can send Binary Text, Numeric, and List of Texts variables, it can only receive **Numeric variables**.
 - Use an MB activated by the SMS Configuration FB to activate the Scan, as shown in Using SMS Messaging



When the PLC receives a message, the Message Properties defined in the SMS configuration for that message define how it will be processed.

The screenshot shows the 'Message Properties...' dialog box with the following settings:

- Scan Message
- Receive Bit: MB 20 : Holding Temperature
- Auto Acknowledge
- Limit To Authorized Phone Numbers

The 'Limit To Authorized Phone Numbers' section contains a table with the following data:

Phone Index	Phone Number
0	Last Received Phone Number
1	+3145348237
2	0453483237
3	055338793
4	
5	
6	
7	
8	


Four callout boxes provide the following explanations:

- Callout 1:** Selecting Scan causes the PLC to check if this specific message has been received, when the entire SMS Configuration is scanned for received messages.
- Callout 2:** When this message is received by the PLC, this MB turns ON.
- Callout 3:** AutoAcknowledge (ACK) allows a cell phone user to check if the PLC received this message.
- Callout 4:** Selecting Limit to Authorized Phone Numbers enables you to define legal origins for an SMS message; the numbers from which the message may be received.

SMS: Send

To send an SMS, place an SMS Send operation in your Ladder application. Before you can send an SMS, you must initialize a COM port to use a GSM modem, create an SMS Configuration, and set conditions as explained in Using SMS Messaging.

Note •	Communications cannot flow through the port during initialization. To avoid conflicts in your program, use the Modem Initialization Status SBs.
•	Before using a modem, prepare it as described in the help topic PLC-side Modems.
•	If the SMS Configuration is busy, messages cannot be received. Avoid conflicts by using a negative contact, linked to the Configuration's Modem is Busy MB, as an activating condition for SMS: Send.



Note •	You can send only one SMS message at a time, but you may send it to multiple phone numbers.
•	The Send Status MB turns on if there are more than one Send operations, and the PLC has not finished processing the first Send before the second Send is activated. In this case, Modem Busy MB of the SMS: Configuration bit will be ON, causing the Send Fail Bitmap to contain a value of -1.

Open the Phone Book of the linked Configuration; select where to send the message.

Select an SMS Configuration. These messages will be sent via the Com port selected in the SMS Configuration.

Select a tab to determine what message will be sent when the Send FB is called in your program.

ON when transmission fails due to an unreachable phone number.

Provides a bitmap that indicates the index number of a phone number that cannot be reached. If, for example, bit #3 in the register is not 0, the 3rd number in the phone book could not be reached. **Note that a value of -1 indicates that the Modem Busy (GSM) MB was on when the Send attempt was made.**

<p>Compose Message</p>	<p>Opens a blank message field. Create a message by typing characters and attaching variables.</p>
------------------------	--

<p>Select from Configuration</p>	<p>Opens the list of messages contained in the linked Configuration. To select a message to send, click it; the message will be highlighted.</p>
----------------------------------	--

<p>Indirect Message</p>	<p>Enables a vector of register values to be sent as ASCII characters. Note • Each register byte contains one character.</p>
-------------------------	---

Note • When you create messages in a Configuration, VisiLogic does not allow you to begin a message with a fixed text character that is not a numeral (0-9) or a number sign (#). These limitations do not apply to messages that you compose in an SMS Send FB, or to Indirect Messages. These may begin with variables or with any alphanumeric character.


- A message containing only English characters may contain up to 160 characters.
- A message containing non-English characters may contain up to 70

	characters.
•	Phone Indexes is based on the Phone Book in the linked SMS configuration. Index numbers are 0 to 8, note that 0 is the index of the last number called.
•	SB 184 SMS: Transmission Succeeded and 185 SMS: Transmission Failed are both reset when any message is sent to any phone number. After the message has been processed, the Relevant SB will turn ON.
•	You can send messages in ASCII text format by turning ON SB 279: ASCII Text message format,
•	If forced display messages are supported by the cell phone receiving the SMS, you can send a forced display message by turning ON SB 280: Force Message Display on Cell Phone.

SMS Variables


Variables can be included in Configuration or Send FB messages. A single SMS message can contain both fixed text and up to 10 variables. Note that SMS variables are not related to HMI variables.

Although the PLC can send Binary Text, Numeric, and List of Texts variables, it can only receive **Numeric** variables.



Binary Variable

This type of variable displays different text in the SMS variable field according to the status of a bit operand. The value currently visible is the last value sent.



Numeric Variable

A Number Variable enables you to:


- Show any numeric value within a message.
- Control the format in which that value is shown, including the placement of a decimal point and leading zeros.
- Use Linearization to show a converted value, such as an analog temperature converted to degrees Celsius.

List of Texts: by Pointer

This type of variable contains numbered lines of text. You link the Variable to an operand. The value within that operand 'points' to the number of a line within the list. When the operand value is equal to a particular line number, the text of that line is shown in the Display.

SMS: Check GSM Signal Quality

The signal quality may be checked at any point after SMS Configuration.



The signal quality value is placed in **SI 185 GSM Signal Quality**.

A value of -1(FFFF) signifies a modem error. This may be due to a weak signal; try repositioning the antenna. If this has no effect, check the modem.

Send SMS messages from a GSM cell phone

To send SMS messages from your cell phone to your PLC, you must:

- Create and download a project to your PLC that includes an SMS Configuration, set Message Properties, and define conditions as described in the topic Using SMS Messaging.
- Write an SMS message in your cell phone.
- Send the message to the PLC's GSM modem

Note • You can only send messages that are already part of an SMS Configuration in the PLC.


- If the Limit to Authorized Phone Numbers option is selected in the SMS configuration, the cell phone number must be in the list.

Writing SMS messages in your cell phone

You write an SMS message using your cell phone keypad. Make sure that:

- The fixed text in your cell phone is identical to the message in the PLC's SMS Configuration **in every detail**: spaces, characters--and note that characters are case-sensitive.
- You bracket variable values with number signs (#) as shown below. These signs '#' do **not** count as spaces.
- The variable field in the SMS message is big enough to hold the value.

The figure below shows the same SMS message: as it appears on a cell phone display, and as it appears in the PLC's SMS Configuration.



When you send this message from your cell phone, the value 110 will be written into the variable in the PLC.


Sending the message to the PLC

1. Enter the number of the PLC's GSM modem exactly as you would enter any GSM cell phone number, then send the message.

Checking that the PLC has received the SMS message

You can check if the PLC received your message by using the Acknowledge feature:

1. Select 'Acknowledge' in Message Properties, the **ACK** box is checked as shown below.



2. Use your cell phone to send the message "**Holding Temperature:#110#**" to the PLC.

Cell Phone Display



3. The PLC receives this SMS message; AutoAcknowledge causes the PLC to immediately return the message to your cell phone, together with the current variable value.
4. You can now view this SMS message on your cell phone display, together with changes in the variable value.

Cell Phone Display



Note that although the PLC can send SMS messages that include Numeric, Binary, and List variables, the PLC can only receive Numeric variables.

SMS Operands

Operands linked to SMS FBs should be assigned Power-up Values; bits should be reset, and registers initialized to 0.

SMS: Configuration FB

<p>Modem Busy (GSM) Reset when SMS: Configuration is activated.</p>	<p>MB</p>	<p>Turns ON when:</p> <ul style="list-style-type: none"> • SMS: Send FB is activated. • Check GSM signal FB is active • A Scan FB is processing incoming messages. • An SMS is being Auto-acknowledged. • The PLC is communicating data with another application, such as VisiLogic. 	<p>Turns OFF when</p> <ul style="list-style-type: none"> • Send process is complete. • When messages received from a Scan FB have been processed.
<p>Status Messages Initialized to 0 when SMS: Configuration is activated.</p>	<p>MI</p>	<p>• Updated at the end of all operations using the SMS: Configuration; Send, Scan, and Check GSM Signal FBs.</p> <p>• Indicates error status for Send, Scan, and Check GSM Signal FBs.</p> <p>• Current value always shows the most recent error status.</p> <p>Value Message</p> <p>0 No error</p> <p>1 Message received from a phone number that is not in the phone book, or the number is not in the correct format</p> <p>2 (Send only) Non-existent SMS message index number</p> <p>3 SMS received from unauthorized phone number</p> <p>4 (Scan only)The SMS message received does not exist in the SMS configuration</p> <p>5 Modem TimeOut time exceeded: no reply</p> <p>6 (Scan only) Received Variable Mismatch.</p> <p>Variable:</p> <ul style="list-style-type: none"> - Does not exist in the SMS configuration, or - Is not in the correct format, or - Exceeds the range set for the variable <p>7 Modem Reply Error</p> <p>8 Unknown Modem Reply</p> <p>9 (Send only)Either the phone number or the SMS message is in the incorrect format and may not be transmitted</p>	

SMS Scan FB

<p>Scan Status Initialized to 0 the first time the SMS Scan is called</p>	<p>MB</p>	<p>Turns ON when:</p> <ul style="list-style-type: none"> • An error occurs during the current Scan. The Error message is indicated in the Status Messages MI of the SMS: Configuration. 	<p>Turns OFF when</p> <ul style="list-style-type: none"> • A Scan operation is successfully completed.
---	------------------	--	---

SMS: Send FB

<p>Send Status</p>	<p>MB</p>	<p>Turns ON when:</p> <ul style="list-style-type: none"> • The Send operation has been completed, and one or more of the SMS messages has not been successfully sent. • This MB turns on if there are more than one Send operations, and the PLC has not finished processing the first Send before the second Send is activated. In this case, Modem Busy (GSM) MB of the SMS: Configuration will be ON, causing the Send Fail Bitmap will contain a value of -1. <p>-The Error message is indicated in the Error Status MI of the SMS: Configuration linked to the Scan FB</p> <p>-The Send: Fail Bitmap indicates which phone numbers have not received the SMS.</p>	<p>Turns OFF when</p> <ul style="list-style-type: none"> • All messages in the SMS: Send have been sent to all of the phone numbers.
---------------------------	------------------	--	---

Send: Fail Bitmap

MI

- Provides a bitmap that indicates the index number of a phone number that cannot be reached. If, for example, bit #3 in the register is not 0, the 3rd number in the phone book could not be reached.
- The bits are initialized to 0 when the Send FB is activated. As calls are made, each **failure** causes the relevant bit to turn ON.
- Note that:
 - Phone Indexes is based on the Phone Book in the linked SMS configuration. Index numbers are 0 to 8, note that 0 is the index of the last number called.
 - a value of -1 indicates that the **Modem Busy** MB of the **SMS: Configuration** was ON when the Send attempt was made.

SMS System Operands

The status of these SBs changes to reflect the status of each SMS message sent by the system, including when messages are auto-acknowledged.

When the Send process begins, for each and every message, both SB 184 and 185 are OFF. After the message is sent, the relevant bit turns ON, indicating the success or failure of that message.

Each port has a Succeed and Fail SB. When the Send process begins from a particular COM port, for each and every message, both the Succeed and Fail SB turn OFF.

If the message is sent successfully, the bit turns ON, indicating the success or failure of that message.

If the message fails, when TimeOut is exceeded or because the modem reports an error, the bit remains OFF.

Operands that are linked by the user to SMS FBs may be found in the topic SMS Operands.

SB	Description	Turns ON when:	Turns OFF when:
184	SMS: Transmission Succeeded, COM1 (ACK)	Transmission succeeds	Transmission begins
185	SMS: Transmission Failed, COM1 (NACK)	Transmission fails	
186	SMS: Transmission Succeeded, COM2 (ACK)	Transmission succeeds	
187	SMS: Transmission Failed, COM2 (NACK)	Transmission fails	
188	SMS: Transmission Succeeded, COM3 (ACK)	Transmission succeeds	
189	SMS: Transmission Failed, COM3 (NACK)	Transmission fails	

Use these together with SI 198 and 199 to write incoming SMS messages to a vector of operands. This does not affect the function of the SMS message function blocks.

SB	Description	Turns ON when:	Turns OFF when:
198	Record the Received SMS Message Length	If SB 199 is set, SB 198 is set when a message is received	User Program

199 | Save SMS to Memory Vector | User Program |

Use these together with SB 198 and 199 to write incoming SMS messages to a vector of operands. This does not affect the function of the SMS message function blocks.

SI	Description	Value
198	Received SMS Message Length	Shows the length of the message in bytes The data remains until the vector is overwritten
199	SMS to Memory Vector - start of vector	The SMS message data is written starting from this address. To write to a vector of XIs, enter a negative value


GPRS

GPRS Overview


GPRS is a wireless data transmission service offered by some cellular providers. When a Unitronics' PLC is connected to a GPRS modem, the PLC can establish a data connection with a remote PC connected to the Internet and transmit IP packets of data over the GPRS cellular network.

You can then use your PC to access the PLC via VisiLogic, Remote Access or other communication .dll, as well as log PLC data via the DataXport utility. You can also send e-mail via GPRS modem.

The figure below shows GPRS communication elements.



<p>Notes •</p>	<p>The PLC must be connected to a GPRS modem. GPRS service must be supplied by the user's cellular service provider.</p>
<ul style="list-style-type: none"> • 	<p>To enable any GPRS operations to run, the PLC application must include GPRS Configuration and GPRS Run FBs.</p>
<ul style="list-style-type: none"> • 	<p>You must prepare both the PLC and PC side modems by carrying out the Prepare PLC-side Modem procedure detailed in the topic PLC-side modems, and the Initialize PC Modem detailed in the topic PC-side modems.</p>
<ul style="list-style-type: none"> • 	<p>To send e-mail via GPRS modem, when you prepare the modem via Modem Services, set it to a baud rate of 9600. In addition, the COM Init function should be set to 9600.</p>
<ul style="list-style-type: none"> • 	<p>Note that regarding Enhanced Vision models, as of OS 3.1.19 GPRS is no longer supported for Wavecom and Sony Ericsson modems. To view the list of supported modems, open the COM Init function and select GSM modem as shown in the section below, Using GPRS.</p>
<ul style="list-style-type: none"> • 	<p>Unitronics has tested the following GPRS modems with Unitronic's PLCs:</p> <p>Wavecom Fastrack WM15467 (GPRS+TCP/IP 900/1800 MHz), Firmware version: 640b09gg.Q2406B 1272884070403, TCP/IP stack: eDsoft-W302_V02.00 104930</p> <p>You can use Hyperterminal to: Check the modem's firmware version, via command AT+CGMR. Check the TCP/IP Stack, via command AT#VVersion.</p>




Sony Ericsson GT47

Firmware version: R5B003 prgCXCC1122528

You can use Hyperterminal to:


Check the modem's firmware version, via command AT+GMR.



- The PLC must initiate the GPRS data link by calling the PC.
A sample application showing how to establish PC-PLC communications via GPRS is available for currently supported modems. This application is intended to be used as a template, for you to simply copy and adapt to your own requirements. Sample applications are located under Help>Examples.
- Wavcom modems do not support the End Call function. In order to end a call, use the Unregister from Network function, and then re-register if required.
- The Sony Ericsson GT47 GPRS modem must be used in conjunction with an appropriate cable and 5 pin connector.
- Not supported by the V120-12 series.

Using GPRS

The PLC's Ladder application must contain the conditions and elements shown below.



FB Name	Purpose
COM Port Init FB	Configure this FB to initialize the PLC COM Port connected to the GPRS-modem. Within the COM Init FB, select the GSM modem type, and then the actual GPRS modem type, such as the Sony Ericsson GT47. COM Port Init is usually a Power-up task. Note • To learn how to prepare the modem for PLC use, check the topic PLC-side Modems.
GPRS Configuration	The Configuration is linked to the serial port initialized via the COM Port Init FB. Note • The activating conditions should include the appropriate Modem Initialized SB for the COM Port.
GPRS Register to Network	Register must follow the GPRS Configuration. Connect provides the parameters that enable the PLC to connect to the Internet via the cellular network.
GPRS Run	This element enables data communications via GPRS. Note • The activating conditions should include the appropriate Modem Initialized SB for the COM Port.

Downloading OS via GPRS

Enhanced Vision controllers using Boot 2.00 and higher support OS download via GPRS modem.

Notes •	The TC65 does not support OS download.
	The modem must be connected to COM2.

Once the download begins, the controller enters Boot mode. Any interruption in communication may result in the controller being 'stuck' in boot mode, without an installed OS. For this reason, **it is it is recommended that**

someone be next to the PLC during the OS download in order to attend to any potential problems.

FB Operations

GPRS Operations are located on the FBs menu.

Configuration

Register to Network

Run

Start/End Call

Listen/Stop Listening Remote Device

Unregister (Disconnect) from Network

Check Signal Quality


GPRS Operands & Status Messages

GPRS Configuration

The GPRS Configuration must be included in all GPRS Ladder applications.

The Configuration is linked to the serial port connected to the GPRS modem and initialized via the COM Port Init FB.


Note • The activating conditions should include the appropriate Modem Initialized SB for the COM Port.



Parameter	Type	Function
Name		The name of the Configuration.
Port Number	Constant	Click the drop-down arrows to view available ports; click the port you want to use.
Status Messages	MI	The value of the linked MI indicates GPRS status messages.
Call Status	MB	This bit turns ON when the remote device has been accessed and the GPRS connection is established.

GPRS Register to Network


This FB provides the parameters that enable the PLC to connect to the Internet via the GPRS cellular network.



Parameter	Type	Function
Name		Select the name of the GPRS Configuration that Connect will use to connect to the GPRS network.
Registration Status	MB	Turns ON when the PLC is assigned an IP address and registered by the GPRS network.
IP Address	MI	When the PLC registers on the GPRS network, it is assigned a dynamic IP address. This is the start of a vector that contains the IP address that is assigned to the modem when the modem registers with the GPRS network. The vector is 4 MIs long. The low byte of each MI provides the number for an octet within the IP address. If, for example, the IP address is linked to MI 0, and the low bytes of MI 0 to MI 3 contain the values 192, 198, 192, 45, the IP address will be 192.198.192.45.
APN Server	Constant or MI	The name of the APN (Access Point Name) Server given by your GPRS service provider.
Dial Number (optional)	Constant or MI	These parameters are required by some GPRS service providers and GPRS modem manufacturers.
User Name (optional)	Constant or MI	
Password (optional)	Constant or MI	

GPRS Run


This element enables data communications via GPRS and must be included in all GPRS applications. The activating conditions should include the appropriate Modem Initialized SB for the COM Port.



Start Call, End Call

Start Call


This FB provides the Port and IP address of the remote device, enabling the PLC to call the remote device and establish a data communications link.



Parameter	Type	Function
Name		Select the name of the GPRS Configuration that Connect will use to connect to the GPRS network.
Remote TCP/IP Port	Constant or MI	The access port of the remote device.
IP Address	Constant or MI	The address of the remote device.

End Call

This FB ends the current data communications sessions with a remote device, but does not terminate the connection to the GPRS network.



Note •

Wavecom modems do not support the End Call function. In order to end a call, use the Unregister from Network FB, and then re-register to the network if required.

Listen /Stop Listening to Remote Device

Listen


This FB provides the Port and IP address of the remote device, enabling the PLC to call the remote device and establish a data communications link.



Parameter	Type	Function
Name		Select the name of the GPRS Configuration that Connect will use to connect to the GPRS network.
Remote TCP/IP Port	Constant or MI	The port the PLC uses to listen to the remote device.

Stop Listening

This FB ends the current data communications sessions with a remote device, but does not terminate the connection to the GPRS network.




Parameter	Type	Function
Name		Select the name of the GPRS Configuration that Connect will use to connect to the GPRS network.

Note •

Wavecom modems do not support the End Call function. In order to end a call, use the Unregister from Network FB, and then re-register to the network if required.

Unregister from Network


Use this to disconnect the PLC from the GPRS network, including a delay of a second or two to allow the socket time to close when de-registering.



Check Signal Quality

The signal quality value is placed in SI 185 GSM Signal Quality.

A value of -1(FFFF) signifies a modem error. This may be due to a weak signal; try repositioning the antenna. If this has no effect, check the modem.



GPRS Operands & Status Messages

Operands linked to GPRS FBs should be assigned Power-up Values; bits should be reset, and registers initialized to 0.

GPRS: Configuration FB

Call Status GPRS	MB	Turns ON when: Call successfully made	Turns OFF when Call is terminated
Status Messages Initialized to 0 when GPRS: Configuration is activated.	MI	Value Message 0 No message 1 GPRS network registration is in progress 2 Registration Complete: the modem successfully registered with and received an IP address from the GPRS network 3 Connected to GPRS network 4 Listen Mode: Initialization Begins 5 Listen Mode: Initialized 6 Listen Mode: Initialization Re-started 10 Start Call: Begins 11 Start Call: Complete 15 End call: Begins 16 End call: Complete 20 Unregistration Begins (Not during Call) 21 Unregistration Begins (During Call) 22 Unregistration Complete: the modem has successfully disconnected from the GPRS network 23 Listen Mode: Close process begins 24 Listen Mode: Closed 30 Check Signal Quality: Start 31 Check Signal Quality: End 40 Command not supported (When End Call is activated in an application using a Wavecom modem) 50 Modem reply error 51 Modem Timeout error 52 Network Registration: failed	

GPRS: Register to Network

Registration Status	MB	Turns ON when: The modem successfully registers with and received an IP address from the GPRS network	Turns OFF when The modem disconnects from the network
IP Address	MI	This is the start of a vector that contains the IP address that is assigned to the modem when the modem registers with the GPRS network. The vector is 4 MIs long. The low byte of each MI provides the number for an octet within the IP address. If, for example, the IP address is linked to MI 0, and the low bytes of MI 0 to MI 3 contain the values 192, 198, 192, 45, the IP address will be 192.198.192.45.	

GPRS System Operands

SI	Description	Value
185	GSM Signal Quality	The value is written during COM Init of the GSM modem. The value is updated whenever the user uses the GSM Signal Quality FB. A value of -1 (FFFF) signifies a modem error. This may be due to a weak signal; try repositioning the antenna. If this has no effect, check the modem.

SBs 120-125 register the signals that each port receives from the DTR and DSR pins of a serial communication cable. The DTR SBs 120, 122, and 124 are also used by the OS to control the DTR signal during RS485 serial communications, and during GPRS communications using the Sony Ericsson GPRS modem.

SB#	Description	Turns ON when:	Turns OFF when:	Reset by:
SB100	GPRS modem connected	Call Remote device begins GPRS incoming call is answered	End Session succeeds Disconnect from Network succeeds	OS
SB 120	DTR COM Port 1 (signal output from PLC)	DTR signal present	DTR signal absent	OS, may also be reset by user
SB 121	DSR COM Port 1 (signal input to PLC)	DSR signal present	DSR signal absent	OS
SB 122	DTR COM Port 2 (signal output from PLC)	DTR signal present	DTR signal absent	OS, may also be reset by user
SB 123	DSR COM Port 2 (signal input to PLC)	DSR signal present	DSR signal absent	OS
SB 124	DTR COM Port 3 (signal output from PLC)	DTR signal present	DTR signal absent	OS, may also be reset by user
SB 125	DSR COM Port 3 (signal input to PLC)	DSR signal present	DSR signal absent	OS


PLC DataCom

PLC DataCom Overview

If your controller comprises an Ethernet card, you can use Remote PLC DataCom commands to communicate mixed data messages, containing both register and bit values, to remote Unitronics PLCs over TCP/IP.

Any controller in the network may function as either master or slave via the controller's Ethernet port.

i Remote PLC DataCom runs over UDP. TCP is not supported. Specific information on implementing Ethernet is provided in the topic Using Ethernet.



Using Remote PLC DataCom

Before using a Remote PLC DataCom operation in your application, you must:

- Assign IP addresses to both master and slave PLCs. This is done by placing TCP/IP Card Init FBs in the ladder application of both master and slave.
- Determine which socket will be used for PLC DataCom.
 - Socket 0: This socket is set to UDP broadcast by default. If you select Socket 0, you must set it to support UDP Unicast (device to device) by turning SB 159 OFF. You must also include a TCP/IP Socket Init, set to UDP mode.
 - Sockets 1-3: These are set to TCP by default. In order to use these sockets, use a TCP/IP Socket Init function to switch the socket to UDP mode. If you set Sockets 1-3 to UDP, they will be in Broadcast mode.
- Include at least 1 Remote PLC DataCom Configuration FB in the ladder application of **both** master and slave.
- The condition that activates the Configuration must turn ON for a single program scan (positive transition recommended).
However, the Remote PLC DataCom configuration must be scanned


during every program cycle--after the Configuration is activated. One way to ensure this is by placing the configuration in the first subroutine of the main module.

- Enable data transfer by including an Update FB in the ladder application of **both** master and slave.


You can also include a DataCom Data Synchronization function in your master's ladder application. This causes the Write messages to be sent before the Read messages.

The programs below show how to implement PLC DataCom via Socket 0.

Master Program



Slave Program



Note • Non-Legacy controllers such as the V570 have a fast program scan. In order to ensure that operations work correctly, ensure that the program scan is greater than 3 msec. This can be done by increasing the scan time with the Idle utility.

FB Operations

Remote PLC DataCom Operations are located on the FBs menu.

Configuration

DataCom Data Synchronization

Update

Master Data Request

PLC DataCom: Configuration

A PLC DataCom Configuration FB must be included in both master and slave Ladder applications as shown below. PLC DataCom Operations are located on the FBs menu.

Master Configuration

The Master Configuration enables you to send data requests to Slave PLCs.

To display the Master parameters, select Master under Master/Slave.

Each Configuration can contain both Read and Write Mix Requests. Each request may be for a different data type. Your data request must include :

- Master and Slave operand addresses
- Length of vector
- Direction: Read or Write







After you add a request, the OK button is disabled. Click the Compile button to see current buffer status; if the buffer contains less than the maximum number of bytes, the OK is enabled.


Read Write Limitations

Only the following data types may be used in Read/Write requests: MI, ML, DW, MB, I and O.

Registers: may only be read/written to the same data type.

Booleans: Inputs cannot be written to.

Booleans, Read Write			Registers, Read Write		
I		MB, O	MI		MI
O		MB, O	ML		ML
MB		MB, O	DW		DW



Parameter	Type	Function
Configuration parameters		
Delay Program Scan	MI	This is the amount of time a Master PLC will halt the program scan in order to wait for an answer from a Slave. Time out units are defined in 1 msec; the maximum is 100 msec.
Actual Time of Delay	MI	This is the amount of time the Master PLC actually waited for a Slave response.
Status	MI	The value in the Status MI indicates the following: 0 - No Error 1 - Master: waiting for message (The Configuration parameter Delay Program Scan time has not been exceeded) Errors: 3 - The number of Read requests or the number of Write requests is greater than 16. 4 - The Master message length or the Slave message length exceeds the legal limit of 500 bytes. 5 - No Ethernet card can be found. 6 - The Ethernet card is not set to UDP. 7 - The Wait Time has been exceeded (Wait time > 100 in the Master or Wait time > 10 in Slave). 8 - Master has not received message (The Configuration parameter Delay Program Scan time has been exceeded). 9 - PLC or network error. 10 - The remote Slave IP does not exist. 11 - Checksum Error in the message received by the Master.

TCP/IP

Socket		In order to support Remote PLC DataCom, the socket you use must be set to UDP, Multicast mode. By default, Socket 0 is set to UDP, Unicast. To enable PLC DataCom, reset SB 159 to change Socket 0 to Multicast.
Remote IP	MI	The IP address of the remote Slave unit. Note • The IP vector is 4 MIs long. The low byte of each MI provides the number for an octet within the IP address. If, for example, the IP address is linked to MI 0, and the low bytes of MI 0 to MI 3 contain the values 192, 198, 192, 45, the IP address will be 192.198.192. 45.
Remote Port	MI	The access port of the remote Slave unit.

Master Data Requests

Click in a field to select the:


- Start of the master's data vector
- Start of the slave's data vector
- Vector length
- Direction, Read from Slave or Write to Slave

Memory usage

The function uses two buffers, Send and Receive. Each buffer can contain a maximum of 500 bytes.
Clicking Compile updates the Buffer Usage report.
If the Request fits in the buffer, the OK button is enabled.

Slave Configuration


The Slave Configuration enables the Slave PLC to receive data requests.



Parameter	Type	Function
Configuration parameters		
Delay Program Scan	MI	This is the amount of time a Slave PLC will halt the program scan in order to wait for a Master message. Time out units are defined in 1 msec; the maximum is 10 msec.
Actual Time of Delay	MI	This is the amount of time the Slave PLC actually waited for a Master message.
Status	MI	<p>The value in the Status MI indicates the following:</p> <ul style="list-style-type: none"> 0 - No Error 1 - Master: waiting for message (The Configuration parameter Delay Program Scan time has not been exceeded) <p>Errors:</p> <ul style="list-style-type: none"> 3 - The number of Read requests or the number of Write requests is greater than 16. 4 - The Master message length or the Slave message length exceeds the legal limit of 500 bytes. 5 - No Ethernet card can be found. 6 - The Ethernet card is not set to UDP. 7 - The Wait Time has been exceeded (Wait time > 100 in the Master or Wait time > 10 in Slave). 8 - Master has not received message (The Configuration parameter Delay Program Scan time has been exceeded). 9 - PLC or network error. 10 - The remote Slave IP does not exist. 11 - Checksum Error in the message received by the Master.

Master Data Request


Activate a Master Data Request to send all data messages in the Master Configuration.



Update


Update enables a PLC to receive Remote PLC DataCom messages. Update must be included in Slave ladder applications to enable a Slave to receive messages, and must be included in the Master ladder application to enable the Master to receive responses from slave PLCs.

Update should be placed on the left-hand ladder rail in the Main routine.



DataCom Data Synchronization

This function causes the Write data messages to be sent before the Read data messages.



PLC DataCom Status Messages

The value in the Configuration's Status MI indicates the following:

- 0 - No Error
- 1 - Master: waiting for message (the Configuration parameter Delay Program Scan time has not been exceeded)
- 3 - The number of Read requests or the number of Write requests is greater than 16.
- 4 - The Master message length or the Slave message length exceeds the legal limit of 500 bytes.
- 5 - No Ethernet card can be found.
- 6 - The Ethernet card is not set to UDP.
- 7 - The Wait Time has been exceeded (Wait time > 100 in the Master or Wait time > 10 in Slave).
- 8 - Master: waiting for message (the Configuration parameter Delay Program Scan time has been exceeded).
- 9 - PLC or network error.
- 10 - The remote Slave IP does not exist.
- 11 - Checksum Error in the message received by the Master.

Note •	To automatically reconnect a lost Ethernet connection, turn SB 168 Automatically reconnect (keep alive) ON at power-up.
•	To enable PLC to disconnect when the Ethernet connection is inactive for a period of time, assign timeout values in SIs 103 -106
•	To enable a PLC attempt to reconnect when there is no communication from the connected device for a period of time, assign timeout values in SIs 107 -110

Protocol FB, Serial

Protocol FB (Serial) Overview

Use the Communication Protocol operations to enable your controller to exchange data with external devices, such as frequency converters, bar-code readers, and printers via a Vision COM port. Protocol operations are located on the FBs menu.

How the Protocol FB communicates data between Vision controllers and other devices

A device, such as a magnetic card reader, may use its own proprietary protocol. If you know the protocol's structure, you can use the Protocol FB to structure messages accordingly. This enables a Vision controller to exchange data with the device using the device's own protocol.

Note that before you can use Protocol operations, you must configure the COM port to be connected to the external device in accordance with the device's requirements. This is done by placing a COM Port Init FB in your Ladder application.

Basic Example


The example below shows how a Vision controller can, via COM port 2, read Register 25 within a device that has the ID number of 01. The device uses the simple protocol shown below.

Device Protocol


Parameter name	Length (bytes)	Value	Comments
STX	1	STX 02(hex)	All messages must begin with the STX character
Unit ID	2	ID# range = 0-99	All messages must contain the ID number of the device that the controller is communicating with
Command	2	03=Read Register 04=Read Bit 05=Write Register	Commands are embedded in Data Request messages.
Data (Request)	4		Vision to Device
Data (Response)	8		Device to Vision
Reserved	2	2 Null characters=00,00	These characters must be included in all messages.
Checksum	2	Sum 8	
ETX	1	/ backslash) 2F(hex)	All messages must end with the '/'character

Message Structure: Data Request (Vision to device)

The device can only receive request messages that are structured as shown below.



Checksum



Message Structure: Data Response (device to Vision)

The device sends data in messages that are structured as shown below.




Protocol Ladder Requirements

In order to enable a Vision controller to request and receive data from a device, the controller's Ladder application must contain:

- A COM Init FB to initialize the serial port that will be linked to the device.
- A Protocol Configuration FB set to use the serial port.
- A Protocol Send FB, which enables the controller to send data request messages to the device.
- A Protocol Scan FB, which enables the controller to receive data response messages from the device. Note that in order to receive new messages, you **must clear the communication buffer after each message by using the Reset Buffer FB.**

COM Init and Configuration



Since COM Port 2 is connected to the device, the application initializes and configures COM 2 at Power-up.



Send: Data Request

The application requests data via the Protocol Send FB. The Send FB enables you to structure messages that conform to any protocol's requirements.

Below, the Vision sends a data request to Unit 01. The request is Command 03, Read Register, and the register is Register 25.




Scan: Receiving Messages


A Protocol Scan FB contains messages. Activating the Scan causes the Vision to check if it has received any of the messages contained within the Scan FB. Note that the controller can only receive messages that are defined in the Scan FB.

Note • In order to receive new messages, you must clear the communication buffer by using the Reset Buffer operation. You can save the contents of the buffer at any time by using the Copy Buffer operation.


- Maximum message length is 500 characters; a message may include up to 50 variables. Note that within the body of a message, no section--whether text or variable--may exceed 255 characters.



Below, the application enables the Vision to receive a response to Command 03. Note that Buffer reset follows the Scan.



Note that the Scan message contains a Data Response field that is long enough to contain the contents of a register.



For more information regarding Protocol operations, refer to the topics below.

FB Operations

Configuration

Scan

Send

Copy Buffer Contents

Reset Buffer

Note •

Reset Buffer must be used in the Ladder application to enable new messages to be received.


- If you want to access a PLC via PC, remember that a PC accesses a PLC via a serial port. Vision controller ports are served by three communication buffers. Note that if all three buffers are busy processing communications, new requests are ignored until a buffer is free.

Protocol: Configuration

You create messages and attach variable data in Protocol Send and Scan operations. Each operation is linked to a Protocol Configuration. When a Send operation is called in your program, the Configuration determines which COM port is used for outgoing messages; when a Scan operation is activated, the PLC monitors that COM port for incoming messages.

Note • The Configuration should be placed in the Main Routine, before any other FB operations. If the configuration is not active, Protocol operations will not be processed.

- Before you place this FB in your Ladder, you must use a COM Port INIT FB to configure a COM port.



Parameter		Function
Name		Identifies the configuration. You use the name to link Protocol Send and Scan operations to a configuration.
COM Port		Determines which port is used for communicating the configured protocol.
Function in Progress	MB	Link an MB; this MB will be ON when the Configuration is processing Scan or Send operations.
Status	MI	If errors occur when the Configuration is used for a Send or Scan operation, the value of the linked MI indicates which error has occurred.

Protocol: Scan


A Protocol Scan operation contains messages. Activating the Scan causes the PLC to check if it has received any of the messages contained within the Scan. The PLC can only receive messages that are contained in a Scan FB.

Each Protocol Scan operation is linked to a particular Protocol Configuration. The Scan only registers messages that are received via the COM port defined in that Configuration.

Scan is located under FBs>Protocol.

Note • In order to receive new messages, you must clear the communication buffer by using the Reset Buffer operation. You can save the contents of the buffer at any time by using the Copy Buffer operation.

• Maximum message length is 500 characters; a message may include up to 50 variables. Note that within the body of a message, no section--whether text or variable--may exceed 255 characters.



The screenshot shows the **Protocol Scan** software interface. Key features and settings are highlighted with callouts:

- Message index #**: Points to the first column of the message list.
- Scan Length**: Points to the second column of the message list.
- Inserts a Variable into the message**: Points to the variable insertion icon.
- Inserts a control character**: Points to the control character insertion icon.
- Add & delete messages**: Points to the add and delete message icons.
- Delete all messages**: Points to the 'Clear All' button.
- Select the name of the configuration to be used in the scan**: Points to the 'Select Name' dropdown menu.
- Variables appear in numbered fields**: Points to the numbered columns in the message list.
- To create fixed text, click on a line and type**: Points to a line in the message list.


The interface includes a table of messages:

#	Length	Message
0	0	S t a r t 1 1 1 1 1 1 1 1 00 00 2 2
1	0	S t o p 1 1 1 1 1 1 1 1 00 00 2 2
2	1	
3	3	

Settings at the bottom include:

- Start Of Text (STX)**: Length: 1, STX: 02
- Terminators**: End Of Text (ETX) selected, Length: 1, ETX: 2F
- Message Length**: (Unselected)
- Silence: Duration (mS)**: (Unselected)
- Session Complete**: MB 2 : Session Complete
- Number of Bytes received**: MI 3 : Number of Bytes received
- Index of Received Message**: MI 4 : Index of Received Message

Message index	Identifies the incoming message.
Scan Length	This enables you to define the length of each incoming message, via the drop-down box that follows Message index #. Scan Length causes the Scan FB to use the length of a message--including header and terminator--to define whether an incoming message is legal. The length of an incoming message cannot be less than the length specified in the Scan operation. Note • This parameter overrides Start Of Text and Terminator settings. If you use Scan Length, arrange the messages in ascending order, for example, message #0 may contain 3 bytes, #1 may contain 4 bytes, #2 may contain 6 bytes, etc.
Start of Text (STX)	Check Start Of Text to use an STX parameter to indicate the beginning of a message. Length: Enter the number of bytes required by the external device's protocol to mark STX. STX Character: Click a 'byte' box and select an ASCII character.



Terminators	Select one of the terminator parameters to indicate where the message ends. Note • Use Message Length only in cases where the messages are of equal length. If the messages are of different length, use a different terminator.
-------------	--

Parameter		Function
Session Complete	MB	<p>Turns ON when: Turns ON when the PLC receives a valid message, including the message's STX and terminator, after the Linked Configuration's Function in Progress MB turns OFF.</p> <p>Turns OFF when Turns OFF whenever the Protocol Scan operation is called by the program. Turns OFF when a Reset Buffer operation runs. In your program, link the Session Complete bit to a positive transition contact, then use this condition to activate a Copy Buffer FB, as well as number of Bytes Received and Number of Received Message.</p>

Note •
 -If the PLC receives a message which is **not** defined in the Scan FB, the message is invalid. The Message Received MB remains OFF.
 -If a message in the Scan FB contains a Numeric Variable field, and the PLC receives this message with non-numerical characters in the field (except for leading spaces), the message is invalid. The Message Received MB remains OFF.
 -An example of leading spaces is if, for example, the Numeric Variable field is 4 boxes long, and the 'number' 22 is received. In this case, the Scan FB will register the number22 preceded by 2 leading spaces (_ _ 2 2).

Number of Bytes Received	MI	This holds the number of bytes currently in the buffer. It is initialized by the system when a different message is received.
Index of Received	MI	This holds the index number of the received message. It changes when another message enters the system.

Message


The value in the linked MI is valid only when the Session Complete bit in ON. During this time, the linked MI contains the index number of the last valid incoming message. Once an invalid message has been received, the first incoming character of any message causes - 1 to be written in the linked MI.

Protocol Messages

Messages can include:

• **Fixed Text**

This text does not change.




• **Variables**

These variables may be received by the PLC: Numeric, Stream, and Checksum.


• **Control Characters**

These can be added according to protocol requirements.



Example

Note that Buffer reset follows the Scan.



Note that the Scan message contains a Data Response field that is long enough to contain the contents of a register.

The diagram illustrates the mapping between a device protocol message structure and the Protocol Scan FB configuration. The device protocol message is shown as a sequence of fields: STX (02), Unit ID (01), Data response (read from Reg. #25), Reserved (0000), Checksum, and ETX (2F). The Protocol Scan FB configuration window shows the corresponding settings: STX set to 02, ETX set to 2F, and the Data response field mapped to a register address.

Scan operations containing more than one message

Note that if a Scan operation contains more than one message with identical variables that use the same format, the PLC will overwrite the variable values as they are received.

To enable the PLC to differentiate between the messages and their attached variables, include fixed text and/or control characters within the message.

The PLC can use Fixed Text to identify variables, even if the variables use identical formats.


The screenshot shows the Protocol Scan FB configuration window with two messages defined in the 'Protocol Messages' table:

#	Length	Message	Scan Length	Start	End	Reserved	Checksum	ETX
0	0	S t a r t	1	1	1	1	1	1
1	0	S t o p	1	1	1	1	1	1

Annotations explain that if received messages are different lengths, you can use Scan Length to identify incoming variables. In this case, fixed text does not have to be used -- if messages are arranged in order of descending length. Another annotation states that when these identical variables are received, the PLC will write the values into the correct registers.


Protocol: Send

Each Protocol Send operation is linked to a particular Configuration; outgoing messages are sent via the COM port selected in that Configuration. Send is located on the FBs menu.




Start of Text (STX)

Check Start Of Text to use an STX parameter to indicate the beginning of a message.
 Length: Enter the number of bytes required by the external device's protocol to mark STX.
 STX Character: **Click a 'byte' box and select an ASCII character.**




End of Text (ETX)

The ETX parameter indicates where the message ends.
 Length: Enter the number of bytes required by the external device's protocol to mark ETX.
 ETX: **Click a 'byte' box and Select an ASCII character.**



End of Message format:

- Note that the protocol may require that a checksum be either part of the message body or part of the End of Message
- If your protocol requires a checksum as part of the End of Message, click the End of Message button to define **checksum placement and format.**
- Use the options to configure the checksum according to the requirements of your particular protocol.



Send Message Number

Determines which message in the FB will be sent. In the program, store a message index numbers in the linked register. When the FB is called, message whose index number currently in the linked MI will be sent.

Advanced Button

Protocol Messages

Messages can include:

- **Fixed Text**

Fixed text must be included if there is more than one message in a Scan. This enables the PLC to identify the message.

- **Control Characters**


These can be added according to protocol requirements.


- **Variables**

These variables may be sent by the PLC: Binary, Numeric, Stream, List of Texts, Checksum, Date, and Time.

Example

Below, the Vision sends a data request to Unit 01. The request is Command 03, Read Register, and the register is Register 25.







Protocol: Copy Buffer Contents

You can copy the current contents of the buffer which receives incoming messages at any point in your application by including the Copy to Buffer operation, which is located on the FBs menu.

This operation copies whatever information is in the buffer at the time the operation is called.

- Note •** Note that copying the buffer contents is optional.
- Maximum message length is 500 characters; a message may include up to 50 variables. Note that with in the body of a message, no section--whether text or variable--may exceed 255 characters.




Copy Format

The format determines how the received bytes are copied.


- **1->1**

Select this to copy the low byte (first 8 bits) of each received register value currently in the buffer to a vector defined in the PLC.




● 2->1

Select this to copy both low and high bytes of each received register value currently in the buffer to a vector defined in the PLC. Note that this is an entire 16-bit register, and the first 2 bytes of a 32-bit register.




● 4->1

Select this to copy all 4 bytes of each 32-bit register currently in the buffer into a defined vector.



Use the Session Complete bit to activate a Copy Buffer FB, as well as record the Number of Bytes Received and Number of Received Message.





Protocol: Reset Buffer

In order to receive new messages, you must clear the communication buffer by using the Reset Buffer operation, which is located on the FBs menu.

Note •

Note that the Session Complete bit turns OFF automatically when the Reset Buffer operation runs.


- Maximum message length is 500 characters; a message may include up to 50 variables. Note that with in the body of a message, no section--whether text or variable--may exceed 255 characters.



Variables

Variables enable you to send and receive a variety of dynamic data from your process.


Variable Types: Send



The PLC sends messages via the Configuration linked to the Send operation. These are the types of variables that can be attached to an outgoing message.

• Binary text

Use this type of variable to send text based on the status of a linked bit.



• Numeric


Use a Numeric variable to send a vector of registers. You can send register values as Binary, Hex as ASCII, or Decimal ASCII. The variable field automatically adjusts to fit the size of the data to be sent.

Note •

Sending Hex as ASCII: the PLC transfers the value to ASCII, and sends it byte by byte, beginning from the most significant value.


Thus, the value 8F03BCA1 sent "Hex as ASCII" will be converted to Hex and sent as follows:

38, 46, 30, 33, 42, 43, 41, 31.



Stream

Use Stream to send a vector of registers to a target device.




Note • Values are sent in binary format, beginning from the LSB. Thus, the value 8F03BCA1 is sent as follows:

A1, BC, 3, 8F.

- In order to send floating values, select MF and the Convert 4 bytes into 1 linked element option. Note that the PLC uses the big-endian system; meaning that the most significant value in the sequence is stored at the lowest (first) storage address).


Stream Variable Format

The format determines which bytes are sent from within a register.




• **1->1**

Select this to send the low byte (first 8 bits) of each register in the vector.




• **2->1**

Select this to send both low and high bytes from each register in the vector. Note that this is an entire 16-bit register, and the first 2 bytes of a 32-bit register.



• **4->1**


Select this to send all 4 bytes of each 32-bit register in a vector.



• **List of texts**

This type of variable contains a list of numbered lines of text. The value within the linked operand 'points' to the number of a line within the list. When the operand value is equal to a particular line number, the text of that line is included in the variable.

Selecting the Define Length option enables you to make all of the text lines a uniform length, regardless of the number of characters a specific line may have. If a text line is shorter than the defined length, empty spaces will be added; if the text line is longer than the defined length, excess characters will be cut off.




• **Checksum**

Via this variable, you can calculate a checksum and attach it to a message. Use the options to configure the checksum according to the requirements of your particular protocol.


• **Date**

Use this variable to send the current date according to a selected format.



• Time

Use this variable to send the current time according to a selected format.



Variable Types: Scan

The PLC scans for messages that enter the system via the Configuration linked to the Scan operation. These are the types of variables that can be attached to an incoming message.

To correctly identify incoming variables, use either Scan Length, or include fixed text.

Notes •

Scan Length can be defined for each message via the drop-down box that follows Message index #. Scan length causes the Scan FB to use the length of a message to define whether an incoming message is legal.

This parameter overrides Start Of Text and Terminator settings. If you use Scan Length, arrange the messages in ascending order, for example, message #0 may contain 3 bytes, #1 may contain 4 bytes, #2 may contain 6 bytes, etc.

- If a Scan operation contains more than one message with identical variables that use the same format, the PLC will overwrite the variable values as they are received.

To enable the PLC to differentiate between the messages and their attached variables, include fixed text and/or control characters within the message.

The PLC can use Fixed Text to identify variables, even if the variables use identical formats.

If received messages are different lengths, you can use Scan Length to identify incoming variables. In this case, fixed text does not have to be used -- if messages are arranged in order of descending length.

When these identical variables are received, the PLC will write the values into the correct registers.

Protocol Scan Configuration:

- Start Of Text (STX): Length: 1, STX: 02
- Terminators: End Of Text (ETX) Length: 1, ETX: 2F
- Message Length: Silence: Duration (mS):
- Session Complete: MB 2: Session Complete
- Number of Bytes received: MI 3: Number of Bytes received
- Index of Received Message: MI 4: Index of Received Message

• **Numeric Receive**

Use a Numeric variable to receive a vector of registers. You can receive register values as Binary, Hex as ASCII, or Decimal ASCII.

The length of the vector that is used to store the incoming value

The start of a vector, where each register value within the vector determines the decimal point location in each received corresponding register

The number of data bytes the value in each incoming register byte length of each value

The start of the vector where the incoming value is stored.

Protocol Variables Configuration:

- Numeric Receive
- Decimal ASCII: Fixed Length
- Vector Length: 3
- Format: Decimal Point
- Length: 5
- Prefix Sign Format: Positive & Negative (+,-)
- Link: MI 8

Receive Vector

MI 8: + 1 2 3 4 (No decimal point)

MI 9: + 1 2 . 3

MI 10: + 1 . 2 3

MI 11: [] [] [] [] 1 (Decimal Point)

MI 12: [] [] [] 1 0

MI 13: [] [] 1 0 0


• **Receive Stream**

Use Stream to receive a vector of register values from an external device and copy them into a defined vector of registers within the PLC.

Note •

A vector is read either until the end of the defined vector length, or until a null character is encountered. By adding a null character to the end of the stream, you can mark the end of a data string. This can prevent other data, that might be present in a vector, from being added to the data string when the vector is read.

In order to send floating values, select MF and the Convert 4 bytes into 1 linked element option. Note that the PLC uses the big-endian system; meaning that the most significant value in the sequence is stored at the lowest (first) storage address).



• **Checksum**

Via this variable, you can process the checksum of an incoming message. Use the options to configure the checksum according to the requirements of your particular protocol.

Checksum Configuration

Use the options to configure the checksum according to the requirements of your particular protocol.

Format	Select the data representation method: Decimal ASCII, Hex as ASCII, or Binary.																																																																																																																																																															
Calculate Offset	<p>The two Offset parameters determine the delimiters of the data to be calculated for checksum.</p>																																																																																																																																																															
Calculation Type	<p>This is the type of calculation that will be performed on the data defined above.</p> <p>SUM</p> <p>Adds all of the data bytes in the selected cells into one sum.</p>																																																																																																																																																															
<table border="1"> <thead> <tr> <th rowspan="2">SUM</th> <th colspan="2">Checksum length</th> <th colspan="4">1</th> <th colspan="4">2</th> <th colspan="4">3</th> <th colspan="4">4</th> </tr> <tr> <th colspan="2">Format</th> <th>1</th><th>2</th><th>3</th><th>4</th> <th>1</th><th>2</th><th>3</th><th>4</th> <th>1</th><th>2</th><th>3</th><th>4</th> <th>1</th><th>2</th><th>3</th><th>4</th> </tr> </thead> <tbody> <tr> <td rowspan="3">Modulo 256 (100H)</td> <td>Binary (CA)</td> <td></td> <td>CA</td><td>0</td><td>CA</td><td>0</td><td>0</td><td>CA</td><td>0</td><td>0</td><td>0</td><td>CA</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>Decimal (202)</td> <td></td> <td>32</td><td>30</td><td>32</td><td>32</td><td>30</td><td>32</td><td>30</td><td>32</td><td>30</td><td>32</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>Hex as ASCII (CA)</td> <td></td> <td>41</td><td>43</td><td>41</td><td>30</td><td>43</td><td>41</td><td>30</td><td>30</td><td>43</td><td>41</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td rowspan="3">Modulo 65536 (10000H)</td> <td>Binary (1CA)</td> <td></td> <td>CA</td><td>1</td><td>CA</td><td>0</td><td>1</td><td>CA</td><td>0</td><td>0</td><td>1</td><td>CA</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>Decimal (468)</td> <td></td> <td>38</td><td>35</td><td>38</td><td>34</td><td>35</td><td>38</td><td>30</td><td>34</td><td>35</td><td>38</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>Hex as ASCII (1CA)</td> <td></td> <td>41</td><td>43</td><td>41</td><td>31</td><td>43</td><td>41</td><td>30</td><td>31</td><td>43</td><td>41</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </tbody> </table>		SUM	Checksum length		1				2				3				4				Format		1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4	Modulo 256 (100H)	Binary (CA)		CA	0	CA	0	0	CA	0	0	0	CA									Decimal (202)		32	30	32	32	30	32	30	32	30	32									Hex as ASCII (CA)		41	43	41	30	43	41	30	30	43	41									Modulo 65536 (10000H)	Binary (1CA)		CA	1	CA	0	1	CA	0	0	1	CA									Decimal (468)		38	35	38	34	35	38	30	34	35	38									Hex as ASCII (1CA)		41	43	41	31	43	41	30	31	43	41								
SUM	Checksum length		1				2				3				4																																																																																																																																																	
	Format		1	2	3	4	1	2	3	4	1	2	3	4	1	2	3	4																																																																																																																																														
Modulo 256 (100H)	Binary (CA)		CA	0	CA	0	0	CA	0	0	0	CA																																																																																																																																																				
	Decimal (202)		32	30	32	32	30	32	30	32	30	32																																																																																																																																																				
	Hex as ASCII (CA)		41	43	41	30	43	41	30	30	43	41																																																																																																																																																				
Modulo 65536 (10000H)	Binary (1CA)		CA	1	CA	0	1	CA	0	0	1	CA																																																																																																																																																				
	Decimal (468)		38	35	38	34	35	38	30	34	35	38																																																																																																																																																				
	Hex as ASCII (1CA)		41	43	41	31	43	41	30	31	43	41																																																																																																																																																				

XOR


Calculate checksum using exclusive-OR operation.

XOR	Checksum length Format	Checksum length									
		1	2	3	4						
Modulo 256 (100H)	Binary (46)	46	0	46	0	0	46	0	0	0	46
	Decimal (70)	30	37	30	30	37	30	30	30	37	30
	Hex as ASCII (46)	36	34	36	30	34	36	30	30	34	30
Modulo 65536 (10000H)	Binary (46)	46	0	46	0	0	46	0	0	0	46
	Decimal (70)	30	37	30	30	37	30	30	30	37	30
	Hex as ASCII (46)	36	34	36	30	34	36	30	30	34	30

CRC: acronym for Cyclic Redundancy Check, a procedure used in checking for errors in data transmission. A complex polynomial is used to generate a number that is based on the transmitted data. The sending device performs the calculation before transmission, and then sends the result to the receiving device. The receiving device repeats the same calculation after it receives the data. If both devices arrive at the same result, the transmission is assumed to be error-free. This is called a redundancy check because each transmission includes not only data but extra (redundant) error-checking values

CRC-16

Calculates checksum according to CRC-16.



CRC-16	Checksum length Format	1		2		3		4			
		1	2	1	2	1	2	1	2	3	4
	Binary (ABC5)	C5	AB	C5	0	AB	C5	0	0	AB	C5
	Decimal (43973)	33	37	33	39	37	33	33	39	37	33
	Hex as ASCII (ABC5)	'3'	'7'	'3'	'9'	'7'	'3'	'3'	'9'	'7'	'3'
		35	43	35	42	43	35	41	42	43	35
		'5'	'C'	'5'	'B'	'C'	'5'	'A'	'B'	'C'	'5'

CRC-CCITT

This function computes a Cyclic Redundancy Code of the 8-bit character string, using $X^{16} + X^{12} + X^5 + 1$ as the polynomial. The optional parameter seed may supply an initial value, which allows for running CRC calculations on multiple strings. If the parameter seed is not specified, a default value of 65,535 (216-1) is assumed. Four types of CRC - CCITT are available:

CRC - CCITT 1: Checksum performed on 16-bit integers, initialized to zero value.

CRC - CCITT 2:: 16-bit integer, initialized to value 0xFFFF.

CRC - CCITT 3: Checksum performed on bytes, initialized to zero value.

CRC - CCITT 4: bytes, initialized to 0xFFFF.

C code

```
//-----
word wCalcCRC_CCITT_WordRes( byte * bpBuff, word wBuffLen,
word wInitVal )
{
byte bShifter;
byte bData;
word wCarry;
word wCRC;
word wIndex;
int iIndex2;
wCRC = wInitVal;
for ( wIndex = 0; wIndex < wBuffLen; wIndex+=2 )
```

```

{
for ( iIndex2 = 1; iIndex2 > -1 ; iIndex2 --)
{
bShifter = 0x80;
bData = bpBuff[iIndex2];
do
{
wCarry = wCRC & 0x8000;
wCRC <<= 1;
if ( bData & bShifter )
{
wCRC++;
}
if ( wCarry)
{
wCRC ^= 0x1021;
}
bShifter >>= 1;
} while (bShifter);
}
bpBuff+=2;
}
return wCRC;
}
//-----
-----
word wCalcCRC_CCITT_ByteRes( byte * bpBuff, word wBuffLen,
word wInitVal )
{
byte bShifter;
byte bData;
word wCarry;
word wCRC;
wCRC = wInitVal;
while( wBuffLen--)
{
bShifter = 0x80;
bData = *bpBuff;
bpBuff++;
do
{
wCarry = wCRC & 0x8000;
wCRC <<= 1;
if ( bData & bShifter )
{
wCRC++;
}
}
if ( wCarry)
{
wCRC ^= 0x1021;
}
}
}


```

	<pre> } bShifter >>= 1; } while (bShifter); } return wCRC; } </pre> <p><u>2's complement</u> This is calculated as follows: Checksum = 0 For Stardoms to Endorses do Checksum = Checksum + Netherworlds End For Checksum = (Checksum XOR 0xFFFFFFFF) + 1</p>																
<p>Modulus method</p>	<p><u>256 (100H): 8 bits</u> Select to store the first 8 bits (low data byte) of the result into the checksum field.</p> <p><u>65536 (10000H): 16 bits</u> Select to store the entire result into the checksum field.</p>																
<p>Checksum Length</p>	<p>This determines the length of the field which will hold the calculated checksum result.</p> <p><u>Example</u> If the result is 7563 and the 16-bit modulus method is selected, the results stored in checksum fields of different lengths as follows:</p> <table border="1" data-bbox="383 1249 1125 1451"> <thead> <tr> <th></th> <th><u>Length: 1</u></th> <th><u>Length: 2</u></th> <th><u>Length: 3</u></th> </tr> </thead> <tbody> <tr> <td>Binary</td> <td>63</td> <td>7563</td> <td>0075, 63</td> </tr> <tr> <td>Decimal</td> <td>33</td> <td>36, 33</td> <td>35, 36, 33</td> </tr> <tr> <td>Hex as ASCII (7563 = 1D8B)</td> <td>42</td> <td>38, 42</td> <td>44, 38, 42</td> </tr> </tbody> </table>		<u>Length: 1</u>	<u>Length: 2</u>	<u>Length: 3</u>	Binary	63	7563	0075, 63	Decimal	33	36, 33	35, 36, 33	Hex as ASCII (7563 = 1D8B)	42	38, 42	44, 38, 42
	<u>Length: 1</u>	<u>Length: 2</u>	<u>Length: 3</u>														
Binary	63	7563	0075, 63														
Decimal	33	36, 33	35, 36, 33														
Hex as ASCII (7563 = 1D8B)	42	38, 42	44, 38, 42														
<p>Advanced: Set Limits</p>	<p>From Value and To Value determine a range for the checksum result ;if the final value falls within these limits, the function can automatically add a set value to the calculated checksum.</p>																

Protocol Status Operands and Messages

The Status Operands show the state of Protocol communications.

All of the Status operands linked to Protocol FBs should be assigned Power-up Values; bits should be reset, and registers initialized to 0.



Protocol Operation Status Operands

When you place a Protocol Configuration your application, the linked operands indicate the status of Protocol operations.

<p>Function in Progress Shows status of Protocol Configuration</p>	<p>MB</p>	<p>Turns ON when: Configuration begins When Send or Scan begins Note • Messages cannot be sent while this MB is ON. Use an indirect contact for this MB as an activating condition for Send operations.</p>	<p>Turns OFF when The Protocol: Configuration is finished. When Scan is complete, when the PLC receives the message's STX and terminator. The Status Message indication changes</p>																																				
<p>Status Messages</p>	<p>MI</p>	<p>Automatically initialized to 0 when a Protocol operation is activated. Updated at the end of each attempt to communicate via the Protocol Configuration. Indicates status of Protocol communications, according to the table below. Note that the current value always shows the most recent status.</p> <table border="0"> <thead> <tr> <th>Value</th> <th>Error Message</th> <th>Indication</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No Error</td> <td>Operations successful</td> </tr> <tr> <td>1</td> <td>Send: General Error</td> <td>Indicates an unknown system error.</td> </tr> <tr> <td>2</td> <td>Send: COM Port busy</td> <td>The COM port that is selected in the active Protocol Configuration cannot currently be accessed.</td> </tr> <tr> <td>3</td> <td>Send: Invalid Message Index</td> <td>The message that is referenced in the Send operation does not exist.</td> </tr> <tr> <td>4</td> <td>Send: Invalid Operand Type</td> <td>The message references an operand type that does not exist in the system.</td> </tr> <tr> <td>5</td> <td>Send: Invalid Operand Address</td> <td>The message references an operand address that does not exist in the system.</td> </tr> <tr> <td>6</td> <td>Send: Data Overflow</td> <td>The message data exceeds 512 bytes.</td> </tr> <tr> <td>7</td> <td>Send: Format Error</td> <td>The message contains variable fields that are not long enough for the attached variable data.</td> </tr> <tr> <td>257</td> <td>Receive: General Error</td> <td>Indicates an unknown system error.</td> </tr> <tr> <td>258</td> <td>Receive: Invalid message</td> <td>The received message does not exist in the system.</td> </tr> <tr> <td>259</td> <td>Receive: Checksum Error</td> <td>The message may have been corrupted during transmission.</td> </tr> </tbody> </table>		Value	Error Message	Indication	0	No Error	Operations successful	1	Send: General Error	Indicates an unknown system error.	2	Send: COM Port busy	The COM port that is selected in the active Protocol Configuration cannot currently be accessed.	3	Send: Invalid Message Index	The message that is referenced in the Send operation does not exist.	4	Send: Invalid Operand Type	The message references an operand type that does not exist in the system.	5	Send: Invalid Operand Address	The message references an operand address that does not exist in the system.	6	Send: Data Overflow	The message data exceeds 512 bytes.	7	Send: Format Error	The message contains variable fields that are not long enough for the attached variable data.	257	Receive: General Error	Indicates an unknown system error.	258	Receive: Invalid message	The received message does not exist in the system.	259	Receive: Checksum Error	The message may have been corrupted during transmission.
Value	Error Message	Indication																																					
0	No Error	Operations successful																																					
1	Send: General Error	Indicates an unknown system error.																																					
2	Send: COM Port busy	The COM port that is selected in the active Protocol Configuration cannot currently be accessed.																																					
3	Send: Invalid Message Index	The message that is referenced in the Send operation does not exist.																																					
4	Send: Invalid Operand Type	The message references an operand type that does not exist in the system.																																					
5	Send: Invalid Operand Address	The message references an operand address that does not exist in the system.																																					
6	Send: Data Overflow	The message data exceeds 512 bytes.																																					
7	Send: Format Error	The message contains variable fields that are not long enough for the attached variable data.																																					
257	Receive: General Error	Indicates an unknown system error.																																					
258	Receive: Invalid message	The received message does not exist in the system.																																					
259	Receive: Checksum Error	The message may have been corrupted during transmission.																																					

Examples

Basic Example

How does the Protocol FB communicate data between Vision controllers and other devices?

A device, such as a magnetic card reader, may use its own, proprietary protocol. If you know the protocol's structure, you can use the Protocol FB to structure messages accordingly. This enables a Vision controller to exchange data with the device using the device's own protocol.

The example below shows how a Vision controller can, via COM port 2, read Register 25 within a device that has the ID number of 01. The device uses the simple protocol shown below.

Device Protocol


Parameter name	Length (bytes)	Value	Comments
STX	1	STX 02(hex)	All messages must begin with the STX character
Unit ID	2	ID# range= 0-99	All messages must contain the ID number of the device that the controller is communicating with
Command	2	03=Read Register 04=Read Bit 05=Write Register	Commands are embedded in Data Request messages.
Data (Request)	4		Vision to Device
Data (Response)	8		Device to Vision
Reserved	2	2 Null characters=00,00	These characters must be included in all messages.
Checksum	2	Sum 8	
ETX	1	/ backslash) 2F(hex)	All messages must end with the '/'character

Message Structure: Data Request (Vision to device)

The device can only receive request messages that are structured as shown below.




Checksum



Message Structure: Data Response (device to Vision)

The device sends data in messages that are structured as shown below.




Protocol Ladder Requirements

In order to enable a Vision controller to request and receive data from a device, the controller's Ladder application must contain:

- A COM Init FB to initialize the serial port that will be linked to the device.
- A Protocol Configuration FB set to use the serial port.
- A Protocol Send FB, which enables the controller to send data request messages to the device.
- A Protocol Scan FB, which enables the controller to receive data response messages from the device. Note that in order to receive new messages, you **must clear the communication buffer after each message by using the Reset Buffer FB.**

COM Init and Configuration



Since COM Port 2 is connected to the device, the application initializes and configures COM 2 at Power-up.



Send: Data Request

The application requests data via the Protocol Send FB. The Send FB enables you to structure messages that conform to any protocol's requirements.

Below, the Vision sends a data request to Unit 01. The request is Command 03, Read Register, and the register is Register 25.




Scan: Receiving Messages

A Protocol Scan FB contains messages. Activating the Scan causes the Vision to check if it has received any of the messages contained within the Scan FB. Note that the controller can only receive messages that are defined in the Scan FB.

Note • In order to receive new messages, you **must** clear the communication buffer by using the Reset Buffer operation. You can save the contents of the buffer at any time by using the Copy Buffer operation.

Below, the application enables the Vision to receive a response to Command 03. Note that Buffer reset follows the Scan.



Note that the Scan message contains a Data Response field that is long enough to contain the contents of a register.

Advanced Mitsubishi Frequency Converter

The information below is intended to accompany the sample application Mitsubishi.vlp. This application shows how to exchange data between networked Mitsubishi frequency converters and a Vision controller.

Data exchange is performed using the Mitsubishi communication protocol, via VisiLogic's communication Protocol FB. By modifying the FB's parameters, you can exchange data between Vision controllers and external devices using many different protocols.

About the Mitsubishi Protocol

The Mitsubishi manual for the converter used in the example may be found by accessing the Mitsubishi site at:

http://www.meau.com/eprise/main/Web_Site_Pages/Public/Documents_Downloads/P-DD-Technical-Manuals,

entering SH(NA)3197-B under **Title**, and then pressing **Search**. Note that this manual is in .pdf format and requires you to have Adobe's Acrobat Reader installed on your system.

The manual includes complete protocol requirements. The elements used in the sample application to implement the Mitsubishi protocol are presented below.

Read Commands

Command	Data No.	Descriptions	Frame Length
01	80-80E	Data Value and processing information of status display	12
02	00	Current alarm number	4
	90	Absolute position of motor end in pulse unit	8
	91	Absolute position in command unit	8
05	00-35	Current value of corresponding parameters (decimal numbers in data number correspond to the parameter numbers)	8
33	10-15	Alarm number	4
	20-15	Alarm Time	8
35	80-80E	Data value and processing information of status display when alarm occurs	12
6D	Register number	Register amount (single register)	8
6E	Register number	Register amount (double register)	8

Write

Command	Data No.	Descriptions	Setting Range	Frame Length
81	00	Status Display clear	1EA5	4
82	00	Alarm reset	1EA5	4
84	00-35	Write to corresponding parameters (the decimal number in the data number corresponds to parameter number)	Areas according to parameter #	8
92	60	Communication device input signal		8
B8	00-3F	Program data		8
B9	Register number	Register amount (single register)		8
BA	Register number	Register amount (double register)		8

Station ID

Each converter is assigned a station number. Station numbers are transmitted in hexadecimal.

ID No.	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
JIS #	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
ID No.	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
JIS #	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V

Protocol message structure

Send

The FB shown below is located in Net 8 within subroutine: Send command to Mitsubishi. Note how the messages in the Protocol Send FB are configured to conform to the Mitsubishi message structure.

The screenshot shows the 'Protocol Send' configuration window. At the top, a diagram illustrates the Mitsubishi message structure: SOH (ASCII character 01), ID #, Command, STX, Data Number, Data, ETX, and Check-sum. Callouts explain each field: SOH marks the beginning of a message; ID # is transmitted as hexadecimal; Command # is determined by the command; STX(02) precedes the data request; Data Number is the type of data transmitted/requested; ETX follows the data; and ETX determines the checksum format and placement. The configuration window below shows 'Start Of Text (STX)' set to 01 and 'End Of Text (ETX)' set to 03, with 'End Of Message' set to 'ETX_Checksum'. A table of data fields is also visible, with values corresponding to the callouts.

Scan

The FB shown below is located in Net 3 within subroutine: Check answer after sending. Note how the messages in the Protocol Send FB are created to conform to the Mitsubishi message structure.

Error codes

The Mitsubishi protocol uses an error code to determine if data is transmitted correctly.

When a converter receives a message, it replies by sending a message to the controller, according to the table below.

Error Code		
Normal	Alarm	Description
A	a	Data transmitted properly
B	b	Parity error
C	c	Checksum error
D	d	Character error
E	e	Command error
F	f	Data # error

The image shows a software interface for configuring a protocol. At the top, a diagram illustrates the message structure: S T X | ID # | Error Code | Data Number | Data | E T X | Check-sum. Below this, a 'Protocol messages' table shows a sequence of bytes: 0: 0 0 2, 1: 1 A 0 0 2 2, 2: 1 b, 3: 1 B. The configuration window below has several sections: 'Start Of Text (STX)' with a length of 1 and a value of 02; 'Terminators' with 'End Of Text (ETX)' selected, a length of 1, and a value of 03; and 'End Of Message' set to 'ETX_Checksum'. Annotations in green boxes explain these fields: 'ASCII character STX(02) marks the beginning of a message' points to the STX field; 'Station ID #, received as hexadecimal' points to the '1 A' in the message table; 'Error Code Upper-case=Normal Lower-case=Alarm' points to the '0 0' in the message table; 'Fixed text' points to the '0 0 2 2' in the message table; 'Data: the Alarm #' points to the '1 b' in the message table; 'ETX follows the data' points to the '03' in the ETX field; and 'End of Message determines checksum format and placement. Options are selected that conform to the protocol's requirements.' points to the 'End Of Message' dropdown.

#	0	1	2	3
	0 0 2	1 A 0 0 2 2	1 b	1 B

Start Of Text (STX)
Length: 1
STX: 02

Terminators
 End Of Text (ETX)
Length: 1
ETX: 03
End Of Message: ETX_Checksum

Session Complete: MB 1003 : Session Complete
Number of Bytes received: MI 1019 : Number of Bytes received
Number of received Message: MI 1020 : Number of received Message

OK Cancel Help

Protocol FB (TCP/IP)

Protocol FB (TCP/IP) Overview

Use the Communication Protocol TCP/IP operations located on the FBs menu to enable your controller to exchange data with TCP/IP-enabled devices, such as frequency converters, bar-code readers, and printers. The controller must comprise an Ethernet card. Communication Protocol TCP/IP operations are located on the FBs menu.

You can find general information about Ethernet, IP addressing, sockets, and ports in the topic About Ethernet.


Specific information on implementing Ethernet is provided in the topic Using Ethernet.

Protocol TCP/IP operations are located on the FBs menu.

For more information regarding Protocol operations, refer to the topics below.


Example: TCP/IP Master

The nets below show the elements that are required by a master PLC. Note that the master application requires Socket Init and a TCP/IP Connect function, and that when you wish to terminate a session, you must include a Close Socket function.



Example: TCP/IP Slave

The nets below show the basic conditions enabling a TCP/ IP slave to receive messages.



FB Operations**Configuration****Scan****Send**

To learn how the Scan operation works check the Protocol FB chapter. This chapter also includes information regarding Variables, Status and Error Messages.


Protocol TCP/IP: Configuration


You create messages and attach variable data in Protocol TCP/IP Send and Scan operations. Each operation is linked to a Configuration. When a Send operation is called in your program, the Configuration determines which socket is used for outgoing messages; when a Scan operation is activated, the PLC monitors that socket for incoming messages.

Note • The Configuration should be placed in the Main Routine, before any other FB operations. If the configuration is not active, Protocol operations will not be processed.

- Before you place this FB in your Ladder, your application must include:
 - a Set PLC Name function
 - a TCP/IP Card Init to configure the Ethernet port
 - a Socket Init function, initializing a socket to TCP
 - TCP Connect and TCP Close functions

- The Protocol FB does not support UDP. You can use Socket 0, if you change it to TCP in the Socket Init Function. Note that after you make this change, the default text remains UDP, even though the socket is initialized to TCP.





Parameter		Function
Name		Identifies the configuration. You use the name to link Protocol Send and Scan operations to a configuration.
(IN) Socket		Determines which socket is used for communicating the messages.
(OUT) Status	MI	If errors occur when the Configuration is used for a Send or Scan operation, the value of the linked MI indicates which error has occurred.
Addresses	MI or Constant	Provides the list of device's IP addresses for Scan operations.


Protocol TCP/IP: Scan

A Scan operation contains messages. Activating the Scan causes the PLC to check if it has received any of the messages contained within the Scan. The PLC can only receive messages that are contained in a Scan FB.

Each Protocol Scan operation is linked to a particular Protocol Configuration. The Scan only registers messages that are received via the Socket defined in that Configuration.

Scan is located under FBs>Protocol TCP/IP.

Note •	Maximum message length is 500 characters; a message may include up to 50 variables. Note that, no section of a message--whether text or variable--may exceed 255 characters.
•	A message that is received overwrites a previously received message.
•	The PLC cannot receive more than 1 message per program scan; this means that if the PLC receiving messages has a scan cycle of 1 second, the sending device should not send more than 1 message per second.



Message index	Identifies the incoming message.
Scan Length	This enables you to define the length of each incoming message, via the drop-down box that follows Message index #. Scan Length causes the Scan FB to use the length of a message to define whether an incoming message is legal. The length of an incoming message cannot be less than the length specified in the Scan operation. Note • If you use Scan Length, arrange the messages in ascending order, for example, message #0

may contain 3 bytes, #1 may contain 4 bytes, #2 may contain 6 bytes, etc.

Parameter		Function	
Message Received	MB	<p>Turns ON when: Turns ON when the PLC receives a valid message.</p>	<p>Turns OFF when Turns OFF whenever the Scan operation is called by the program. In your program, link the Message Received bit to a positive contact, then use this condition to activate Copy operations, such as for the message variables, Number of Bytes Received and Number of Received Message.</p>


Note •

-If the PLC receives a message which is **not** defined in the Scan FB, the message is invalid. The Message Received MB remains OFF.

-If a message in the Scan FB contains a Numeric Variable field, and the PLC receives this message with non-numerical characters in the field (except for leading spaces), the message is invalid. The Message Received MB remains OFF.

-An example of leading spaces is if, for example, the Numeric Variable field is 4 boxes long, and the 'number' 22 is received. In this case, the Scan FB will register the number22 preceded by 2 leading spaces (_ _ 2 2).

Number of Bytes Received	MI	This holds the number of message bytes. It is initialized by the system when a different message is received.
Index of Received Message	MI	<p>This holds the index number of the received message. It changes when another message enters the system.</p> <p>The value in the linked MI is valid only when the Session Complete bit in ON. During this time, the linked MI contains the index number of the last valid incoming message.</p> <p>Once an invalid message has been received, the first incoming character of any message causes - 1 to be written in the linked MI.</p>
Index of IP	MI	<p>When you create the Configuration, you create a list of IP addresses of the devices in your TCP/IP application. Each IP is assigned an index number.</p> <p>This list is used by the Scan operation.</p> <p>When a message is received, the IP and exit port of the sending device is written to a vector of 5 MIs. The first 4 contain the IP address, and the fifth will contain the port number.</p> <p>If the IP of the sending device matches an IP in the Configuration list, the index of the IP is written to this MI.</p> <p>Note • If the IP of the sending device is not in the Configuration list, the PLC receives the data, but the value -1 is written to the MI.</p>



Note • If the PLC receives a message from a device with an IP that is not in the Configuuse Scan Length, arrange the messages in ascending order, for example, message #0 may contain 3 bytes, #1 may contain 4 bytes, #2

IP Start of Vector, 5 Integers

MI


This is the start address of a vector of 5 MIs. When a message is received, the IP and exit port of the sending device is written to this vector The first 4 contain the IP address, and the fifth will contain the port number.

Protocol Messages

Messages can include:

- **Fixed Text**

This text does not change.




- **Variables**

These variables may be received by the PLC: Numeric, Stream, and Checksum.

- **Control Characters**

These can be added according to protocol requirements.




Scan operations containing more than one message

Note that if a Scan operation contains more than one message with identical variables that use the same format, the PLC will overwrite the variable values as they are received.

To enable the PLC to differentiate between the messages and their attached variables, include fixed text and/or control characters within the message.


The PLC can use Fixed Text to identify variables, even if the variables use identical formats.

If received messages are different lengths, you can use Scan Length to identify incoming variables. In this case, fixed text does not have to be used -- if messages are arranged in order of descending length.



Protocol TCP/IP: Send

Each Send operation is linked to a particular Configuration; outgoing messages are sent via the COM port selected in that Configuration. Send is located on the FBs menu.



Send Message Number

Determines which message in the FB will be sent. In the program, store a message index numbers in the linked register. When the FB is called, message whose index number currently in the linked MI will be sent.

Protocol Messages

Messages can include:

- **Fixed Text**

Fixed text must be included if there is more than one message in a Scan. This enables the PLC to identify the message.

- **Control Characters**

These can be added according to protocol requirements.


- **Variables**

These variables may be sent by the PLC: Binary, Numeric, Stream, List of Texts, Checksum, Date, and Time.

Variables

Variables enable you to send and receive a variety of dynamic data from your process.


Variable Types: Send



The PLC sends messages via the Configuration linked to the Send operation. These are the types of variables that can be attached to an outgoing message.

- **Binary text**

Use this type of variable to send text based on the status of a linked bit.




- **Numeric**

Use a Numeric variable to send a vector of registers. You can send register values as Binary, Hex as ASCII, or Decimal ASCII. The variable field automatically adjusts to fit the size of the data to be sent.


Note •

Sending Hex as ASCII: the PLC transfers the value to ASCII, and sends it byte by byte, beginning from the most significant value. Thus, the value 8F03BCA1 sent "Hex as ASCII" will be converted to Hex and sent as follows:
38, 46, 30, 33, 42, 43, 41, 31.



• **Stream**

Use Stream to send a vector of registers to a target device.



Note •


Values are sent in binary format, beginning from the LSB. Thus, the value 8F03BCA1 is sent as follows:

A1, BC, 3, 8F.

- In order to send floating values, select MF and the Convert 4 bytes into 1 linked element option. Note that the PLC uses the big-endian system; meaning that the most significant value in the sequence is stored at the lowest (first) storage address).


Stream Variable Format

The format determines which bytes are sent from within a register.




● 1->1

Select this to send the low byte (first 8 bits) of each register in the vector.




● 2->1

Select this to send both low and high bytes from each register in the vector. Note that this is an entire 16-bit register, and the first 2 bytes of a 32-bit register.



● 4->1


Select this to send all 4 bytes of each 32-bit register in a vector.



• List of texts

This type of variable contains a list of numbered lines of text. The value within the linked operand 'points' to the number of a line within the list. When the operand value is equal to a particular line number, the text of that line is included in the variable.

Selecting the Define Length option enables you to make all of the text lines a uniform length, regardless of the number of characters a specific line may have. If a text line is shorter than the defined length, empty spaces will be added; if the text line is longer than the defined length, excess characters will be cut off.




• Checksum

Via this variable, you can calculate a checksum and attach it to a message. Use the options to configure the checksum according to the requirements of your particular protocol.


• Date

Use this variable to send the current date according to a selected format.



• **Time**

Use this variable to send the current time according to a selected format.



Variable Types: Scan

The PLC scans for messages that enter the system via the Configuration linked to the Scan operation. These are the types of variables that can be attached to an incoming message.

To correctly identify incoming variables, use either Scan Length, or include fixed text.

Notes •

Scan Length can be defined for each message via the drop-down box that follows Message index #. Scan length causes the Scan FB to use the length of a message to define whether an incoming message is legal.


This parameter overrides Start Of Text and Terminator settings. If you use Scan Length, arrange the messages in ascending order, for example, message #0 may contain 3 bytes, #1 may contain 4 bytes, #2 may contain 6 bytes, etc.

- If a Scan operation contains more than one message with identical variables that use the same format, the PLC will overwrite the variable values as they are received.

To enable the PLC to differentiate between the messages and their attached variables, include fixed text and/or control characters within the message.

The PLC can use Fixed Text to identify variables, even if the variables use identical formats.

If received messages are different lengths, you can use Scan Length to identify incoming variables. In this case, fixed text does not have to be used -- if messages are arranged in order of descending length.



When these identical variables are received, the PLC will write the values into the correct registers.

• Numeric Receive

Use a Numeric variable to receive a vector of registers. You can receive register values as Binary, Hex as ASCII, or Decimal ASCII.

The length of the vector that is used to store the incoming value

The start of a vector, where each register value within the vector determines the decimal point location in each received corresponding register

The number of data bytes the value in each incoming register byte length of each value

The start of the vector where the incoming value is stored.

Receive Vector

Decimal Point

MI 8	+ 1 2 3 4	MI 9	+ 1 2 . 3	MI 10	+ 1 . 2 3
	No decimal point				
MI 11		MI 12		MI 13	
			1 0		1 0 0


• Receive Stream

Use Stream to receive a vector of register values from an external device and copy them into a defined vector of registers within the PLC.

Note • A vector is read either until the end of the defined vector length, or until a null character is encountered. By adding a null character to the end of the stream, you can mark the end of a data string. This

can prevent other data, that might be present in a vector, from being added to the data string when the vector is read.

In order to send floating values, select MF and the Convert 4 bytes into 1 linked element option. Note that the PLC uses the big-endian system; meaning that the most significant value in the sequence is stored at the lowest (first) storage address).




• **Checksum**

Via this variable, you can process the checksum of an incoming message. Use the options to configure the checksum according to the requirements of your particular protocol.

Protocol TCP/IP Status Messages

The MI Status Operand in the Configuration shows the state of Protocol communications.



Protocol Operation Status Operands

When you place a Protocol Configuration your application, the linked operands indicate the status of Protocol operations.

Status Messages	MI	Automatically initialized to 0 when an operation is activated. Updated at the end of each attempt to communicate via the Configuration. Indicates status of communications, according to the table below. Note that the current value always shows the most recent status.
-----------------	----	---

Value	Error Message	Indication
0	No Error	Operations successful
2	General Configuration Error	Indicates an unknown system error.
257	Send: General Error	Indicates an unknown system error.
259	Send: Invalid Message Index	The message that is referenced in the Send operation does not exist.
260	Send: Invalid Operand Type	The message references an operand type that does not exist in the system.
261	Send: Invalid Operand Address	The message references an operand address that does not exist in the system.
262	Send: Data Overflow	The message data exceeds 512 bytes.
263	Send: Format Error	The message contains variable fields that are not long enough for the


		attached variable data.
264	Send: TCP/IP General Error	Check the TCP/ IP SIs
513	Receive: General Error	Indicates an unknown system error.
514	Receive: Invalid message	The received message does not exist in the system.
515	Receive: Checksum Error	The message may have been corrupted during transmission.

Note •	To automatically reconnect a lost Ethernet connection, turn SB 168 Automatically reconnect (keep alive) ON at power-up.
•	To enable PLC to disconnect when the Ethernet connection is inactive for a period of time, assign timeout values in SIs 103 -106
•	To enable a PLC attempt to reconnect when there is no communication from the connected device for a period of time, assign timeout values in SIs 107 -110

PID

PID Overview

The PID FB enables you to use system feedback to continuously control a dynamic process. The purpose of PID control is to keep a process running as close as possible to a desired Set Point. VisiLogic's PID FB includes auto-tune.

 In order to ensure proper PID function, you should use Autotune.

During the Autotune process, the PID function collects certain essential data. Unitronics' proprietary PID algorithm uses this data to run smooth, accurate PID.

Note that you can use the Read Control Components FB in conjunction with the PID Server utility to create a data file to send to support@unitronics in the event that you require technical support for PID applications. Information on how to create a data file is in the PID Server help file.

FB Operations

PID Configuration

Run Auto Tune

Run PID

Pause Integral & Derivative Calculation

Error Integral

Read Control Components

PID Autotune

Auto-tuning loops enables the system to set the parameters for PID.

The picture below shows the elements of a basic PID application with Auto-tune.

PID Configuration

To place a PID Configuration:

1. Select PID Configuration from the FBs menu, then place the function in the net; the PID parameter box opens.
2. The Select Operand and Address box opens; prompting you to link operands to the PID parameters.


Note •

To enable PID, values must be provided for:

- Set Point
- Input Range:PV Low Limit & PV High Limit
- Output Range:CV Low Limit & CV High Limit

These values are used to Auto-tune the loop.

After Auto-tune runs, the P, I, D and Sample Time values are automatically written to the Configuration parameters.



PID Function Parameters

Parameters: Inputs	Type	Function
SP: Set Point	MI	SP is the target value for the process. In a heating system, this is the temperature value set for the system. Note that the Set Point and Process value must be given in the same type of units (degrees Celsius, bars, meters per second, etc.)
PV: Process Value	MI	PV is the feedback from the process. PV is output from the process and input to the PID function. In a heating system, the temperature measured by a temperature sensor provides the PV.
Kp: Proportional Band	MI	Use this parameter to define the proportional band, in units of 0.1%. The proportional band is a percentage of the total Process Value (PV). It is a range defined around the Set Point. When the PV is within this range, the PID function is active.
Ti: Integral Time	MI	Use this parameter to define the integral time, in units of 1 second. Integral action responds to the rate of change in the controller's CV output relative to the change in Error. The integral

		time you set is the amount of time, as calculated by the controller, required to bring the process to Set Point. Note that integral (wind up) error may be initialized via the Force Error Integral operation.
Td: Derivative Time	MI	Use this parameter to define the derivative time, in units of 1 second. Derivative action responds to the rate and direction of change in the Error. This means that a fast change in error causes a strong response from the controller. The derivative action 'anticipates' the PV's value in relation to the Set Point and adjusts the CV accordingly, thus shortening the PID function's response time.
ST: Sample Time	MI	Use this parameter to define the intervals between PID function updates, in units of 10mSecs.
Action: 0: Heat, 1: Cool	MB	Select Off to activate Reverse Action (control type = heating), ON to activate Direct Action (control type = cooling).
Input Range: Process Value Low limit	MI	Use this parameter to define the lower limit for the Process Value.
Input Range: Process Value High limit	MI	Use this parameter to define the upper limit for the Process Value.
Output Range: Control Value Low limit	MI	Use this parameter to define the lower limit for the Control Value.
Output Range: Control Value High limit	MI	Use this parameter to define the upper limit for the Control Value.

Parameters: Outputs	Type	Function																						
CV: Control Value	MI	CV is the output from the PID function. CV is output from the PID function and input to the process. Note that this output signal may be an analog or time-proportional variable value.																						
Status Messages Initialized to 0 when Configuration is activated.	MI	<table border="0"> <tr> <td>Value</td> <td>Message</td> </tr> <tr> <td>>=0</td> <td>FB status OK</td> </tr> <tr> <td>< 0</td> <td></td> </tr> <tr> <td>-1</td> <td>Proportion band zero.</td> </tr> <tr> <td>-2</td> <td>Input range is invalid (PV input).</td> </tr> <tr> <td>-3</td> <td>Output range is invalid (CV output).</td> </tr> <tr> <td>-4</td> <td>Integral has reached maximum of 100,000. PID will not allow the Integral value to increase any further.</td> </tr> <tr> <td>-5</td> <td>Error in Auto Tune vector addresses, ex., the vector exceeds the final address in the MI data type.</td> </tr> <tr> <td>-6</td> <td>Set Point less then Input low range or Set Point more then Input high range.</td> </tr> <tr> <td>-7 to-10</td> <td>Auto tune error.</td> </tr> <tr> <td>-11</td> <td>Noise is more then 5% of Input Range.</td> </tr> </table>	Value	Message	>=0	FB status OK	< 0		-1	Proportion band zero.	-2	Input range is invalid (PV input).	-3	Output range is invalid (CV output).	-4	Integral has reached maximum of 100,000. PID will not allow the Integral value to increase any further.	-5	Error in Auto Tune vector addresses, ex., the vector exceeds the final address in the MI data type.	-6	Set Point less then Input low range or Set Point more then Input high range.	-7 to-10	Auto tune error.	-11	Noise is more then 5% of Input Range.
Value	Message																							
>=0	FB status OK																							
< 0																								
-1	Proportion band zero.																							
-2	Input range is invalid (PV input).																							
-3	Output range is invalid (CV output).																							
-4	Integral has reached maximum of 100,000. PID will not allow the Integral value to increase any further.																							
-5	Error in Auto Tune vector addresses, ex., the vector exceeds the final address in the MI data type.																							
-6	Set Point less then Input low range or Set Point more then Input high range.																							
-7 to-10	Auto tune error.																							
-11	Noise is more then 5% of Input Range.																							
Auto-tune parameters	MI	The start of a 32 MI-long Auto-tune vector that contains the Auto-tuned parameters.																						

Note • | Note that, once you have run Auto-tune, you can back up the P, I,

and D values, the sample time (ST), and the 32 MI-long Auto-tune vector into a Data Table. You can then transfer these values to another Vision controlling an identical system, in order to run PID without tuning the loop.

Run Auto-Tune

The Run Auto-tune operation uses the Configuration's parameters:



- Set Point
- Input Range: PV Low Limit & PV High Limit
- Output Range: CV Low Limit & CV High Limit

These values are used to Auto-tune the loop. After Auto-tune is run, the Auto-tune MB turns ON, and all of the Auto-tune parameters are written into the Autotune Parameter MI vector that is defined in the PID Configuration.

Note

Note that, once you have run Auto-tune, you can back up the P, I, and D values, the sample time (ST), and the 32 MI-long Auto-tune vector into a Data Table. You can then transfer these values to another Vision controlling an identical system, in order to run PID without tuning the loop.

In order to Auto-tune the loop, the PID Run operation must be suspended.




Auto-tune Parameters

Parameters: Inputs	Type	Function
Stage	#	The number of Stages aids the system to determine accurate Auto-tune parameters. The Default is 3. The higher the number of stages, the longer the Auto-tune time, however choosing a lower Stage may result in less accurate Auto-tune parameters.
Auto-tune Done	MB	After Auto-tune is run, the Auto-tune MB turns ON, and all of the Auto-tune parameters are written into the Auto-tune Parameter MI vector that is defined in the PID Configuration.

-


Run PID

In order to run a PID loop, the Run operation must be included in the application following the PID Configuration. In order to Auto-tune the loop, the PID Run must be suspended.



Pause Integral & Derivative Calculation


If conditions require, you can suspend this value and prevent it from changing. This may prove useful, for example, in a temperature application, when an opened oven door can cause a temporary temperature drop.



Read Control Components

This function enables you to scale down very large PID control values to smaller, more logical values. The current functions factors the PID control values by a value in an MI, then stores the values in the output MIs.

Use this function in conjunction with the PID Server utility to create a data file to send to support@unitronics in the event that you require technical support for PID applications.



Parameters	Type	Function
Resolution Factor	#	This is the value used to factor the PID control values.
Control Value: Proportional Output	MI	Stores the factored Proportional Output.
Control Value: Integral Output	MI	Stores the factored Integral Output.
Control Value: Derivative Output	MI	Stores the factored Derivative Output.


-

Error Integral

You can read and write to the Integral Value.


Read Error Integral

Use this operation to store the current error in the linked ML.



Force Error Integral

Use this to initialize or change the error value while the application is running. You can erase wind up error by writing '0' into the linked register.




General Background: How PID Works


The PID function uses system feedback to continuously control a dynamic process. The purpose of PID control is to keep a process running as close as possible to a desired Set Point.

About PID and Process Control

A common type of control is On-Off control. Many heating systems work on this principle. The heater is off when the temperature is above the Set Point, and turns on when the temperature is below the Set Point. The lag in the system response time causes the temperature to overshoot and oscillate around the Set Point.



PID control enables you to minimize overshoot and damp the resulting oscillations.




PID enables your controller to automatically regulate your process by:

Taking the output signal from the process, called the Process Variable (PV),

Comparing this output value with the process Set Point. The difference between the output Process Variable and the Set Point is called the Error signal.

Using the Error signal to regulate the controller output signal, called the Control Variable (CV), to keep the process running at the Set Point. Note that this output signal may be an analog or time-proportional variable value.

In the figure below, a system is regulated according to temperature.



- A steam valve releases heat into the system.
- A temperature sensor outputs a temperature value, the PV.
- This PV enters the controller. The PID function compares the temperature value with the Set Point to calculate the Error signal.
- The PID function regulates the controller output, the CV. This output controls the steam valve, causing it to vary the release of steam and run the process at the desired Set Point.

Inside the PID Function


The PID function is based on 3 actions, Proportional, Integral, and Derivative. The PID output is the combined output of all 3 actions.

All of the PID functions are activated by changes in the process Error, the difference between the Process Value and the process Set Point value ($E = SP - PV$).

Proportional Band

The proportional band is a range defined around the Set Point. It is expressed as a percentage of the total Process Value (PV). When the PV is within this range, the PID function is active.

Note • The proportional band may exceed 100%. In this case, PID control is applied over the entire system range.



- The Process Value (PV) of this system is 0°-100°, a total range of 100°.
- The proportional band is set at 10%. This means that the range of the proportional band is 40°-60°.
- When the Temperature is outside of the proportional band, the PID function is not active.

Proportional Action

Proportional action begins after the PV enters the proportional band; at this point, the Error is 100%. The action outputs a value that is in **direct linear proportion to the size of the Error value.**

A broad proportional band causes a more gradual initial response from the controller. Typically, Set Point overshoot is low; but when the system stabilizes, oscillations around the Set Point tend to be greater.


A narrow band causes a rapid response that typically overshoots the Set Point by a greater margin. However, the system does tend to stabilize closer to the set point. Note that a proportional band set at 0.0% actually forces the controller into On-Off mode.

The drawback of proportional control is that it can cause the system to stabilize below set point. This occurs because when the system is at set point, Error is zero and the control value output is therefore pegged at zero as well.

The majority of systems require continuous power to run at set point. This is achieved by integrating integral and derivative control into the system.

Direct and Reverse Action

Direct action causes the output to change in the same direction as the change in Error, meaning that a positive change in Error causes a positive change in the proportional band's output. Reverse action creates an inverse change in the output, meaning that a positive change in Error causes a negative change in output.




Integral Action

Integral action responds to the rate of change in the controller's CV output relative to the change in Error. The integral time you set is the amount of time, as calculated by the controller, required to bring the process to Set Point. Note that if you set a short integral time, the function will respond very quickly and may overshoot the Set Point. Setting a larger integral time value will cause a slower response. Integral time is sometimes called Reset.

The controller's CV output may reach and remain at 100%, a condition called saturation. This may occur, for example, if the process is unable to reach Set Point. This causes the Error signal to remain stuck in either the positive or negative range. In this situation, the integral action will grow larger and larger as the Error accumulates over time. This is called integral "wind up", which can cause the controller to overshoot the set point by a wide margin.

This situation can be prevented by setting an MB to clear the accumulated Integral error when saturation is occurs.



Derivative Action

Derivative action responds to the rate and direction of change in the Error. This means that a fast change in error causes a strong response from the controller.

The derivative action 'anticipates' the PV's value in relation to the Set Point and adjusts the controller's CV output accordingly, thus shortening the PID function's response time.

PID Status Messages

PID error indications are given in the Status Messages MI in the PID configuration.

Status

Messages

Initialized to 0 when

Configuration is activated.

MI

Value Message

- 0 FB status OK
 - 1, 2, 3 Auto-tune in progress
 - 4 PID running
 - 5, 6 Setpoint change in progress
 - 7 Integral-wind up
 - 8 integral-wind down
 - 9 Pause mode, Integral and Derivative values are not currently being calculated
 - 10, 11 CV exceeds proportional band, no calculation performed
 - 12, 13 AT parameter mismatch
- Note that this means that PID will run without Auto-tune. The user may either rewrite the PID values to the 32-MI long Auto-tune vector, or may re-run Auto-tune
- 1 Proportion band zero.
 - 2 Input range is invalid (PV input).
 - 3 Output range is invalid (CV output).
 - 4 Integral Overflow has reached maximum of 100,000. PID will not allow the Integral value to increase any further.
 - 5 Error in 32-MI long Auto Tune vector addresses, ex., the vector exceeds the final address in the MI data type.
 - 6 Set Point less than Input low range or Set Point more than Input high range.
 - 7 to-10 Auto tune error, failed to calculate PID parameters
 - 11 Noise is more than 5% of Input Range.


PID Tips

Background: the Proportional Band and PV


The proportional band is a range defined around the Set Point. It is expressed as a percentage of the total Process Value (PV). When the PV is within this range, the PID function is active.

Note • The proportional band may exceed 100%. In this case, PID control is applied over the entire system range.

• The PV and Setpoint must be the same unit type.



You can set PV limits by assigning Power up values as shown below.



Note • A broad proportional band increases the stability of the system, but also increases fluctuations during the stable phase.

• A proportional band that is too narrow will cause the system to react as though to ON-OFF control, and greatly overshoot and undershoot the setpoint.



You can increase the proportional band or the integral time to decrease overshooting and stabilize the system.

PID Analog Input Tips

PID Range Settings: PV Low and PV High limits.

If your PID PV is based on an analog input using current or voltage, you can use the analog range units to set the PV low and PV high limits. If this is done, you must also 'normalize' the setpoint to this range.

In general, it is recommended that you linearize the ranges to Engineering Units (EU). In this case use the analog reading ranges for X1 and X2, and use engineering units for Y1 and Y2.


Input resolution	Reading Range
10 bit, (0 to 10V, 0-20mA)	0-1023 units
10 bit (4-20mA)	205 to 1023
12 bit (0 to 10V, 0-20mA)	0-4095
12 bit (-20mA)	818-4095
14 bit (0 to 10V, 0-20mA)	0-16383 unit
14 bit (4-20mA)	3277-16383

Note •

If you are using a PT100 or Thermocouple input, the values do not have to be linearized. This is because the input value is already in degrees Celsius or Fahrenheit (0.1 ° resolution) according to the Hardware Configuration.


Example: If the MI that is linked to a temperature input, set to Celsius, contains the value 385, the temperature reading is 38.5 ° C.

Example: Temperature, Thermocouple type 'J'



Example: Linearizing to bars (pressure EU)

Assume that you are using a 14-bit input, 4-20mA with a pressure transducer with a range of 0-10 bars. Set Linearization parameters as shown below.



Although you can set the PV limits to the input range, this may not produce accurate results.

Example 1: Assume that the 14-bit pressure transducer mentioned above is in a system with range limits of 0-5 bars. If you set the PV Low to 0 and the PV high to 1000 (10.00 bars), this is the range that will be used by the PID function. PID will work properly.

However, you can achieve better PID control by setting the PV Low to 0 and the PV High to 600 (6 bars). Since the error is a function of the PID working band, Example 2 will run with approximately 40% greater accuracy than Example 1.

Example 2: Thermocouple type 'J' has as range of -200 to 760 ° C. Assume that this is the input for a PID system with an ambient temperature that can reach a low of 10 ° C to a maximum setpoint of 250 ° C. If you set the PV Low to 0 and the PV High to 300 ° C, PID control will function with approximately 3 times greater accuracy than if you set the PV range to cover the entire -200 to 760 input range.

PID via Digital Output (Contactor, Solenoid Valve, SSR)

You can use the PWM (Pulse Width Modulation) FB to control a PID system. PWM FB enables you to control the ratio between the ON and OFF status of a selected MB (Duty Cycle) within the defined cycle time, which is given as ticks of 2.5 milliseconds. The ratio is given as an ON pulse percentage on the range of 0-1000 (0-100%).

In order to control PID with the PWM FB, you **must** set the PID CV range to 0-1000 (0-100.0%).


Since the PWM cycle time is set in ticks of 2.5 ms, e.g. 1 s = 400. If the output is a relay/contactor/solenoid valve, the recommended cycle time range is between 2000 and 12000 (5 to 30 sec).

Example: As the PWM output MB pulses ON and OFF, the pulse ON time is proportional to the CV. If the cycle time is = 4000 (10 sec), and the CV is 100 (10.0%), the output bit will be ON for 1 second and OFF for 9 seconds, thereby supplying 10% of the energy to the system.

If the switch is an SSR, the recommended cycle time range is between 200 and 1000 (0.5 to 2.5 sec). Transistor outputs are preferable.

If you use an SSR, you can use a Unitronics PLC that supports a high-speed output. In Hardware Configuration, set the Frequency (F=1/CT) parameter's

Power-up Value to 5 to 10Hz (which is 0.2 -0.1s cycle time). Link the PWM Duty Cycle MI to the CV. Note that in order to activate the output pulses, you must SET the RUN MB linked to the HSO in Hardware Configuration.



Manual Loop Tuning


In certain cases, you may already have the PID values required by you application. However, you should still perform Autotune in order to ensure proper PID function.

This is because during the Autotune process, the PID function collects certain essential data. Unitronics' proprietary PID algorithm uses this data to run smooth, accurate PID.

Drum Sequencer

Drum Sequencer Overview

The Drum Sequencer FB simulates a mechanical drum sequencer as shown below. Drum instructions are best suited for repetitive processes that consist of a finite number of steps.



The Drum Sequencer FBs enable you to:

- Define the number of steps on your 'drum'
- Define the time duration of a step
- Define the number of output columns
- Link a coil (O or MB) to an output column.
- In each step, determine the status of each coil.

The Drum FBs are located on the FB's menu.

Using Drum

The main routine of a basic drum Ladder application must include a:

- Configuration
The Configuration contains the Drum Outputs, arranged in steps. The duration time of each step is also set in the configuration.
- Scan
This should follow the Configuration. The Scan controls the drum; if the Scan is inactive, the drum is static.

These elements enable the drum to begin at a Start Step, which is specified in the Configuration. When the duration time set for the first step elapses, the drum progresses to the next step. When the last step in the drum is complete, the drum continues with the Start Step.

Progressing through Steps

- Set a duration time
This is done in the Configuration. If you do **not** set a time, the drum will **remain** in that step, unless you use a Jump to Step operation.
- Jump to another step at any time
Even if the drum is in the middle of a different step, you can use a Jump to Step operation: Next Step, Go To Start Step, or Go To Step (Index)

In the event of Power-Up

At Power-up, the drum starts at the Start Step. If power-up occurs while the drum is running, you can return to the desired step by saving the Current Step Index, and then using that step number to as a Power-up value in a Go To Step Index operation.

Final Step

In order to mark the final step in the drum, use a step that includes an output that you dedicate to that purpose. You can then use the changing output status to drive any task.

The screenshot shows the 'Drum Sequencer Configuration' dialog box. The 'Name' is 'Drum_Sequencer_1', 'Number of Outputs' is '9', and 'Sequence Steps' is '5'. The table below shows the configuration for 5 steps and 10 outputs (MB 0-10). Step 1 has a duration of 00:00:10.00. Step 2 has a duration of 00:00:10.00. Step 3 has a duration of 00:00:10.00. Step 4 has a duration of 00:00:10.00. Step 5 has a duration of 00:00:00.00. A callout box points to the 00:00:00.00 duration with the text: 'Note that the duration is 0. The drum will remain in this step indefinitely.' Another callout box points to the MB 10 output column for step 5 with the text: 'When the drum has reached the 'final' step, the MB turns ON.'

#	Start	Duration	1	2	3	4	5	6	7	8	9	10
			MB 0	MB 1	MB 2	MB 3	MB 4	MB 5	MB 6	MB 7	MB 8	MB 10
1	<input type="checkbox"/>	00:00:10.00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="checkbox"/>	00:00:10.00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input checked="" type="checkbox"/>	00:00:10.00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="checkbox"/>	00:00:10.00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="checkbox"/>	00:00:00.00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Drum Sequencer Operations

Configuration

Scan


Go To Step

Go To Start Step


Go To Next Step

Drum Sequencer: Configuration

The Drum Sequencer Configuration represents the traditional 'drum'. The Configuration contains rows of output bits. Each row is a Sequence Step, which correspond to the 'process steps' on a drum.



Your program must activate the Drum Sequencer Configuration before running Drum Sequence operations. You can do this by activating it as a power-up task.




Name	Description
#	This the Step Index number. Use this together with the Go To Step Index operation, which you use for determining the Drum operations' functions.
Start	When the Drum Sequencer runs, this is the first step in the sequence. Whenever the drum restarts, whether as a result of power failure or any other reason,
Duration	If you do not set a Time, the drum will remain in that step, unless a Jump to Step operation changes the current step.
Current Step Index	This MI contains the Step Index number of the current drum process step.

Drum Sequencer: Jump to Step

To jump to another step at any time, even if the drum is in the middle of a different step, link one of these operations to a Configuration.


Next Step

Use this to immediately progress to the next step, without relation to the current state of the drum.




Go To Start Step

Use this to jump back to the Start Step set in the Configuration..



Go To Step (Index)

Use this to immediately jump to a particular step, according to its Step Index number.



In the event of Power-Up

At Power-up, the drum starts at the Start Step. If power-up occurs while the drum is running, you can return to the desired step by saving the Current Step Index, and then using that step number to as a Power-up value in a Go To Step Index operation.

Events

Events Overview

Events: Registering MB status change

An Event is the change in status of an MB from OFF (0) to ON (1). Events can be used, for example, to monitor the status of an array of alarm bits. The Events FBs are located on the FB's menu.

The Event: Scan enables you to:

- Define a vector of MBs.
- Locate the **first** MB that is ON (active) within that vector
- Record the MB's location.

Other Event operations enable you to:

- Move between the active MBs within that vector
- Change MB status from ON to OFF.

Note • | From OS Version OS 1.3.00 and up, V130/V350/V570 support XBs.

Event Operations

Event: Scan

Next Event

Previous Event

Clear Current

Clear All

Events: Count



Events: Loopback

Track Events

Events: Scan

Use the Events: Scan to define a vector of MBs and locate the first positive bit within that vector. Once you have defined a vector of MBs using the Events Scan FB, you can perform other actions within that vector using Event operations.

Note • | Place the Scan FB directly on the left-hand Ladder rail; this ensures that all of the Events functions will run continuously.





Operand	Type	Function
MB Vector: Start	MB	The first MB of the vector to be scanned.
MB Vector: End	MB	The last MB of the vector to be scanned.
Active MB	MB	Turns ON when an active bit is located. Note • Once the Active MB has been turned ON, it remains ON until it is reset by the program.
Active MB Location: Offset in Vector	MI, ML, DW	Contains the location of the Active MB, relative to the beginning of the defined vector. Note • If no MB is active, the value in the linked register will be -1.

Next Event

Once a vector of MBs is defined using the Event Scan FB, the Scan finds the first active MB in the vector.


Use the Next Event operation to move to the next active MB in the vector, in the direction of the Most Significant Bit.




Previous Event

Once a vector of MBs has been defined using the Event Scan FB, the Scan finds the first active MB in the vector.


Use the Previous Event operation to move to the previously active MB in the vector, in the direction of the Least Significant Bit.






Clear Current


Use the Clear Current operation to reset a currently active MB.






Clear All

This operation causes **all** of the active MBs in an Event vector to be reset.



Events: Count

This shows the number of MBs currently ON within the vector defined by the Events Scan.



Events: Loopback

When Loopback is activated by power flow, the focus of the Events moves to the beginning of the vector.

Track Events



This FB enables you to keep track of Rise and Fall events as they happen.

- Rise Events:

Each time an MB rises in the Events vector, the Rise Event MB in Track Events turns ON for a single cycle, and the Rise Location MI contains the location of the active MB, relative to the beginning of the Events vector. If two MBs rise during a single cycle, the Rise Event Location MI will show the events in two consecutive cycles.
- Fall Events:

Each time an MB falls in the Events vector, the Fall Event MB in Track Events turns ON for a single cycle, and the Fall Location MI contains the location of the active MB, relative to the beginning of the Events vector. If two MBs fall during a single cycle, the Rise Event Location MI will show the events in two consecutive cycles.

Note that Track events can only monitor an vector that, as defined in the Events Configuration, does not exceed 255 MBs in length.



If MB 41 rises, MB 61 rises for a single scan and MI 2 will contain 1.


If MB 42 falls, MB 62 rises for a single scan and MI 3 will contain 2.

PWM


PWM FB Overview

The PWM FB enables you to control the change in the status of a selected MB, causing it to function like a PWM (Pulse Width Modulation) output at a resolution of 2.5 milliseconds (in relation to the total scan time).

You can place the PWM FB directly on the left Ladder rail to cause it to run continuously. PWM is located on the FBs menu.




Parameter	Function
Cycle Time	The total cycle time. One unit of cycle time is equal to 2.5 msec.
Duty Cycle	The ratio of the "on" period of a cycle to the total cycle period, expressed as a tenth of a percent of the total Cycle Time.
Output	The MB you select will function as the PWM output. It will be turned ON and OFF according to the input parameters.



Real-time Cycle Changes

If you link the parameters Cycle Time or Duty Cycle to MIs, and the parameters change when the application is running, note that the change is effective at the **next** change in status.



Example

Cycle Time = 800

Duty Cycle = 255

If the Cycle Time parameter is 800; the **total** PWM cycle time will be 2000mSec (800 x 2.5 = 2000mSec).

If the Duty Cycle parameter is 255; the selected MB will be ON for **25.5% of the total Cycle Time** (25.5% of 2000 = 510mSec), and OFF for **74.5% of the total Cycle Time** (74.5 of 2000= 1490mSec)


Loadcell

Loadcell Overview

Loadcell FBs, located on the **FB** menu, enable you to include an I/O module that is connected to a loadcell or strain-gauge in your control application. Unitronics I/O expansion loadcell modules are intelligent I/O modules that are capable of receiving analog values directly from loadcells.

IO-LC1 offers 1 Loadcell input; IO-LC3 module offers 3 Loadcell inputs. Each IO-LCx module is capable of providing excitation for up to 12 loadcells.

The **Loadcell FBs** enable you to calibrate the loadcell. You can also tare and zero the loadcell, compensate for deadload and scale movement, and set the input range.



The readings from each loadcell are written to PLC registers according to the parameters in the project's Hardware Configuration.

Once you connect the loadcell and calibrate at least 2 points, you can begin to run a loadcell application. The loadcell input can be read in 6 different ways:

- Gross weight
- Net weight
- Net Min. Weight
- Net Max. Weight
- Scaled to uV/V
- Raw Value

Most applications will require only the Gross or Net weight. Raw Value and uV/V readings may be useful for troubleshooting purposes.

Note • Minimum settling times for projects using multiple loadcells are

- 12.5ms for one active loadcell
- 675ms for two active loadcells
- 1,012.5ms for three active loadcells

More information is available in the Setup Help topic, and in the module's specification sheet..

- Both negative and positive (signed and unsigned) values can be processed by the I/O-LCx and the support software, enabling a range of applications.
- This feature is not supported by the V120-12 series.

FB Operations

Configuration

Scan

Calibration

Setup

Tare & Zero

Advanced

- **Note** • Both negative and positive (signed and unsigned) values can be processed by the I/O-LCx and the support software, enabling a range of applications.
- This feature is not supported by the V120-12 series.

Loadcell Hardware Configuration

The IO-LCx Hardware Configuration enables you to configure a loadcell, plus the digital input and digital outputs located on the module. These digital I/Os enable you to implement setpoints that are processed within the I/O module, independently of the controller and its program scan, enabling a fast response to process events.

Configuring a Loadcell

The number of Loadcell tabs in the Hardware Configuration window depends upon the loadcell module.


The screenshot shows the IO-LC3 configuration window. At the top, there are tabs for 'Digital Inputs', 'Digital Outputs', and 'Load Cell'. Under the 'Load Cell' tab, there are sub-tabs for 'Loadcell 1', 'Loadcell 2', and 'Loadcell 3'. The 'Loadcell 3' tab is selected. Below the tabs, there is a checked 'In Use' box. The 'Resolution' is set to 'High (ML)'. The 'Number of Input Values' is set to 'Two values'. The 'Excitation' is set to 'AC'. The 'LC Input Value(s)' list contains 'ML 0 - LC 1st Input' and 'ML 1 - Loadcell'. The 'Hardware Status Messages' list contains 'MI 0 - LC Status'. A yellow warning icon is present with the text: 'Via Number of Input Values, you can represent the LC input simultaneously in 2 different modes. Selecting one value links the LC input to a single register. Selecting two values links the first value to a single register. The second value automatically links to the next successive register'. Below the configuration window, a diagram shows a row of boxes labeled 'ML 0', 'ML 1', '2', '3', '4', and '...'. Red arrows point from 'ML 0' and 'ML 1' to two green boxes: 'Value 1 (Default: Net Weight)' and 'Value 2 (Default: Gross Weight)'.

Parameter	Type	Function
In use		Select 'In Use' to enable the loadcell for the application. Note • A loadcell marked 'in use' can be suspended according to application conditions via the Advanced Calibration function Enable/Disable loadcell. This may be done to shorten the application's calibration time.
Resolution	ML, MI	Selecting High enables you to link the input value to an ML, Normal to an MI.
LC Input Value(s)	MI, ML	When the application runs, these registers contain the weight value input to the controller from the I/O LCx. When you select two values, you link the first value to a single register. The second value is automatically linked to the next register. The default representation mode for the first register is Net Weight , and Gross Weight for the second register.
Excitation		AC is the default, recommended Excitation method. You may select the DC option if your application requires.
Hardware Status Messages	MI	Provides a bitmap showing the status of the module.



Loadcell: Configuration

All Loadcell operations run through a Loadcell Configuration placed in the control program. Each Configuration is linked to a specific Loadcell input on the I/O expansion module.

Loadcell Configuration is generally a Power-up task. The Loadcell Configuration FB is located on the FB's>Loadcell menu.



Parameter	Type	Function
I/O Module DIN Location		Links the Configuration with the correct I/O expansion module according to its DIN rail location in Hardware Configuration.

		<p>On this DIN rail, the I/O LC3 is module # 2</p>  <p>Note • If the module is not located in the entered location, the LC Command Status Messages MI will display 6, Communication Error (I/O module does not exist)</p>
<p>Loadcell Input Number</p>		<p>Here, Loadcell 2 is being shown as marked 'In Use'.</p>  <p>Note • If the selected Loadcell is not marked 'In Use', the LC Command Status Messages MI will display 11, Illegal parameter</p>
<p>LC Command Status Messages</p>	<p>MI</p>	<p>Is reset to 0 when a command is activated. Updated at the end of all operations using the Loadcell Configuration. Indicates error status for all loadcell operations processed by the Configuration Current value always shows the most recent error status.</p> <p>Value Message</p> <p>0 Function in Progress</p> <p>1 Command carried out successfully</p> <p>2 I/O Expansion Command Buffer is full, please retry. Can be avoided by using SB 91, I/O Expansion Module--Command Buffer Full, as a condition</p> <p>3 The I/O expansion module linked to the configuration is busy</p> <p>5 Timeout Exceeded</p> <p>6 Communication Error (I/O module does not exist)</p> <p>11 Illegal parameter</p> <p>13 Power supply not connected</p> <p>16 Scale is currently in motion (is only relevant if In-Motion function is applied)</p> <p>17 Signal is out of range (this value occurs when the Out of Range bit is ON)</p> <p>18 Illegal weight (Occurs during calibration, if the raw value of weight being calibrated is too close to the raw value of an already calibrated weight; minimum distance is 256 or 100 Hex)</p> <p>19 Command not supported in uV/V mode</p> <p>20 Not calibrated (This value appears when less than 2 points have been calibrated)</p> <p>21 EEPROM Protection Error (Indicates when too many Save Calibration FBs are run too frequently. Check the activating conditions for the Save Calibration FB, and whether your application contains loops)</p>
<p>LC Success Bit</p>	<p>MB</p>	<p>Use this to monitor the status of a command</p> <p>Turns ON when: Configuration is first activated. Command is successfully processed. Command Status Messages MI is 1.</p> <p>Turns OFF when: Command Status Messages MI is 0. Function in Progress MB is ON, indicating that a command is being processed. Command error occurs</p>


Function in Progress	MB	<p>This bit is ON when the module is processing a command. Use this as a condition bit for Loadcell operations to avoid conflicts.</p> <p>Turns ON when: Command is being processed. Command Status Messages MI is 0.</p> <p>Turns OFF when: Configuration is first activated. Command Status Messages MI is 1.</p>
-----------------------------	----	---

	LC Success Bit	Function in Progress	LC Command Status Messages
Command Issued	0	1	0
Success	1	0	1
Error	0	0	>1

Scan

A Scan FB must be included for every Loadcell Configuration in a Loadcell application. When an application contains more than 1 Loadcell Configuration in the Ladder, the Scan FB displays the Select Name drop-down list, enabling you to link the desired Configuration.

The Scan FB is located on the FB>Loadcell menu.



Note • The Scan FB must be on the left-hand ladder rail.


Calibration

Calibration parameters include calibrated points, input range settings, tare and zero values. These may be burned to the module's EEPROM using the Save Calibration FB. Before you can begin to implement a Loadcell application, you must calibrate at least two points, although up to 12 points may be calibrated; all other calibration parameters are optional. However, note that if the application requires you to set Input Range/Gain, you must make these settings **before** you calibrate points. Setting the Input Range/Gain after calibrating points invalidates these points.

Calibrating Points

A Calibration Point matches a Raw Value with a Weight value. These points are used to linearize the input value.

To calibrate points, connect the controller to the loadcell via the I/O-LCx. Initial calibration is generally performed with known weights as shown in the following figure. After calibration has been performed, advanced calibration enables points to be added or edited via the ladder without weight being physically placed on the loadcell.



Notes •

If the application requires you to set Input Range/Gain, you must make these settings before you calibrate points. Setting the Input Range/Gain after calibrating points invalidates the calibrated points.


- Zero does not have to be calibrated.
- Points do not have to be calibrated in any particular order.
- All calibrated points must be separated by a raw value minimum of 256 (100 Hex).
- Calibration is an immediate operation; motion is not checked before the operation is carried out.
- Calibration should be performed with greater accuracy than is required by the application. For example, in an application that requires 100g accuracy, calibrate in units of 10g, then round off the represented value by 10.
- The highest Calibrated Point weight value should 80–100% of the scale capacity.
- Calibration cannot be performed if the selected representation

mode is uV/V.

- During Calibration, increase filter depth by:
 - Increasing Settling Time.
 - Disabling other Loadcells.

Calibrate Point FB


The Calibrate Point FB is located on the FB's>Loadcell>Calibration menu.



Parameter	Type	Function
Point Number	Constant, MI	A Calibration Point matches a weight value with a raw value. The raw value is acquired as an input from the loadcell when the application is run.
Calibrate to Weight	MI, ML	This provides the weight value that is matched to the raw value

Save Calibration

When you save the calibration, calibrated points, tare, zero, and input range are burned into the module's EEPROM memory. This protects the calibration in the event of a power outage, reset, or power-up. To preserve any changes made to calibrated points, input range settings, tare and zero values, use Save Calibration any time these parameters are edited.



Tare & Zero

Applying Tare and Zero accomplish the same aim: to start a weighing session with a value of zero.

The Tare value may include, for example, the container of the material to be weighed.

If the scale does not read 0 when empty, use Zero to compensate.

Scale Reading	Empty Container	Empty Container- Tare applied
	0.15	0.00
Scale Reading	Empty Scale	Empty Scale- Zero applied
	0.01	0.00

When Tare is applied, it is reflected in the net weight.

When Zero is applied, only the gross weight will be zero at the beginning of a weighing session.

Acquire Tare/Zero FB: value read from Loadcell

Acquire Tare and Acquire Zero are both located on the FB's>Loadcell>Tare & Zero menu.

Acquire Tare: In this method, the tare value is acquired from the scale. The objects comprising the tare, such as a pallet or materials container, are placed on the scale, and Acquire Tare is activated.

Acquire Zero: The scale must be empty to acquire Zero. Acquire Zero is **not** related to the Auto-Zero Tracking function, which enables the module to compensate for the accumulation of undesired material on the scale in the course of operations.


Note • Loadcell Name determines from which loadcell the tare/zero will be acquired. After the tare has been acquired, the tare value will be applied to that loadcell.

- Use the Save Calibration FB to save Tare and Zero values to the module's EEPROM memory.

- Tare and Zero cannot be acquired when running uV/V mode.

- If the Motion Band FB is activated, the tare value cannot be acquired until the scale is stable.


i Although only the FBs relating to tare are pictured in the following figures, the figure apply to both Tare and Zero FBs.



Advanced Tare& Zero Functions


These FBs are both located on the FB's>Loadcell> Advanced> Tare & Zero menu.

Edit Tare/Zero: value via operand or constant



Parameter	Type	Function
Tare/Zero Value	MI, ML, or Constant	Edit Tare/Zero enables the tare value to be acquired from a register or constant value within the controller. You can also use Edit Tare/Zero to change a loadcell's existing tare/zero value.

Read Tare/Zero: reading the current Tare or Zero Value



Parameter	Type	Function
Read Tare/Zero	MI, ML	Reads the current tare or zero value applied to the linked loadcell input into the linked register.

Setup

Setup FBs provide additional parameters that you may require for your application. Setup FBs include Motion Band, Filter & Rounding, and Auto-Zero, and are located on the FB's>Loadcell>Setup menu.

Note • The Setup FBs need to be activated only once, at power-up. They are not saved to EEPROM.

Motion Band


When the weight on the scale changes, the scale needs time to stabilize.

The Motion band determines the amount of weight change the module uses to decide if the scale is in motion.


Bit 0, of the MI that is linked to **LC Hardware Status Messages** in Hardware Configuration, is the In-motion indicator. Bit 0 is ON when the scale is in motion, and OFF when the scale is steady.

As the module reads the signals from the loadcell(s) it calculates the weight value. If a weight change falls within the Motion Band, Bit 0 turns OFF.

In the figure below, the in-motion indicator (Bit 0) turns ON when the weight change is below 100 grams, or more than 500 grams. When the weight change falls within the band (100 to 500), Bit 0 turns OFF.




Notes •	The FB must be activated in order to apply the Motion Band.
•	The In-motion indication is OFF: <ul style="list-style-type: none"> - at Power-up - or when the scale is not calibrated.
•	In order for the In-Motion indication to function properly, the filter Active Band must be equal or higher than the In-Motion Tolerance. Refer to the Filter and Rounding function for description and power-up defaults.
•	If the Motion Band is active, the tare/zero values cannot be acquired when the scale is in motion.



Parameter	Type	Function
LC Motion Band	MI, ML, or Constant	Provides a value for the weight band. A weight change that falls outside this band turns the In-motion bit ON. When the weight change is inside the band, the bit turns OFF.

Filter and Rounding

The Filter & Rounding parameters change the default filter parameters and value rounding. Rounding further smooths the loadcell reading.



Parameter	Type	Function
Rounding	MI or Constant	<p>The number used to round the output values.</p> <p>0 - Round by 1(Power-up default) 1 - Round by 2 2 - Round by 5 3 - Round by 10 4 - Round by 20 5 - Round by 50 6 - Round by 100</p> <p>Note • Value rounding will not take effect in uV/V and Raw value representation modes.</p>
Settling Time	MI, or Constant	<p>The time, in units of 10msec, that the filter requires to settle to the final reading.</p> <p>Notes • The default settling time is 1 second, the minimum time is 12.5 milliseconds, and the maximum is 24 seconds.</p> <ul style="list-style-type: none"> • A value of zero disables the filter. • Settling time rises with the number of active loadcells. <p>The minimum settling times are:</p> <ul style="list-style-type: none"> - 12.5ms for one active loadcell. - 675ms for two active loadcells. - 1,012.5ms for three active loadcells. <p>Using a settling time of zero sets the settling time to its minimum value without returning an error.</p>
Active Band	MI, ML, or Constant	<p>The band of weight changes in which the filter is active.</p> <p>The filter is turned off by weight changes that exceed the active band. This allows a rapid response to large weight changes. When the weight changes become smaller than the active band, the filter turns on.</p> <p>An active band of zero forces the filter to be always active.</p> <p>Notes • If the Motion Band is on, the filter's Active Band must be equal or higher than the Motion Band.</p>

Auto Zero Tracking

When activated, Auto-Zero Tracking zeros the gross weight according to the conditions you set, enabling the module to automatically compensate for small variations at the zero point, such as those caused by a buildup of litter on the scale platform, or by temperature fluctuations near the scale.

Before Auto-zero Tracking can zero the scale:


- The Motion Band FB must be included in the application.
- The Motion Band must be active.
- The In-Motion bit, Bit 0 of the MI linked to **LC Hardware Status Messages** in Hardware Configuration, must already have turned OFF, indicating that the scale is steady.

Once these conditions have been met, Auto-zero zeros the gross weight.

Notes •

Once Auto-Zero tracking is activated, it stays active until the function is suspended by the application.

- Auto zero tracking will not function in uV/V representation mode.



Parameter	Type	Function
LC Time: Scale Stable, 10 mS units	MI, ML or Constant	The time in which, in units of 10 mSec, the scale must be stable in order to trigger Auto-Zero Tracking. Notes • Initializing this parameter to 0 will turn off Auto Zero Tracking and clear the accumulated offset. <ul style="list-style-type: none"> • Power-up default: 0 (auto zero tracking is off). • To clear the auto zero tracking offset, initialize this parameter to 0, and then enter a new time value.
LC Tracking band, Weight from last Auto-0	MI, ML or Constant	This determines the maximum distance from the point of the last zero (auto or manual) in which auto-zero tracking is activated [weight units].
LC Tracking Range, Weight from Calib. 0	MI, ML or Constant	This determines the maximum weight from the point of the last calibrated zero in which auto-zero is activated.

Loadcell Operands & Status Messages

Loadcell: Configuration FB

All Loadcell operations run through a Loadcell configuration placed in the control program. Each Configuration is linked to a specific Loadcell input on the I/O expansion module.

Command Status Messages Initialized to 0 when Loadcell Configuration is activated.	MI	Is reset to 0 when a command is activated. Updated at the end of all operations using the Loadcell Configuration. Indicates error status for all loadcell operations processed by the Configuration Current value always shows the most recent error status. Value Message 0 Function in Progress 1 Command carried out successfully 2 I/O Expansion Command Buffer is full, please retry. Can be avoided by using SB 91, I/O Expansion Module--Command Buffer Full, as a condition 3 The I/O expansion module linked to the configuration is busy 5 Timeout Exceeded
--	-----------	--

		<p>6 Communication Error (I/O module does not exist)</p> <p>11 Illegal parameter</p> <p>13 Power supply not connected</p> <p>16 Scale is currently in motion (is only relevant if In-Motion function is applied)</p> <p>17 Signal is out of range (this value occurs when the Out of Range bit is ON)</p> <p>18 Illegal weight (Occurs during calibration, if the raw value of weight being calibrated is too close to the raw value of an already calibrated weight; minimum distance is 256 or 100 Hex)</p> <p>19 Command not supported in uV/V mode</p> <p>20 Not calibrated (This value appears when less than 2 points have been calibrated)</p> <p>21 EEPROM Protection Error (Indicates when too many Save Calibration FBs are run too frequently. Check the activating conditions for the Save Calibration FB, and whether your application contains loops)</p>	
LC Success Bit	MB	<p>Turns ON when: Configuration is first activated. Command is successfully processed. Command Status Messages MI is 1.</p>	<p>Turns OFF when: Command Status Messages MI is 0. Function in Progress MB is ON, indicating that a command is being processed.</p>
Function in Progress	MB	<p>Turns ON when: Command is being processed. Command Status Messages MI is 0.</p>	<p>Turns OFF when: Configuration is first activated. Command Status Messages MI is 1.</p>

Loadcell Hardware Status Messages (Hardware Configuration)

The MI linked to the parameter **LC Hardware Status Messages** in Hardware Configuration provides a bitmap for the following messages.

Bit#	Description	Turns ON when:	Turns OFF when:
0	Scale motion Only relevant if Motion Band FB is included in application and activated	Scale is in motion	At Power-up When Scale is steady
1	Input Value Range Linked to I/O module's Out of Range LED indicator	Input value is out of range Possible causes: 1 or more signal wires are disconnected A/D input voltage is out of range	Input value is in range
2	Input Value Validity	Input Value is invalid Possible causes: Channel is temporarily disabled, via the Disable all other Loadcells FB Bit is ON at Power-up until the first input value is received from the loadcell	Input Value is valid
3	Loadcell Calibration Status	When less than 2 points are calibrated	At least 2 points are calibrated
4	Input Power Supply Status Linked to I/O module's Out of Range LED indicators	No Power When the input power is not supplied, the indicators blinks rapidly	Power Supply OK

Note • Bits 6 & 7 are linked to Outputs 0 & 1, located on the I/O module. Bit 6 is related to Output 0, Bit 7 to Output 1. Bits 6 & 7 can be used to monitor the setpoint output's status from within the Ladder application. The I/O module itself controls the setpoint function of the outputs. The module turns the outputs ON and OFF when the current loadcell input value reaches setpoint. Since the function is based in the firmware of the expansion module, when the output's status changes as a result of reaching/departing from setpoint, the status change is not registered by the Ladder application. Examples

When setpoint output 1 is assigned to load cell channel 0, Bit 7 of load cell 0 status will indicate the state of output 1.
 When setpoint output 0 is assigned to load cell channel 2, Bit 6 of load cell 2 status will indicate the state of output 0.

6	Setpoint Status, Output 0	Output 0 is ON	Output 0 is OFF
7	Setpoint Status, Output 1	Output 1 is ON	Output 1 OFF
SB91	I/O Exp. Module--Command buffer is full	ON when commands cannot be sent to the I/O module.	OFF when commands can be sent to the I/O module..

Advanced Loadcell Functions

Advanced-Calibration

These FBs are all located on the FB's>Loadcell> Advanced> Calibration menu.


Note • The Edit and Read Calibration Point functions contain parameters which accept the raw and weight values from existing Calibration Points. These parameters must be linked to the same type of registers, MI or ML, used to calibrate the original Calibration Point.

Edit Calibration Point: value via operand or constant

A Calibration Point matches a raw value to a weight value. You can use Edit Calibration Point to change these values.

Notes • The loadcell will stop functioning if deleting a point causes the number of Calibration Points to be less than 2.

• To prevent your changes from being lost at power-up, reset, or in the event of power outage, use the Save Calibration FB to burn the changes to the module's EEPROM.




Parameter	Type	Function
LC Calibration Point Number	MI or Constant	The number of the Calibration Point that you wish to edit.
LC Raw Value	MI, or ML	This register contains the new raw value for the Calibration Point.
LC Calibrate to Weight	MI, or ML	This register contains the new weight value for the Calibration Point.

Read Calibration Point

Use this function to read the current raw and weight values of a Calibration Point.

Note • If the point being read is not in use, both returned values will be -32768 (0x8000) for integer and -8388608 (0x800000) for long.




Parameter	Type	Function
LC Calibration Point Number	MI or Constant	The number of the Calibration Point that you wish to read.
LC Raw Value	MI, or ML	This register contains the current raw value of the Calibration Point.
LC Calibrate to Weight	MI, or ML	This register contains the current weight value of the Calibration Point.

Delete Calibration Point

This deletes a Calibration Point.

Notes • The loadcell will stop functioning if a deleted point causes the number of Calibration Points to be less than 2.

• To prevent your changes from being lost at power-up, reset, or in the event of power outage, use the Save Calibration FB to burn the changes to the module's EEPROM.




Parameter	Type	Function
LC Calibration Point Number	MI or Constant	The number of the calibrated point that you wish to delete.

Clear Calibration

This deletes all calibrated points, tare, zero, and input ranges from the module's memory. However, Clear Calibration does not erase the values from the EEPROM. They may be retrieved from the EEPROM by resetting the controller.

To delete all values from the EEPROM, run Clear Calibration followed by Save Calibration.




Enable/Disable all other load cells

Disable All Other Loadcells disables all loadcells in the expansion module except for the loadcell selected in the FB.

During Calibration, the Disable All Other Loadcells FB can be used to increase filter depth for a specified settling time by eliminating the delay caused by channel change (approx. 300ms) and thus ensuring faster and more accurate calibration.

To prevent channel changing from wasting settling time, use this function to disable all other loadcells except for the one you are currently calibrating.



Enable All Other Loadcells re-enables all loadcells in the expansion module.

Notes •

After this FB is run, and the Command Status Messages MI linked to the selected Loadcell Configuration indicates 1, updated values for all of the enabled channels are already available at their linked operands. This indication can be used to trigger a process, such as calibration.

- Disabled Loadcells: the Hardware Status Messages MI linked to the selected Loadcell Configuration The status bit "Value not valid" will rise in the disabled load cells' status word.

Setpoint

Each digital output located on the I/O module is associated with a setpoint. The I/O module itself controls the setpoint function of the outputs. The module turns the outputs ON and OFF when the current loadcell input value reaches setpoint.

Setpoint activity is therefore not linked to the program scan. Each output may be assigned a setpoint.

Since the function is based in the firmware of the expansion module, when the output's status changes as a result of reaching/departing from setpoint, the status change is not registered by the Ladder application. To monitor the outputs' status, this MI provides a bitmap indicating status messages; Bit 6 is related to Output 0, Bit 7 to Output 1.

Therefore, use Bits 6 & 7 of the **LC Hardware Status Messages** MI to monitor the outputs' status, from within the Ladder application.

Note •

Once the Setpoint is activated, it cannot be changed by setting the output via the Ladder application.

The setpoint remains OFF, regardless of its N.O./N.C.setting, when the loadcell input value is:

- invalid (i.e., powered off, LC disabled, out of range, loadcell not calibrated).
- In uV/V mode.


Examples

- When setpoint output 1 is assigned to load cell channel 0, Bit 7 of load cell 0 status will indicate the state of output 1.
- When setpoint output 0 is assigned to load cell channel 2, Bit 6 of load cell 2 status will indicate the state of output 0.

Bit	Description	Turns ON when:	Turns OFF when:
6	Setpoint Status, Output 0	Output 0 is ON	Output 0 is OFF
7	Setpoint Status, Output 1	Output 1 is ON	Output 1 OFF

Set and Activate Setpoint

Use this FB to implement a desired setpoint.




Parameter	Type	Function
LC Value Mode	Constant	Set the input value mode for the setpoint: 0 - Net 1 - Gross 2 - Net Min 3 - Net Max
LC Output Number	Constant	Select output: Output - 0 Output - 1
LC Setpoint Type	MI, ML, or Constant	Select setpoint type: 0 - Normal state: Open Activation: Low 1 - Normal state: Open Activation: High 2 - Normal state: Closed Activation: Low 3 - Normal state: Closed Activation: High

		<p>High Activation Normally Open</p> <p>weight ↑</p> <p>Setpoint</p> <p>Hysteresis Band</p> <p>Output value: 0 1 0</p>	<p>High Activation Normally closed</p> <p>weight ↑</p> <p>Setpoint</p> <p>Hysteresis Band</p> <p>Output value: 1 0</p>
		<p>Low Activation Normally Open</p> <p>weight ↑</p> <p>Setpoint</p> <p>Hysteresis Band</p> <p>Output value: 0 1 0</p>	<p>Low Activation Normally Close</p> <p>weight ↑</p> <p>Setpoint</p> <p>Hysteresis Band</p> <p>Output value: 1 0</p>
<p>LC Setpoint Value</p>	<p>MI, ML, or Constant</p>	<p>The actual value assigned to the setpoint.</p>	
<p>LC Setpoint Hysteresis</p>	<p>MI, ML, or Constant</p>	<p>Sets a band in which the output will not chatter due to overshoot or vibrations.</p>	

Deactivate Setpoint

Use this to suspend the activity of a particular setpoint.




Change Representation Mode

During hardware configuration, under Number of values, you select whether to use one or two values. When you select a register for the Address: Value(s) parameter, selecting two values means that the register immediately following the register you select is used for the second value. The default representation

mode for the first register is Net Weight, and Gross Weight for the second register.

Via Change Representation mode, you can 'read' the value as:

- Gross weight
- Net weight
- Net Min. Weight
- Net Max. Weight
- Scaled to mV
- Raw Value



Parameter	Type	Function
LC Value to Represent	Constant	Select the value for which you want to change the representation mode.
LC Representation Mode	MI or Constant	Select the desired representation mode. 0 - Net (Gross if no Tare) (Power-up default for 1st value) 1 - Gross (Power-up default for 2nd value) 2 - Net Min 3 - Net Max 6 - uV/V 7 - Raw value

Note • When, after Change Representation Mode runs, the LC Command Status Messages MI returns '1', the requested value is already in its linked operand. This means that you can use the '1' status to trigger a process which relies on this specific representation value.

- The mV/V representation mode uses the default calibration. Therefore:
 - The mV/V rep. mode indicates the actual applied differential input voltage in micro-volts per every volt of the excitation, regardless of the user-selected input range and DAC (offset) compensation.
 - Setting **one** of the values representation modes to mV/V will force **both** values to be represented in mV/V (the rep. mode of the other value will not be overwritten).

- It takes approximately 330msec to change between mV/V and other different representation modes.
- The A/D raw value is affected by the user-selected input range (gain and DAC (offset) compensation). To cancel this effect, use the Clear Calibration command to set default calibration. To return to the last saved calibration, reset the controller (no need to re-power-up neither the unit nor the controller).

Reset Net Min/Max Values

Resets the Net Minimum value to positive full-scale, and the Net Maximum value to negative full-scale.


As soon as the scale becomes stable, meaning that the In-motion bit is OFF, the Net Min and Max values will be set to the net value.

A Net Min and Max reset occurs also at power-up.

Change Excitation Mode

Use this FB to temporarily change the excitation supplied to the loadcell.

This method is intended to use only for diagnostic purposes, such as when using a DC milli-voltmeter.



Note •	Changing the excitation mode may add an offset to the A/D measurements. Therefore, the system should be calibrated using the same excitation mode the loadcell will work with.	
•	In general, the working excitation mode should be set via Hardware Configuration.	
•	The Change Excitation command overrides the hardware configuration excitation setting until the next system reset / power-up.	
•	Changing excitation mode may cause a momentary conversions-break (about 300msec) due to filter reset.	
Parameter	Type	Function
LC Excitation mode	MI or Constant	0=DC 1=AC

Input Range

The Input Gain parameter sets the amplification range for the input signal.

The Offset parameter is generally used to compensate for the deadload; particularly in cases where the combined weight of deadload and payload exceed the A to D converter input range.


Input Range and Offset are considered part of the loadcell's calibration. To burn these values into the module's EEPROM memory and protect them in the event of a power outage, use the Save Calibration FB.

Notes •	Changing Gain or Offset requires you to recalibrate and save all calibrated points.	
•	If the application requires you to set Input Range/Gain, you must make these settings before you calibrate points. Setting the Input Range/Gain after calibrating points invalidates the calibrated points.	
•	Offset values out of the ± 31 range will be truncated and no error will be returned.	
•	The $\mu\text{V}/\text{V}$ rep. mode uses its own input range settings and therefore is not affected by the command.	

Set Gain FB

This FB limits the input range. The gain is applied to the signal **after** offset compensation.

Setting the Set Gain MB to 0 limits the input range to $\pm 20\text{mV}$ (Default setting), setting it to 1 (or any other value) limits the input range to $\pm 80\text{mV}$.




Set Offset

This FB sets the offset compensation, which is applied to the input signal **before** the gain. By default, the offset is set to 0mV (no offset).

Possible values are in the range of ± 31 , where: $1\text{LSB} \approx 0.5\text{mV/V}$ (= 2.5mV at exactly 5V excitation). Hence, the maximum offset compensation is $\pm 15.5\text{mV/V}$ (= $\pm 77.5\text{mV}$ at exactly 5V excitation).

To calculate the offset value, measure the differential voltage at the input, between the -SG and +SG terminals, and then calculate the offset value according to $1\text{LSB} \approx 0.5\text{mV/V}$.

If, for example, the differential voltage at the input is 10mV, use -4 as the offset value.



Read Gain

Reads the input range Gain.

Read Offset

Reads the input range Offset.

Filter

Filter Overview

Filter, located on the FB menu, enables you to take from 4 to 16 values and calculate an average. You can influence the average by configuring the function to:

- Discard a user-defined number of maximum & minimum input values
- Weight the average according to the order of the input values (FIFO).


Note • The values are not allocated memory, but are stored and calculated independently within the function block.

- Certain analog inputs can also be filtered via Hardware Configuration settings.


How Filter works

The Filter Configuration holds the parameters that determine how the input values are averaged. The input value is taken from the linked Filter Calculate function.


In the figure below, Filter Calculate is linked to the configuration Filter_1. In this configuration, Parameter 1: Filter type is Dynamic Average; Parameter 2: Number of Values is 8; and Parameter 3: Discard Values is 2.



ML 0 provides the input values. Each time Filter: Calculate is activated, the value in ML 0 is copied to the vector of the linked Filter Configuration,. In this example, 8 values are collected. As each new value is input, the oldest value is shifted out.



Since Discard Values is 2, the 2 lowest and 2 highest values are discarded. The remaining values are summed, and then averaged ($30+40+50+60=180/4$). The result is 45, which is output to ML 1.




FB Operations

Filter: Configuration

Filter: Calculate

Filter: Configuration

The Filter Configuration holds the parameters that determine how the input values are averaged, therefore it must be activated before the Filter: Calculate function is called.



Parameters	Type	Function
Filter Type: Calculates the average of all the current input values	Dynamic Average	Each input value is given equal weight.
	Order-weighted Average	More weight is given to the newer input values. (FIFO)
Number of Values	4-16	Defines the values in the vector as well as the divisor for calculating the average.
Discard Values	0-4	Removes the minimum and maximum input values according to the selection. For example, selecting the number '3' cause the 3 lowest and 3 highest values to be discarded before the average is calculated.



Filter: Calculate

Each time the Calculate function's activating condition is turned ON, the function's Input parameter is copied to the vector of the linked Filter

Configuration, the average is calculated, and the result is placed in the linked output operand.

- Note •** | The output value is overwritten each time the function is activated.

- | The vector is not allocated PLC memory. The values are stored in the function



Accelerate

Accelerate Overview

Accelerate causes a register value to increment or decrement within a set range, at an accelerating or decelerating rate. This rate increases/decreases exponentially as long as the function receives power flow.

The value to be incremented/decremented is set in the Configuration, together with the other parameters that set the rate of change.

Accelerate operations are located on the FBs toolbar.

FB Operations

Configuration


Increment/Decrement

Configuration

The Configuration should be called as a Power-up task. The function sets the parameters which determine the value to increment or decrement, the range for that value, the initial step size, and the factor of acceleration/deceleration.

The rate of acceleration is calculated as follows:

$$\text{Rate of Acceleration} = \text{Acceleration factor} * \text{Initial Step Size} * \text{Time (where time is the duration of the time period that Accelerate is active)}$$



Parameter	Type	Function
Value to Increment/Decrement	MI,ML, DW, or	This is the register value that is incremented ('accelerated') or decremented ('decelerated').
Range: Minimum Value	MI,ML, DW, or Constant	The value being incremented or decremented cannot fall below this value. Note • Both minimum and maximum values must be assigned to the same operand type.
Range: Maximum Value	MI,ML, DW, or Constant	The value being incremented or decremented cannot exceed this value.
Initial Step Size	MI or Constant	When the function is activated, this determines the step size during the first 3 seconds of Increment/Decrement. One step is made each seconds. After three seconds has elapsed, the function uses the Initial Step Size as a factor in calculating the rate of acceleration. Note • This value cannot exceed 255.
Acceleration Factor	MI or Constant	The factor used in the acceleration/deceleration formula. Note • This value cannot exceed 255.
Status	MI	Bit Message 0 No error 1 Range: Minimum Value and Range: Maximum Value have not been assigned to the same operand type. 2 Range: Minimum Value is higher than or equal to Range: Maximum Value. 3 Accelerated value exceeds Range: Maximum Value. 4 Accelerated value is lower than Range: Maximum Value. 5 Initial Step Size exceeds 0 - 255 (byte size). 6 Acceleration Factor exceeds 0 - 255 (byte size).

Increment/Decrement

Increment



When this is active, the Value to Increment/Decrement increases according to the rate of acceleration. The longer Increment is active, the faster the rate of increase.

Decrement




When this is active, the Value to Increment/Decrement decreases according to the rate of acceleration. The longer decrement is active, the faster the rate of decrease.

Fast Response

Fast Response Overview

Fast Response functions are intended for applications that require very fast reaction times. The functions may be used with the I/O Expansion Module I/O-DI8-TO8. In conjunction with Fast Response FBs, the module can use input state to control the state of an output. The control is direct, internal to the module, and is independent of the program scan.




The module can be set to work in four different modes via the Set Mode operation. In addition, the Set Counter operation may be used to store a value or reset the high-speed counter on the module.

Fast Response: Mode Overview

Mode 1: Single Input


- Register when a selected input, **Input 1**, turns ON or OFF.
- Wait the time span defined for **Input 1**(units of 1mSec), then change the state of the corresponding output.
- Maintain the state of the output for a defined time span, and then return the output to its original state.



Mode 2: Two Inputs


- Register when **Input 1** turns ON or OFF.

- Wait the time span defined for **Input 1**, then change the state of the corresponding output.
- Register when **Input 2** turns ON or OFF.
- Wait the time span defined for **Input 2**, then return the output to its original state.




Mode 3: Two Inputs + Output Timer

- Register when **Input 1** turns ON or OFF.
- Wait the time span defined for **Input 1**, then change the state of the corresponding output.
- Register when **Input 2** turns ON or OFF.
- Wait the time span defined for **Input 2**, then return the output to its original state.




- If, however, **Input 2** does **not** change state within the time span defined for the **corresponding output**, the output state changes.



Mode 4: Two Inputs + Output Timer +T2

This mode is identical to Mode 3, with an added feature:

- The time span defined for **Input 2** has an **additional** function. It determines the time span from the change of the output state, during which **Input 2** is ignored.



Using Fast Response: Overview

A Fast Response application must contain the following elements:

- Configuration
Use this to select the I/O Expansion Module for Fast Response
- Set Mode, to select the Fast Response mode and the input or inputs. Note that selecting an input automatically selects the corresponding output; for example, selecting Input 35 automatically selects Output 35.
- Scan




'Fast Response' Toggle

To enable an output to directly respond to an input and bypass the program scan, you must toggle the output into 'Fast Response' mode by turning the appropriate 'trigger output' ON. To calculate the address of this output, check the section below: **Determining the 'toggle output' address.**

To suspend Fast Response and return control to the PLC program, turn the mirror output OFF.

In the application shown below, I 33 is selected as the input. This means that O33 is automatically selected, and that O41 is the 'toggle output' that you use to toggle in and out of Fast Response mode.



Determining the 'toggle output' address

Hardware Configuration shows a DIN rail that holds the I/O Expansion models for your application. The position of the module determines the address of an output. Each module has a group of 16 assigned outputs, no matter how many outputs it actually has. The address of an I/O indicates its actual physical location. This address relates to both the position of the expansion module in the system, and to the position of the I/O on that module.

The formula that is used to calculate the address of an I/O is:

$$(32 + x) + (16 + y),$$

where X is the number representing the location of the module's location (0-7) and Y is the number of the input or output on that specific module (0-15).

To calculate the address of a 'toggle output', use:

$$(40 + x) + (16 + y)$$

Example

- Output #4, located on module #3, will be addressed as O 84
 $84 = (32 + 3) + (16 + 4)$
 Its 'toggle output' will be O92
 $92 = (40 + x) + (16 + 4)$

The screenshot shows the 'Hardware Configuration' window with three IO modules: IO-DI8-RO4, IO-DI8-TO8/RO8, and IO-DI8-RO4. Below them are three physical modules: IO-DI16, EX90-DI8-RO, and three IO-DI8-TO8/RO8 modules. Callouts provide details for three specific modules:

- Module 1** (IO-DI8-TO8/RO8): Physical Outputs: 32-39, 'Mirror' Outputs: 40-47. Fast Response toggle for O33 is O41.
- Module 2** (IO-DI8-RO4): Physical Outputs: 48-51. Note: "Does not support Fast Response".
- Module 3** (IO-DI8-TO8/RO8): Physical Outputs: 64-71, 'Mirror' Outputs: 72-80. Fast Response toggle for O67 is O75.

Tables from the screenshot:

Op	Add	Description
0	32	
0	33	
0	34	
0	35	
PNP	36	
0	37	
0	38	
0	39	

Op	Add	Description
0	48	
0	49	
0	50	
0	51	

Op	Add	Description
0	64	
0	65	
0	66	
0	67	
PNP	68	
0	69	
0	70	
0	71	

About 'Mirror' Inputs

'Mirror' Inputs reflect the status of an output in Fast Response mode. In module I/O-DI8-TO8, the first 8 inputs in Hardware Configuration are related to the actual physical inputs. The second 8 inputs mirror the status of the module's physical outputs.

The figure below shows the third module in a project. If O67 enters Fast Response mode, the status of I75 will change to match the changing status of O67.

Hardware Configuration

Vision
Snap-in I/O
I/O Expansions

IO-DI8-R04
IO-DI8-TO8/RO8
IO-R08
EX90-DI8-R08
IO-AI4-A02

IO-DI8-TO8/RO8

Digital Inputs

	Op	Addr
	I	64
	I	65
	I	66
	I	67
	I	68
	I	69
	I	70
	I	71

PNP

Digital Outputs

	Op	Addr	Description
	O	64	
	O	65	
	O	66	
	O	67	
	O	68	
	O	69	
	O	70	
	O	71	

PNP

IO-DI8-TO8/RO8 IO-DI8-TO8/RO8 IO-DI8-TO8/RO8

Inputs

Opr.	Addr	Use
I	64	<input checked="" type="checkbox"/>
I	65	<input checked="" type="checkbox"/>
I	66	<input checked="" type="checkbox"/>
I	67	<input checked="" type="checkbox"/>
I	68	<input checked="" type="checkbox"/>
I	69	<input checked="" type="checkbox"/>
I	70	<input checked="" type="checkbox"/>
I	71	<input checked="" type="checkbox"/>
I	72	<input type="checkbox"/>
I	73	<input type="checkbox"/>
I	74	<input type="checkbox"/>
I	75	<input type="checkbox"/>
I	76	<input type="checkbox"/>
I	77	<input type="checkbox"/>
I	78	<input type="checkbox"/>
I	79	<input type="checkbox"/>

Physical Inputs

'Mirror Inputs'

175 mirrors the current state of O67

Outputs

Opr.	Addr	Use
O	64	<input checked="" type="checkbox"/>
O	65	<input checked="" type="checkbox"/>
O	66	<input checked="" type="checkbox"/>
O	67	<input checked="" type="checkbox"/>
O	68	<input checked="" type="checkbox"/>
O	69	<input checked="" type="checkbox"/>
O	70	<input checked="" type="checkbox"/>
O	71	<input type="checkbox"/>
O	72	<input type="checkbox"/>
O	73	<input type="checkbox"/>
O	74	<input type="checkbox"/>
O	75	<input type="checkbox"/>
O	76	<input type="checkbox"/>
O	77	<input type="checkbox"/>
O	78	<input type="checkbox"/>
O	79	<input type="checkbox"/>

PH
OU


Tag
cor
Res
mo

'To
OU
Tu
Fa
Re
mc

Note • Older I/O Expansion Module models may not support Fast Response.

Checking the Model Version

The module bears a sticker which gives the version number. Versions previous to V4.00 do not support this function.



FB Operations

Fast Response operations are located on the FBs menu.

Configuration


Set Mode

Set Counter

Scan

Fast Response: Configuration


Your program must activate the Configuration before running Fast Response operations. You can do this by activating it as a power-up task.



Parameter	Function
Exp. Unit	This the DIN-rail position of the expansion module.
Status Messages	<p>The value in the linked MI indicates the status of the function</p> <ul style="list-style-type: none"> 0 - Function in progress. 1 - Complete without error. 2 - Buffer is full (impossible to send the command – please retry. <p>Note that SB 91 (in M91, Next1 and Vision) is set when the buffer is full.</p> <ul style="list-style-type: none"> 3 - The expansion module is processing another command – please retry. 6 - Communication Error (fatal) (expansion module does not exist).

Fast Response: Set Mode

Set Mode must follow the Fast Response Configuration. There are four modes available, as described in the section Mode Overview. The input and output options change according to the selected mode.



Set Mode Parameters

Type	Parameter	Function
Input	Address	The address of the actual input in the project's Hardware Configuration. When you select an input, the corresponding output is automatically selected: ex., selecting I0 automatically selects O0. Only odd-numbered addresses may be used.
	Rise/Fall	This is the event that causes the module to begin counting the input's Time Span
	Time Span	The value in the MI linked to Time Span provides a preset timer value. - Latch: once the time span is activated, time continues to elapse even if the input changes status. - On Delay: If the input changes status while the time span is being counted, the counting stops. When the input status changes again, the counter reset, and begins again from the preset value.
Output	Address	When you select an input, the corresponding output is automatically selected.
	Set/Reset	This sets the output's Start State .

	<p>Set: Selecting Set means that the output's start state is OFF. After Input 1's Time span has elapsed, the output turns ON. Reset Selecting Reset means that the output's start state is ON. After Input 1's Time span has elapsed, the output turns OFF.</p>
Time Span	This is the amount of time the output will be ON or OFF


Notes •

Do not place Set Mode directly on the Ladder rail. Your program should activate Set Mode for a single program scan. If your application changes modes, activate Set Mode for a single scan at each change.

- In Two Input modes; note that you can only assign odd addresses to Input 1.
- When an input is selected, the function controls the corresponding output. For example, if I35 is selected, O35 will be controlled by the function.
- In Two Input modes, when the first input address is selected, the function automatically selects the **previous** address for the second input.

Fast Response: Set Counter


Set Counter enables you to store a value into the I/O Expansion Module's high speed counter. You can also initialize the counter by storing the value zero.



Notes • Do not place Set Counter directly on the Ladder rail. Your program should activate Set Counter for a single program scan, each time you wish to set the counter.

Fast Response: Scan

A Scan FB must be included for every Fast Response Configuration in the application. When an application contains more than 1 Configuration in the Ladder, the Scan FB displays the Select Name drop-down list, enabling you to link the desired Configuration.



Note • | The Scan FB must be on the left-hand ladder rail.

BAS (Building Automation Systems)

BAS, CSI Overview

The BAS operations enable Vision controllers to exchange data with CSI building environment cards. BAS operations are located on the FBs toolbar.

To use BAS, you must initialise the PLC COM port to 9600, 8n1.

BAS Operations

Configuration


Scan

Open Session

Read, Write Inputs: Digital or Analog I/Os

Configuration

The BAS Configuration must be included in the application. In addition, Scan is required in order to enable the PLC application to receive BAS messages; the Open Session operation must also be included in the application.




Configuration Parameters

Parameter	Type	Function
Port #	Constant	Enter the number of the PLC serial port that connects the PLC to the BAS network.
Router ID	Constant	If the BAS card is accessed via a router, select the ID number.
Time Out	MI or Constant	Amount of time the PLC will wait for a reply, units of 10 mS.
Retries	MI or Constant	Number of times the PLC will attempt to send a message.
Function in Progress	MB	Turns ON when the PLC sends a BAS data request, remains ON either until the Time Out is exceeded or until a message is received in answer to the data request. Use this MB as a condition to send a message.
Retries Made	MI or Constant	Number of times the PLC has attempted to send a message.
Status	MI	The value of the linked MI indicates messages as follows: Value Message 1 Operation completed successfully 2 (Transmit) Illegal card ID (0-255) 3 (Transmit) Illegal point value 4 (Transmit) Illegal bit offset 5 (Transmit)-Serial port busy 6 (Receive) Illegal length The actual length of the message does not match the length given in the first message byte 7 (Receive) Illegal card ID The ID received does not match the ID in the data request message 8 (Receive) Illegal Router

	The message was received from a router that is not the router named in the data request message
9	Illegal Command
	The command received does not match the command in the data request message
10	(Receive) Illegal point value
	The point received does not match the point in the data request message
11	(Receive) TimeOut
	An answer was not received before the timeout set in the BAS Configuration.
12	(Receive) Checksum error
13	(Receive) Illegal offset for IO type

Open Session


In order to run BAS operations, you must include Open Session in the application; it may be activated as a power-up task.



Scan

To enable the controller to receive messages, place an BAS Scan FB in your application and link it to a Configuration. When activated, this causes the controller to scan the Com port for incoming BAS messages.


Before you can receive a BAS message, you must initialize a COM port.



Read, Write Inputs: Digital or Analog I/Os


You can read from and write to digital or analog I/Os

Digital I/Os



Parameter	Type	Function
Card ID	MI or Constant	Enter the ID number of the card to be read from/written to.
Point Value	MI or Constant	Card Point to be read from/written to.
Bit offset	MI or Constant	Enter the bit offset value.
Result	MB	Read: Writes the current status of the I/O to the selected MB. Write: Writes the current status of the MB to the selected I/O.

Analog I/Os




Parameter	Type	Function
Card ID	MI or Constant	Enter the ID number of the card to be read from/written to.
Point Value	MI or Constant	Card Point to be read from/written to.
Bit offset	MI or Constant	Enter the bit offset value.
Result	MF	Read: Writes the current value of the I/O to the selected MF. Write: Writes the current value of the MF to the selected I/O.

Draw Axis

Draw Axis Overview

Use this function to place x and y axes, including ticks, on the Vision screen in response to Ladder conditions.

The axes may be used to provide a background for bar graphs, or in conjunction with the Trends function block.



Draw Axis operations are located on the FBs toolbar.

FB Operations


Configuration

Draw


Clear

Configuration

The Draw Axis Configuration sets the parameters the controller uses to draw the axis on the LCD. Each Draw Axis operation is linked to a Configuration.



#	Parameter
1	Axis Type (direction), x or y
2	X-Start Position
3	Y-Start Position
4	Axis Length
5	Space between Ticks
6	Height of Ticks
7	Axis Thickness
8	Tick Thickness




Parameter	Type	Function
Axis Type	Constant	This sets the axis direction. Select between: X axis (horizontal). Y axis (vertical).
X Start Position	MI,ML, DW, or Constant	x-Origin of the axis, in pixels.
Y Start Position	MI,ML, DW, or Constant	y-Origin of the axis, in pixels.
Axis Length	MI,ML, DW, or	Length of the axis, in pixels.

	Constant	
Space Between Ticks	MI,ML, DW, or Constant	Distance between ticks, in pixels.
Height Of Ticks	MI,ML, DW, or Constant	Height of ticks, in pixels.
Axis Thickness	MI,ML, DW, or Constant	Thickness of the main axis line, in pixels.
Tick Thickness	MI,ML, DW, or Constant	Thickness of ticks, in pixels.
Status	MI	<p>If the axis or ticks are not drawn when the Draw operation is called, check the value of the Status MI.</p> <p>The first 4 (LSB) bits of the MI act as a bitmap to indicate the messages listed below.</p> <p>Bit Message</p> <p>0 PLC in Info Mode, Axis cannot be drawn</p> <p>1 PLC in Info Mode, Axis cannot be cleared (erased).</p> <p>2 The main axis line cannot be drawn because:</p> <ul style="list-style-type: none"> - the length of the line exceeds the screen's dimensions. - the coordinates of the line are not within the screen. - both of the above. <p>3 The ticks cannot be drawn because:</p> <ul style="list-style-type: none"> - the length of the ticks exceeds the screen's dimensions. - the ticks are not within the screen.

Each axis, whether x or y, that is drawn on screen requires a separate Draw Axis Configuration. In addition, note that in order to obtain an axis with different tick heights, you must superimpose one axis on top of another.

The example below shows a horizontal axis that is composed of 2 separate Draw Axis Configurations. Note that the parameters supplying coordinates are identical; the tick height and spacing are different.



Draw Axis Configuration

Name: Draw Axis 1a

Draw Axis 1a
Ticks: 5 pixels high, spaced 10 pixels apart.

Params	Type	Add	Unit	Description
D#		0	DEC	X Axis
D#		50	DEC	X Start Position
D#		210	DEC	Y Start Position
D#		200	DEC	Axis Length
D#		10	DEC	Space Between Ticks
D#		5	DEC	Height Of Ticks
D#		2	DEC	Axis Width
D#		1	DEC	Tick Width
OUT	MI	1	DEC	Status

Ok Cancel Help

Draw Axis Configuration

Name: Draw Axis 1b

Draw Axis 1b
Ticks: 15 pixels high, spaced 40 pixels apart.

Params	Type	Add	Unit	Description
D#		0	DEC	X Axis
D#		50	DEC	X Start Position
D#		210	DEC	Y Start Position
D#		200	DEC	Axis Length
D#		40	DEC	Space Between Ticks
D#		15	DEC	Height Of Ticks
D#		2	DEC	Axis Width
D#		1	DEC	Tick Width
OUT	MI	2	DEC	Status

Ok Cancel Help


Draw

To display the axis on screen:

1. Place a Draw operation in the Ladder application.
2. Link it to the desired Configuration.

When Draw is activated, generally by a positive transitional contact, the axis will appear on screen. If the axis does not appear, check the Status MI in the Draw Axis Configuration.

The axis remains on screen until it is cleared by a Clear operation.




Clear

To clear the axis from the screen:

1. Place a Clear operation in the Ladder application.
2. Link it to the desired Configuration.

When Clear is activated, generally by a positive transitional contact, the axis disappears from the screen.



Note •

The Draw Axis Clear clears the last axis drawn.

This means that if the application:

Draws an axis,

Redraws the same axis, but after changing the Configuration's parameters, changing the location/appearance of the axis,

Runs Clear Draw Axis

The result is that only the axis drawn in Step 2 will be cleared.

This means that you must run Clear Draw Axis **before** redrawing an axis.